Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun BRSC006

Braun PureAqua BRSC006 Water Filter Cartridge

INSTRUCTION MANUAL

1. Introduction

This manual provides essential information for the proper installation, operation, and maintenance of your Braun PureAqua BRSC006 Water Filter Cartridge. Designed for use with compatible coffee machines, this filter significantly improves the taste of your coffee by reducing chlorine and helps extend the life of your appliance by minimizing calcification.

2. Safety Information

- Use only with potable (drinkable) water.
- Do not expose the filter cartridge to direct sunlight or extreme temperatures.
- Keep out of reach of children.
- Ensure the filter is correctly installed to prevent leaks.
- Dispose of used filters according to local regulations.

3. Package Contents

Your package should contain:

- 2 x Braun PureAqua BRSC006 Water Filter Cartridges



Image: The retail packaging for Braun PureAqua BRSC006 water filter cartridges, showing two filters inside.

4. Setup and Installation

Follow these general steps for installing your Braun PureAqua BRSC006 water filter cartridge. Always refer to your specific coffee machine's instruction manual for detailed, model-specific installation procedures.

1. **Prepare the Filter:** Remove the new filter cartridge from its packaging.
2. **Rinse the Filter:** Hold the filter under cold running water for approximately 1 minute to rinse it and remove any loose particles.
3. **Prime the Filter:** Submerge the filter completely in a container of cold water, gently shaking it to release any air bubbles. This ensures proper water flow.
4. **Locate Filter Holder:** Identify the water filter holder or reservoir in your coffee machine. This is typically located in the water tank.
5. **Insert Filter:** Carefully insert the primed filter cartridge into the designated holder. Ensure it clicks securely into place.
6. **Fill Water Tank:** Fill the coffee machine's water tank with fresh, cold water.
7. **Perform Initial Rinse:** Run a few cycles of plain water through your coffee machine without coffee to flush the system and activate the filter. Refer to your coffee machine's manual for specific instructions on this step.



Image: Two Braun PureAqua BRSC006 water filter cartridges, ready for installation.



Image: A close-up view of a single Braun PureAqua BRSC006 water filter cartridge.

5. Operating Instructions

Once installed, the Braun PureAqua BRSC006 water filter cartridge works automatically to filter the water used by your coffee machine. It continuously reduces chlorine and calcification as water passes through it, ensuring optimal water quality for your beverages.

- The filter enhances the natural aroma and flavor of your coffee.
- It helps protect your coffee machine from limescale buildup, which can prolong its operational life.



Image: A steaming cup of coffee, symbolizing the enhanced taste provided by filtered water.



Image: Two cups of coffee, highlighting the enjoyment of a quality beverage.



Image: A person preparing coffee using a coffee machine, demonstrating the filter's application.

6. Maintenance

Regular replacement of the water filter cartridge is crucial for maintaining optimal water quality and protecting your coffee machine.

- **Replacement Frequency:** It is recommended to replace the Braun PureAqua BRSC006 water filter cartridge approximately every 2 months, or after filtering about 50 liters of water, whichever comes first. This duration may vary based on local water hardness and usage.
- **Disposal:** Dispose of used filter cartridges responsibly according to your local waste disposal guidelines.



Image: Top view of the water filter cartridge, showing its design for easy handling.

7. Troubleshooting

If you experience issues, consider the following common solutions:

- **Poor Coffee Taste:** Ensure the filter is correctly installed and has been primed. If the filter is old, replace it.
- **Slow Water Flow:** This could indicate a clogged filter. Replace the filter cartridge. Also, check your coffee machine's descaling status, as limescale buildup in the machine itself can restrict flow.

- **Leaks:** Verify that the filter cartridge is securely seated in its holder within the water tank.

8. Specifications

Brand	Braun
Model Number	BRSC006 (also AX13210006)
Product Dimensions (L x W x H)	20 x 14 x 5 cm
Item Weight	92 g
Compatibility	Coffee Machines
External Test Certification	NSF
Product Benefits	Eliminates chlorine and limescale to improve coffee flavor and reduce calcification
Country of Origin	Italy

9. Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your coffee machine or visit the official Braun website. Keep your proof of purchase for any warranty claims.
For further assistance, you may contact Braun customer service directly through their official support channels.

© 2025 Braun. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07MQMR474

More documents and user manuals: **https://manuals.plus/**