Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Geepas GUH2483

Geepas Ultrasonic Humidifier GUH2483 User Manual

Model: GUH2483

1. Introduction

Thank you for purchasing the Geepas Ultrasonic Humidifier Model GUH2483. This device is designed to add moisture to the air, helping to alleviate dry air conditions and improve air quality in your home or office. Please read this manual thoroughly before operating the humidifier to ensure safe and efficient use. Keep this manual for future reference.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons.

- Always place the humidifier on a firm, flat, waterproof surface at least 12 inches (30 cm) away from walls and appliances.
- Do not operate the humidifier if the cord or plug is damaged.
- Do not place the humidifier near heat sources such as stoves, radiators, or direct sunlight.
- Always unplug the humidifier before filling, cleaning, or moving it.
- Do not add essential oils or other additives directly into the water tank unless specifically designed for this model.
- Keep out of reach of children and pets.
- Do not block air vents.
- Use only clean, cool tap water. Distilled or demineralized water is recommended to prevent mineral buildup.

3. Product Overview

Familiarize yourself with the components of your Geepas Ultrasonic Humidifier.





Image 1: Geepas Ultrasonic Humidifier GUH2483. This image displays the silver-colored Geepas Ultrasonic Humidifier. It features a transparent water level indicator on the front, allowing users to monitor the water volume. Below the indicator, the "GEEPAS" logo is visible. At the base of the unit, there is a rotary control knob with markings for "ON" and "MAX", used to power on the device and adjust

the mist output intensity. The top of the unit shows the mist outlet area.

Key Components:

- **Water Tank:** Holds the water for humidification.
- **Mist Outlet:** Where the cool mist is dispersed into the air.
- **Water Level Indicator:** Transparent window to view the water level.
- **Control Knob:** Used to turn the unit on/off and adjust mist output.
- **Base Unit:** Contains the ultrasonic transducer and water reservoir.

4. Setup Instructions

4.1 Unpacking

1. Carefully remove the humidifier from its packaging.
2. Remove all packing materials and ensure no parts are missing.
3. Inspect the unit for any damage. If damaged, do not operate and contact customer support.

4.2 Placement

- Place the humidifier on a flat, stable, and waterproof surface.
- Ensure it is at least 12 inches (30 cm) away from walls, furniture, and electronic devices to prevent moisture damage.
- Do not place it on carpet or absorbent surfaces.

4.3 Filling the Water Tank

1. Ensure the humidifier is unplugged from the power outlet.
2. Carefully remove the water tank from the base unit.
3. Unscrew the tank cap at the bottom of the water tank.
4. Fill the water tank with clean, cool tap water. Distilled or demineralized water is recommended to minimize mineral residue. Do not fill with hot water.
5. Securely screw the tank cap back on.
6. Place the filled water tank back onto the base unit, ensuring it is seated correctly.

5. Operating Instructions

1. After filling the water tank and placing it on the base, plug the power cord into a suitable electrical outlet (100-240V / 50Hz).
2. Turn the control knob clockwise from the "OFF" position. The unit will turn on.
3. Continue turning the knob clockwise to increase the mist output. The "MAX" setting provides the highest mist volume.
4. Adjust the mist output to your desired level.
5. To turn off the humidifier, rotate the control knob counter-clockwise until it clicks into the "OFF" position.
6. When the water level is low, the humidifier may automatically shut off. Refill the water tank as described in Section 4.3.

6. Maintenance and Cleaning

Regular cleaning is essential to prevent mineral buildup and ensure optimal performance and hygiene of your humidifier. Always unplug the unit before cleaning.

6.1 Daily Maintenance

- Empty any remaining water from the tank and base.
- Rinse the water tank and base with fresh water.
- Allow all parts to air dry completely before reassembly or storage.

6.2 Weekly Cleaning (Mineral Deposit Removal)

1. Unplug the humidifier and remove the water tank.
2. Pour 1 cup (250 ml) of undiluted white vinegar into the base reservoir and let it soak for 20 minutes.
3. Gently scrub the ultrasonic transducer (the small disc in the base) and the inside of the base with a soft brush or cloth to remove mineral buildup.
4. Fill the water tank with 1 cup (250 ml) of white vinegar and 1 cup (250 ml) of water. Shake gently and let it soak for 20 minutes.
5. Rinse the base and water tank thoroughly with clean water until the smell of vinegar is gone.
6. Allow all parts to air dry completely before reassembly.

6.3 Storage

When storing the humidifier for an extended period, ensure all parts are clean and completely dry. Store the unit in its original packaging in a cool, dry place.

7. Troubleshooting

Problem	Possible Cause	Solution
No mist output	• No power • No water in tank • Mineral buildup on transducer • Water tank not seated correctly	• Check power connection • Refill water tank • Clean transducer (see Section 6.2) • Re-seat water tank firmly
Unusual odor	• New unit odor • Stagnant water or mineral buildup	• Run for a few days, odor should dissipate • Clean the unit thoroughly (see Section 6.2)
White dust around humidifier	• Hard water mineral content	• Use distilled or demineralized water • Clean the unit regularly

8. Specifications

Feature	Detail
Brand	Geepas
Model Number	GUH2483 (Item model number: 2724465664376)
Type	Ultrasonic Humidifier

Feature	Detail
Capacity	4.00 Liters (4000 Milliliters)
Power	32 Watts
Atomization Quantity	250 ML/H
Voltage / Frequency	100-240 V / 50Hz
Operation Mode	Ultrasonic
Control Method	Touch (*Note: Based on image, appears to be a rotary knob, but product data states 'Touch'. User should refer to actual product.*)
Product Dimensions	24.2 x 32.6 x 28.2 cm
Weight	1.84 kg

9. Warranty and Support

Geepas products are manufactured to the highest quality standards. While specific warranty details are not provided in this manual, some retailers may offer a warranty period (e.g., 2 years as mentioned in customer reviews). Please retain your purchase receipt as proof of purchase for any warranty claims.
For technical support, service, or inquiries regarding your Geepas Ultrasonic Humidifier, please contact your retailer or visit the official Geepas website for customer service information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07N6MWPNJ

More documents and user manuals: **https://manuals.plus/**