Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER ANU-090200A

PK Power 9V 2A AC Adapter Instruction Manual

Model: ANU-090200A

1. Introduction

This manual provides essential instructions for the safe and effective use of your PK Power 9V 2A AC Adapter. This power supply is designed to provide reliable power to various compatible DYMO LabelManager models, ensuring consistent performance without the need for batteries.

Compatible DYMO LabelManager Models include:

- LM-100, LM-110, LM-150, LM-155, LM-160
- LM-200, LM-210D, LM-220P
- LM-300, LM-350, LM-400, LM-450
- LM-500TS, 500TS (1790417 touch)
- LP-200, LP-250, LP-300, LP-350
- 1000, 1000 Plus, 2000, 3500, 4500, 5500
- LT-100H, LT-100T

2. Setup

Follow these steps to correctly set up your AC adapter with your compatible device.

1. **Verify Compatibility:** Ensure your device requires a 9V DC power input with a 5.5mm outer diameter / 2.5mm inner diameter barrel connector and an internal negative (-) polarity. This adapter features an outer positive (+) and inner negative (-) polarity.
2. **Connect to Device:** Insert the barrel connector end of the AC adapter cable into the power input port of your DYMO LabelManager device.
3. **Connect to Power Outlet:** Plug the AC adapter into a standard 100-240V AC wall outlet.
4. **Power On:** Turn on your DYMO LabelManager device. It should now receive power from the adapter.



Image: The adapter's barrel connector correctly inserted into a compatible DYMO LabelManager device.



Image: Visual guide for identifying the correct barrel connector type for the adapter.

3. Operating Instructions

Once connected, the adapter provides continuous power to your device. No specific operational steps are required for the adapter itself beyond proper connection.

Safety Features

The PK Power AC Adapter incorporates multiple safety mechanisms to protect your device and ensure safe operation:

- **Over Charge Protection:** Prevents damage from excessive charging.
- **Over Voltage Protection:** Safeguards against voltage spikes.
- **Short-circuit Protection:** Protects against electrical shorts.
- **Over Current Protection:** Prevents damage from excessive current flow.
- **Over Temperature Protection:** Monitors and prevents overheating.



Image: Overview of the adapter's built-in safety protections.

4. Maintenance

To ensure the longevity and optimal performance of your AC adapter, observe the following maintenance guidelines:

- **Storage:** Store the adapter in a cool, dry, and well-ventilated area when not in use. Avoid extreme temperatures

and high humidity.

- **Cleaning:** Disconnect the adapter from the power outlet and device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Cable Care:** Avoid bending or crimping the cable excessively. Do not place heavy objects on the cable.
- **Ventilation:** Ensure the adapter has adequate ventilation during operation. Do not cover it or place it in enclosed spaces that could lead to overheating.



Image: Proper ventilation and humidity are important for long-term use.

5. Troubleshooting

If you encounter issues with your AC adapter, refer to the following common troubleshooting steps:

- **Device Not Powering On:**
  - Ensure the adapter is securely plugged into both the wall outlet and your DYMO LabelManager device.
  - Verify the wall outlet is functional by testing it with another device.

- Confirm that your DYMO LabelManager device is compatible with a 9V 2A power supply and has the correct barrel connector size (5.5mm OD / 2.5mm ID) and internal negative polarity.
- Inspect the adapter cable and connector for any visible damage. If damaged, discontinue use.

- **Intermittent Power:**
  - Check all connections for looseness.
  - Avoid placing the adapter or cable in positions where they might be strained or moved frequently.
- **Adapter Overheating:**
  - Ensure the adapter is in a well-ventilated area and not covered.
  - If overheating persists, disconnect immediately and contact support.

If troubleshooting steps do not resolve the issue, please refer to the Support Information section.

6. Specifications

Model	ANU-090200A
Input	100-240V AC, 50/60Hz
Output	9V DC, 2A (2000mA)
Connector Type	Barrel Connector, 5.5mm Outer Diameter / 2.5mm Inner Diameter
Polarity	Internal Negative (-), Outer Positive (+)
Cable Length	6.6 feet (2 meters)
Dimensions (Adapter Body)	Approximately 2.82 x 1.57 x 1.44 inches
Weight	Approximately 2.39 ounces
Color	Black



Image: Physical dimensions of the power adapter and cable length.

7. Warranty Information

This PK Power AC Adapter comes with a**12-month warranty** from the date of purchase. This warranty covers manufacturing defects and ensures reliable operation under normal use. Please retain your proof of purchase for warranty claims.

8. Support Information

For any questions, technical assistance, or warranty inquiries regarding your PK Power AC Adapter, please contact our customer support team. We are committed to providing quality service and support.
Please refer to the contact information provided with your purchase or visit the official PKPOWER website for further assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07N83G8VV

More documents and user manuals: **https://manuals.plus/**