Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Geepas 2724291236617

Geepas 2500W Wall Heater Instruction Manual

Model: 2724291236617

Important Safety Instructions

Please read all instructions carefully before using this appliance and retain for future reference.

- Ensure the power supply voltage matches the rating label on the heater.
- Do not operate the heater with a damaged cord or plug. If the cord is damaged, it must be replaced by the manufacturer or a qualified service agent.
- Keep combustible materials such as furniture, pillows, bedding, papers, clothes, and curtains at least 1 meter (3 feet) from the front and sides of the heater.
- Do not use the heater in bathrooms, laundry areas, or similar indoor locations where it may come into contact with water.
- Avoid inserting fingers or foreign objects into any ventilation or exhaust opening, as this may cause electric shock, fire, or damage to the heater.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not cover the heater. Overheating protection is built-in, but proper ventilation is crucial.
- Always unplug the heater when not in use.

Product Overview

The Geepas Wall Heater provides efficient heating for indoor spaces. It features ceramic heating elements, multiple heat settings, a cooling fan option, and convenient remote control operation. Its wall-mounted design saves floor space.



Image: Front view of the Geepas Wall Heater, showing its sleek design and digital display.

Key Features:

- Ceramic Heating Element for efficient warmth.
- Two Heat Settings (1000W and 2000W) for adjustable comfort.
- Cooling Fan System for year-round use.
- 7.5-Hour Timer for scheduled operation.
- Remote Control for convenient adjustments from a distance.
- On-device Control Panel for direct operation.
- Automatic Oscillation Vents for wide heat distribution.
- Overheat Protection for safety.
- Digital Display indicating temperature and functions.

Setup and Installation

This heater is designed for wall-mounted installation. Ensure you have the necessary tools and a suitable location before proceeding.

Choosing a Location:

- Select a wall location that is clear of obstructions and at least 1 meter (3 feet) away from any combustible materials.
- Ensure the wall material can support the weight of the heater.
- The heater should be mounted at a height that allows for optimal heat distribution and safe operation, typically above eye level but accessible for controls.

Mounting Steps:

1. Mark the desired mounting points on the wall using the provided template or by measuring the heater's mounting holes.
2. Drill pilot holes at the marked locations.
3. Insert wall anchors (if required for your wall type).
4. Secure the mounting bracket to the wall using appropriate screws.
5. Carefully lift the heater and align its mounting slots with the bracket.
6. Slide the heater onto the bracket until it locks securely in place.




Image: Geepas Wall Heater mounted on a wall in a living space, demonstrating its placement and heat output.

Power Connection:

Once mounted, plug the heater's power cord into a suitable electrical outlet. Ensure the outlet is easily accessible and not overloaded.

Operating Instructions

Your Geepas Wall Heater can be operated using the control panel on the unit or the included remote control.



Image: Hand holding the remote control for the Geepas Wall Heater, showing buttons for power, function, timer, and swing.

Control Panel and Remote Control Functions:

- **Power Button:** Turns the heater ON or OFF.
- **Function Button:** Cycles through heating modes (1000W, 2000W) and the cooling fan mode.
- **Timer Button:** Activates and adjusts the timer function up to 7.5 hours. Each press typically increases the timer by 0.5 hours.
- **Swing Button:** Activates or deactivates the automatic oscillation of the air vents for wider heat distribution.
- **Temperature Adjustment:** Use the '+' and '-' buttons (if available on your model's remote/panel) to set the desired temperature. The digital display will show the current and set temperature.

Digital Display:

The digital display on the heater shows the current operating mode, set temperature, and remaining timer duration.

Maintenance

Regular maintenance ensures the longevity and efficient operation of your heater.

Cleaning:

- Always unplug the heater and allow it to cool completely before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Use a vacuum cleaner with a brush attachment to remove dust from the air intake and exhaust vents.
- Never immerse the heater in water or any other liquid.

Storage:

When not in use for extended periods, store the heater in a cool, dry place, preferably in its original packaging, to protect it from dust and damage.

Troubleshooting

If you encounter issues with your heater, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Heater does not turn on.	No power supply; Power button not pressed; Overheat protection activated.	Check power cord and outlet; Press power button; Unplug, wait 30 minutes, then plug back in.
No heat output.	Cooling fan mode selected; Low heat setting selected.	Press Function button to select a heating mode; Select 2000W heat setting.
Remote control not working.	Batteries are dead or incorrectly inserted; Obstruction between remote and heater.	Replace batteries; Ensure clear line of sight to the heater's receiver.
Heater suddenly turns off.	Overheat protection activated; Timer has expired.	Unplug, wait 30 minutes, then plug back in; Check timer settings.

If the problem persists after trying these solutions, please contact customer support.

Specifications

Brand: Geepas

Model Number: 2724291236617

Power Settings: 1000W, 2000W (Maximum 2500W capacity)

Heating Element: Ceramic

Number of Speeds: 2

Mounting Type: Wall Mount

Control Type: Remote Control, On-device Control Panel

Timer: Up to 7.5 hours

Cooling Function: Yes

Oscillation: Automatic Vents

Dimensions (LxWxH): 72 x 16.6 x 28.4 cm

Item Weight: 4.94 Kilograms

Material: Plastic

Color: White

Power Source: Corded Electric

Heating Method: Convection

Recommended Use: Indoor, Office

Warranty Information

This Geepas Wall Heater comes with a **two-year warranty** from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects and malfunctions under normal use. It does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear.

Customer Support

For any questions, technical assistance, or warranty claims, please contact Geepas customer support. Refer to the contact information provided in your product packaging or visit the official Geepas website for support details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07NF1PYZR

More documents and user manuals: **https://manuals.plus/**