Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire Bullet Ice Maker

Frigidaire Stainless Steel Countertop Ice Maker Machine

USER INSTRUCTION MANUAL

Introduction

Welcome to the user instruction manual for your new Frigidaire Stainless Steel Countertop Ice Maker. This appliance is designed to provide a convenient and efficient way to produce ice for various occasions, from daily use to entertaining guests. With its rapid ice production capabilities and user-friendly design, you can enjoy a continuous supply of bullet-shaped ice cubes. Please read this manual thoroughly before operating your ice maker to ensure safe and optimal performance.



Figure 1: Frigidaire Stainless Steel Countertop Ice Maker Machine

Safety Information

IMPORTANT SAFETY INSTRUCTIONS: READ ALL INSTRUCTIONS BEFORE USE.

- Always unplug the ice maker from the power outlet before cleaning or when not in use.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Keep the ice maker away from heat sources and direct sunlight.
- Ensure proper ventilation around the unit. Do not block air vents.
- Use only potable water in the reservoir.
- Supervise children when the appliance is in use.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been

damaged in any manner.

Product Features

- **Rapid Ice Production:** Produces 9 bullet-shaped ice cubes every 7-15 minutes, with a capacity of up to 26 pounds in 24 hours.
- **Large Capacity:** Stores up to 1.5 lbs of ice at a time in the ice basket.
- **Sleek & Portable Design:** Features a stainless-steel finish, LED display, and a large see-through window. Compact dimensions (14.5" H x 11" W x 15" D) and lightweight (19.51 lbs) with a convenient carry handle.
- **Effortless Operation:** User-friendly electronic controls with indicators for 'Add Water' and 'Ice Full'.
- **Quiet & Efficient Cooling:** Built-in air outlet ensures continuous ice production without overheating and with low noise.
- **Included Accessories:** Comes with an ice shovel and drain plug for easy ice retrieval and cleaning.

Setup

1. **Unpacking:** Carefully remove the ice maker from its packaging. Remove all packing materials, including any tape or protective film.
2. **Placement:** Place the ice maker on a flat, stable surface away from direct sunlight and heat sources. Ensure there is adequate ventilation around the unit, especially the air outlet. The sleek and compact design allows for versatile placement on your countertop.



Figure 2: Sleek and Compact Design for Easy Placement

3. **Initial Cleaning:** Before first use, clean the interior of the ice maker. Remove the ice basket and wash it with warm, soapy water. Wipe the interior with a soft cloth. Rinse thoroughly and dry.
4. **Fill Water Reservoir:** Open the lid and fill the water reservoir with potable water up to the MAX fill line. Do not overfill. The large 2.3 qt. water tank capacity ensures uninterrupted ice making.



Figure 3: Filling the Water Reservoir

5. **Power Connection:** Plug the power cord into a grounded electrical outlet (115 Volts).

Operating Instructions

1. **Power On:** Press the **ON/OFF** button on the control panel to turn on the ice maker. The 'POWER' indicator light will illuminate.




Figure 4: Intuitive Digital LED Control Panel

2. **Select Ice Size:** Press the **SELECT** button to choose your desired ice cube size: 'S' for small or 'L' for large. The corresponding indicator light will illuminate.
3. **Ice Making Cycle:** The ice maker will begin its first ice-making cycle. This typically takes 7-15 minutes depending on the selected size and ambient temperature.
4. **Ice Collection:** Once ice cubes are formed, they will be released into the ice basket. The 'ICE FULL' indicator light will illuminate when the basket is full, and the unit will pause ice production. Empty the ice basket as needed using the provided ice shovel.



Figure 5: Ice Basket and Shovel for Easy Retrieval

5. **Add Water Indicator:** If the water reservoir runs low, the 'ADD WATER' indicator light will illuminate, and the unit will pause. Refill the reservoir to resume ice production.
6. **Power Off:** To turn off the ice maker, press the**ON/OFF** button again.

Maintenance

- **Regular Cleaning:** For best performance and hygiene, clean the ice maker regularly.
- **Draining Water:** When not in use for an extended period, or for thorough cleaning, drain the water from the reservoir using the drain plug located at the bottom of the unit.
- **Interior Cleaning:** Use a soft cloth dampened with a mild detergent solution to wipe the interior surfaces, including the ice basket and water reservoir. Rinse with clean water and dry thoroughly.
- **Exterior Cleaning:** Wipe the exterior of the unit with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** If storing the ice maker for a long time, ensure it is completely dry. Store it in a cool, dry place.

Troubleshooting

Problem	Possible Cause	Solution
'ADD WATER' indicator is on	Water reservoir is empty or low.	Fill the water reservoir with potable water up to the MAX fill line.
'ICE FULL' indicator is on	Ice basket is full.	Empty the ice basket.
Ice maker is not producing ice	No water in reservoir; unit not powered on; ambient temperature too high.	Ensure water is filled, unit is plugged in and powered on. Operate in a cooler environment.
Ice cubes are too small or clumpy	Water temperature is too high; unit needs more time to cool.	Use colder water. Allow the unit to run for a few cycles to reach optimal temperature. Select 'L' for larger cubes.
Unusual noise during operation	Normal operation sounds (water pump, ice dropping); unit not level.	Ensure the unit is on a stable, level surface. If noise persists and is abnormal, contact customer support.

Specifications

Feature	Detail
Model Name	Bullet Ice Maker
Ice Production Capacity	Up to 26 lbs per 24 hours
Ice Cube Production Time	9 cubes every 7-15 minutes
Ice Storage Capacity	1.5 lbs
Product Dimensions (H x W x D)	14.5" x 11" x 15" (approx. 36.8 cm x 27.9 cm x 38.1 cm)
Product Weight	19.51 lbs (approx. 8.85 kg)
Voltage	115 Volts
Manufacturer	Curtis



Figure 6: Product Dimensions Overview

Warranty and Support

Your Frigidaire Stainless Steel Countertop Ice Maker is manufactured by Curtis and is backed by a manufacturer's warranty. For specific warranty details, including coverage period and terms, please refer to the warranty card included with your product or visit the official Frigidaire website. For technical support, troubleshooting assistance beyond this manual, or to inquire about replacement parts, please contact Frigidaire Customer Service. Contact information can typically be found on the product packaging or the official brand website.

© 2025 Frigidaire. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07NJ6J39Y

More documents and user manuals: **https://manuals.plus/**