Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MOMOHO BTS0011

MOMOHO Tiny Mini Bluetooth Speaker

User Manual - Model: BTS0011

Introduction

Thank you for choosing the MOMOHO Tiny Mini Bluetooth Speaker. This compact and powerful speaker is designed to provide a clear, well-balanced audio experience wherever you go. Its small size makes it ideal for travel, outdoor activities, or simply enjoying music at home. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance of your device.



The MOMOHO Tiny Mini Bluetooth Speaker, demonstrating its incredibly compact size when held in an adult's hand.

What's Included

Your MOMOHO Tiny Mini Bluetooth Speaker package includes the following items:

- 1 x MOMOHO Tiny Mini Bluetooth Speaker
- 1 x USB-C Charging Cable
- 1 x Lanyard
- 1 x User Manual (this document)



All components included with your MOMOHO Tiny Mini Bluetooth Speaker: the speaker, USB-C cable, lanyard, and user manual.

Product Features

- **Mini Size, Powerful Sound:** Despite its tiny footprint, this speaker delivers clear, well-balanced, full-range audio.
- **Bluetooth Remote Shutter & Hands-Free Calling:** The multi-function button allows for remote selfie control and convenient call management.
- **TWS-360° Stereo Pairing:** Connect two MOMOHO speakers wirelessly for an immersive 360° stereo sound experience with doubled volume.
- **Sturdy and Durable Design:** Features a secure silicone bottom, ABS plastic shell for anti-dust and anti-fingerprint properties, and water resistance.
- **Latest Bluetooth 5.2 Technology:** Ensures lower power consumption, faster transmission, and stable connectivity with all Bluetooth-enabled devices.



An internal view highlighting the Hi-Fi sound quality components of the speaker.



The speaker's remote shutter function, useful for group photos.

Setup Guide

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the provided USB-C cable to the speaker's charging port and the other end to a USB power adapter (not included) or a computer's USB port. The indicator light will show charging status.

2. Powering On/Off

To power on the speaker, press and hold the multi-function button (located on the bottom) for 3 seconds until you hear an audible prompt. To power off, press and hold the button again for 3 seconds.

3. Bluetooth Pairing

1. Ensure the speaker is powered on and in pairing mode (indicator light will flash).
2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "BTS0011" from the list of devices.
4. Once connected, you will hear a confirmation sound, and the indicator light will turn solid.

4. TWS (True Wireless Stereo) Pairing

For an enhanced stereo experience, you can pair two MOMOHO Tiny Mini Bluetooth Speakers together:

1. Ensure both speakers are powered off.
2. Power on both speakers simultaneously. They will automatically attempt to pair with each other.
3. Once successfully paired, one speaker will act as the master and the other as the slave. You will hear a confirmation sound.
4. Now, connect your device to the master speaker via Bluetooth as described in step 3.



Two speakers paired for TWS stereo sound, providing a richer audio experience.

Operating Instructions

Button Functions (Single Multi-function Button)

Action	Function
Press and hold for 3 seconds	Power On / Power Off
Single press (while playing music)	Play / Pause Music
Single press (incoming call)	Answer / End Call
Double press (while playing music)	Next Track
Triple press (while playing music)	Previous Track
Single press (in camera mode on phone)	Remote Shutter (for selfies)

Note: Volume control is primarily managed through your connected device.

Portability and Usage

The speaker's compact design and included lanyard make it highly portable. You can easily attach it to your phone, backpack, or keychain, allowing you to enjoy your music on the go. Its durable construction is suitable for various environments, including hiking, running, car use, and general outdoor travel.



The speaker easily fits into a pocket or attaches to a bag, making it convenient for travel.

Your browser does not support the video tag.

Official MOMOHO video demonstrating the mini Bluetooth speaker's features and portability.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the speaker. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Resistance:** The speaker is water-resistant, meaning it can withstand splashes and light rain. Do not submerge the speaker in water. Ensure the charging port cover is securely closed to maintain water resistance.



The speaker is designed with water resistance for outdoor use.

Your browser does not support the video tag.

Video demonstrating the waterproof capabilities of the MOMOHO Bluetooth Speaker.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully.
Cannot pair with device.	Bluetooth is off on device; speaker not in pairing mode; too far from device.	Ensure Bluetooth is on, speaker is in pairing mode, and within 50 feet. Try restarting both devices.
No sound or low volume.	Volume on speaker or device is too low; speaker not connected.	Increase volume on both speaker and device. Re-pair the speaker.
TWS pairing failed.	Speakers not powered on simultaneously or too far apart.	Ensure both speakers are off, then power them on at the same time. Keep them close during pairing.
Sound distortion at high volume.	Volume too high for speaker's capacity.	Reduce the volume on your connected device.

Specifications

Feature	Detail
Model Name	BTS0011
Brand	MOMOHO
Connectivity Technology	Bluetooth, USB

Feature	Detail
Wireless Communication Technology	Bluetooth 5.2
Speaker Maximum Output Power	5 Watts
Item Weight	0.74 Ounces (approx. 21 grams)
Product Dimensions	1.4"D x 1.4"W x 1.57"H (approx. 3.5cm x 3.5cm x 4cm)
Power Source	Battery Powered (1 Lithium Polymer battery included)
Water Resistance Level	Water Resistant
Maximum Bluetooth Range	50 Feet (approx. 15 meters)
Built-in Microphone	Yes (for hands-free calling)
Material	ABS Plastic, Silicone

Warranty and Support

The MOMOHO Tiny Mini Bluetooth Speaker comes with a limited warranty. Please refer to the product packaging or the official MOMOHO website for specific warranty terms and conditions.

For any technical support, questions, or concerns regarding your speaker, please contact MOMOHO customer service through the retailer's platform or the official brand contact channels. Our team is dedicated to ensuring your satisfaction.

© 2024 MOMOHO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07NXXT1X2

More documents and user manuals: **https://manuals.plus/**