Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun BC02XB

Braun Classic Travel Analogue Alarm Clock

Model: BC02XB

Brand: Braun

1. Introduction

This manual provides detailed instructions for the Braun Classic Travel Analogue Alarm Clock, Model BC02XB. Designed for simplicity and reliability, this compact alarm clock features a quiet quartz movement, a crescendo beep alarm, and a convenient snooze/light function, making it an ideal travel companion.



Figure 1: Front view of the Braun Classic Travel Analogue Alarm Clock.

2. Key Features

- **Crescendo Beep Alarm:** The alarm sound gradually increases in frequency and volume to ensure you wake up.
- **Snooze/Light Function:** A single button activates a 5-minute snooze and illuminates the dial for 5 seconds.
- **Compact Size:** Perfectly designed for travel, measuring approximately W5.7cm x H5.7cm x D2.7cm.
- **Quiet Precision Quartz Movement:** Ensures accurate timekeeping with minimal noise.
- **Luminous Tipped Hands:** Hour and minute hands glow in the dark for improved legibility in low light conditions.
- **Iconic Yellow Second Hand:** A signature design element of Braun clocks.

3. Setup

3.1 Battery Installation

The clock requires 1x AA battery (not included). To install:

1. Locate the battery compartment cover on the back of the clock.
2. Slide the cover open.
3. Insert one AA battery, ensuring the correct polarity (+/-) as indicated inside the compartment.
4. Close the battery compartment cover securely.




Figure 2: Back view of the clock with controls and battery compartment.

3.2 Setting the Time and Alarm

On the back of the clock, you will find two adjustment wheels:

- **Time Setting Wheel:** Use the wheel marked with a clock icon to set the current time. Turn the wheel clockwise only to advance the hands.
- **Alarm Setting Wheel:** Use the wheel marked with an alarm icon to set your desired alarm time.

4. Operating Instructions

4.1 Activating/Deactivating the Alarm

The alarm is activated and deactivated using the lever located on the top of the clock:

- To **activate** the alarm, pull the lever up. A small green indicator will become visible.
- To **deactivate** the alarm, push the lever down. The green indicator will no longer be visible.



Figure 3: The crescendo beep alarm feature, which increases in frequency and volume.

4.2 Snooze and Light Function

The button located on the top right corner of the clock serves two purposes:

- **Snooze:** When the alarm sounds, press this button to activate a 5-minute snooze interval. The alarm will sound again after 5 minutes.
- **Light:** Press this button at any time to illuminate the clock's dial for 5 seconds, allowing you to read the time in the dark. The light will slowly fade out.




Figure 4: Integrated snooze and light function button on top of the clock.





Figure 5: Luminous tipped hands for easy reading in low light.

5. Maintenance

- Clean the clock with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid exposing the clock to extreme temperatures, direct sunlight, or high humidity.
- Replace the AA battery annually or when the clock's performance (e.g., alarm volume, light brightness) diminishes.

6. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Alarm does not sound or is too quiet.	Alarm not activated; low battery; alarm time not set correctly.	Ensure alarm lever is up (green indicator visible); replace battery; verify alarm time setting.
Clock hands are not moving or time is inaccurate.	Dead or low battery; hands obstructed; internal mechanism issue.	Replace battery; ensure no debris is obstructing hands; if problem persists, contact support.
Light function does not work.	Low battery; button malfunction.	Replace battery; if problem persists, contact support.

7. Specifications

Feature	Detail
Brand	Braun
Model Number	BC02XB
Color	Black
Display Type	Analog
Movement	Quiet Precision Quartz
Power Source	1 x AA Battery (Not Included)
Product Dimensions	5.7cm W x 5.7cm H x 2.7cm D (2.24"W x 1.06"H)
Item Weight	1.41 ounces (40 Grams)
Special Features	Alarm, Snooze, Light, Luminous Hands

8. Warranty & Support

This Braun Classic Travel Analogue Alarm Clock comes with a**2-year manufacturer's guarantee**.
For further assistance, troubleshooting, or warranty claims, please visit the official Braun Clocks website or refer to the included instruction manual (PDF) that came with your product.
Official Website: www.braun-clocks.com
User Guide (PDF): Download User Guide
User Manual (PDF): Download User Manual

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07P1B3J8X

More documents and user manuals: **https://manuals.plus/**