Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire EFR84ORD

Frigidaire Retro Compact Fridge Freezer Combo User Manual

Model: EFR84ORD | Brand: Frigidaire

Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Frigidaire Retro Compact Fridge Freezer Combo. This 3.2 cu. ft. two-door refrigerator features a flush-back design, a built-in bottle opener, and a sleek, stylish retro look. Please read this manual thoroughly before using your appliance.



Figure 1: Front view of the Frigidaire Retro Compact Fridge Freezer Combo.

Setup and Installation

1. Unpacking

- Carefully remove all packaging materials, including foam and adhesive tape.
- Inspect the refrigerator for any shipping damage. Report any damage to your retailer immediately.
- Clean the interior and exterior surfaces with a soft cloth and mild detergent before use.

2. Placement

- Place the refrigerator on a firm, level surface.
- Ensure adequate air circulation around the unit. Maintain at least 4 inches (10 cm) of space from walls and other appliances.
- The flush-back design allows for placement closer to a wall, optimizing space.
- Adjust the leveling legs at the bottom of the unit to ensure stability and proper door alignment.



Figure 2: Adjustable leveling legs ensure stability on uneven surfaces.

3. Electrical Connection

- Plug the refrigerator into a dedicated 110-volt grounded electrical outlet.
- Do not use extension cords or adapter plugs.

4. Initial Cooling

- Allow the refrigerator to stand upright for at least 2-4 hours before plugging it in to allow refrigerants to settle.
- Once plugged in, allow the unit to cool for at least 4 hours before placing food inside.

5. Reversible Door

The door is reversible, allowing for convenient and attractive placement anywhere in your home or garage. Refer to the detailed instructions in the full product manual for steps on reversing the door swing.



Figure 3: The reversible door offers flexible placement options.

Operating Instructions

1. Temperature Control

- The refrigerator features an adjustable thermostat to control the internal temperature.
- Turn the thermostat knob to your desired setting. Higher numbers indicate colder temperatures.
- Monitor the temperature for the first 24 hours and adjust as needed.

2. Storage and Organization

- The refrigerator includes spill-proof glass shelves that can be adjusted to accommodate various item sizes.
- Storage bins in the door are designed to keep smaller items, such as bottles and cans, handy and organized.
- Vegetable and fruit crisper bins help preserve the freshness of produce.
- The full-width, fixed wire freezer shelf and door bin provide organized storage for frozen foods.



Figure 4: Efficient interior organization with adjustable shelving and dedicated bins.

3. Internal Lighting

- Bright incandescent lighting illuminates the food and freezer compartments, making it easy to find items.

4. Built-in Bottle Opener

- A convenient built-in bottle opener is located on the side of the unit, eliminating the need for a separate tool.



Figure 5: The compact design includes a handy built-in bottle opener.

Maintenance

1. Cleaning

- Always unplug the refrigerator before cleaning.
- Clean the interior with a solution of mild detergent and warm water. Wipe dry thoroughly.
- The spill-proof glass shelves can be removed for easier cleaning.
- Clean the exterior with a soft cloth and mild detergent. Avoid abrasive cleaners or solvents.
- Periodically clean the condenser coils at the back of the unit to maintain efficiency.

2. Defrosting

- This refrigerator features a manual defrost system.
- Defrost the freezer compartment when ice accumulation reaches approximately 1/4 inch (0.6 cm) thickness.
- To defrost, unplug the unit, remove all food, and leave the freezer door open. Place towels on the floor to catch

melting ice.

- Do not use sharp objects or heating devices to speed up defrosting, as this can damage the unit.
- Once defrosted, clean and dry the interior before plugging the unit back in and returning food.

Troubleshooting

Before contacting customer service, please check the following common issues and solutions:

Problem	Possible Cause	Solution
Refrigerator does not operate	Not plugged in; circuit breaker tripped; temperature control set to OFF.	Ensure plug is secure; reset circuit breaker; turn temperature control to desired setting.
Temperature is too warm	Door left open; heavy food load; poor air circulation; temperature control set too high.	Check door seal; allow time for cooling with new load; ensure proper clearance; adjust temperature control to a colder setting.
Excessive noise	Unit not level; loose parts; items rattling inside.	Adjust leveling legs; check for loose components; rearrange items inside.
Frost buildup in freezer	Door not sealed properly; frequent door opening; high humidity.	Check door gasket; minimize door openings; perform manual defrost.

Specifications

Feature	Detail
Brand Name	Frigidaire
Model Info	EFR84ORD
Item Weight	45 pounds
Product Dimensions	19"D x 20.5"W x 35.5"H
Capacity	3.2 Cubic Feet
Annual Energy Consumption	5 Kilowatt Hours
Installation Type	Freestanding
Color	Red
Voltage	110 Volts
Number of Shelves	2 (Glass)
Crispers/Drawers	3
Defrost System	Manual
Door Hinges	Right (Reversible)
Material Type	Metal, Plastic

Feature	Detail
Included Components	Refrigerator, Compact Fridge



Frigidaire is a pending or registered trademark of Electrolux Home Products and used under license from Electrolux Home Products, Inc.

Figure 6: Product dimensions for planning placement.

Warranty and Support

This Frigidaire appliance comes with a manufacturer's warranty. Please refer to the warranty card included with your product for specific terms and conditions, including coverage duration and limitations.

For technical assistance, troubleshooting beyond this manual, or to inquire about replacement parts, please contact Frigidaire Customer Support. Contact information can typically be found on the product packaging, the official Frigidaire website, or your purchase documentation.

Additional protection plans may be available for purchase to extend coverage beyond the standard manufacturer's warranty. Please check with your retailer for details.

© 2023 Frigidaire. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07PQNWKHJ

More documents and user manuals: **https://manuals.plus/**