HITACHI LD55HTS02U-CO4K

Hitachi 55 Inch Smart LED 4K UHD TV User Manual
Model: LD55HTS02U-CO4K

1. Introduction

This manual provides essential information for the safe and efficient operation of your Hitachi 55 Inch Smart LED 4K UHD TV, model LD55HTS02U-CO4K. Please read these instructions thoroughly before using your television and retain them for future reference.
Your new Hitachi TV features a stunning 4K UHD display, smart functionality powered by Android 5.1.1 OS, and versatile connectivity options to enhance your viewing experience.

2. Safety Information

Always observe the following safety precautions to prevent electric shock, fire, or damage to the television:

- Do not expose the TV to rain or moisture.
- Do not open the TV casing; refer all servicing to qualified personnel.
- Ensure proper ventilation around the TV.
- Use only the power cord supplied with the TV.
- Keep batteries out of reach of children.

3. Setup

3.1 UNPACKING

Carefully remove the TV and all accessories from the packaging. Ensure all components are present:

- Hitachi 55 Inch Smart LED 4K UHD TV
- Remote Control
- TV Stand (2 pieces)
- Batteries for Remote Control

- Power Cord
- User Manual (this document)

3.2 STAND INSTALLATION

To install the TV stand:

1. Place the TV face down on a soft, flat surface to prevent screen damage.
2. Align each stand piece with the corresponding slots on the bottom of the TV.
3. Secure the stands using the provided screws. Ensure they are firmly attached.

Image: Front view of the Hitachi 55 Inch 4K UHD Smart TV with its stand installed, displaying a vibrant nature scene.

3.3 WALL MOUNTING (OPTIONAL)

If you choose to wall mount your TV, please use a compatible VESA wall mount kit (not included) and follow the instructions provided with the wall mount. Ensure the wall can support the weight of the TV.

3.4 CONNECTING EXTERNAL DEVICES

Your TV offers various connection ports:

- **HDMI (x3):** For connecting high-definition devices like Blu-ray players, game consoles, or set-top boxes.
- **USB (x2):** For connecting USB storage devices to play media files.
- **LAN:** For a wired internet connection.
- **Audio Out:** For connecting external audio systems.
- **Antenna/Cable Input:** For connecting an antenna or cable TV signal.

After connecting devices, power on the TV and select the correct input source using the remote control.

4. Operating Instructions

4.1 REMOTE CONTROL OVERVIEW

The remote control allows you to access all TV functions. Insert the provided batteries, ensuring correct polarity.

4.2 BASIC TV FUNCTIONS

- **Power:** Press the power button to turn the TV on or off.
- **Volume:** Use the VOL +/- buttons to adjust the sound level.
- **Channel:** Use the CH +/- buttons to change channels.
- **Input:** Press the INPUT button to select the desired source (HDMI 1/2/3, USB, TV).

4.3 SMART TV FEATURES

Your Hitachi TV runs on Android 5.1.1 OS, providing access to a range of smart features:

- **Web Browser:** Browse the internet directly from your TV.
- **App Store 3.0:** Download and install various applications.
- **Pre-installed Apps:** Includes YouTube, Golive 3.0, YuPPTV, Deezer.
- **Wi-Fi Direct:** Connect compatible devices directly to the TV without a router.
- **nScreen:** Share content from your mobile device to the TV.
- **VGA Mirroring:** Display content from a computer via VGA.

Image: A close-up of the Hitachi Smart TV interface, showing various application icons and a weather widget, indicating smart functionality.

4.4 NETWORK CONNECTION

To access smart features, connect your TV to the internet:

- **Wi-Fi:** Navigate to the network settings, select your Wi-Fi network, and enter the password.
- **Wired (LAN):** Connect an Ethernet cable from your router to the LAN port on the TV.

5. Maintenance

5.1 CLEANING THE TV

- **Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, use a screen cleaner specifically designed for TVs, applied to the cloth, not directly to the screen.

- **Body:** Wipe the TV casing with a soft, dry cloth. Do not use abrasive cleaners or solvents.

Always unplug the TV from the power outlet before cleaning.

5.2 SOFTWARE UPDATES

Periodically check for software updates in the TV's settings menu to ensure optimal performance and access to the latest features. Follow the on-screen instructions for any available updates.

6. Troubleshooting

If you encounter issues with your TV, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power	Power cord disconnected, no power from outlet	Check power cord connection, test outlet with another device.
No picture, but sound is present	Incorrect input source, faulty cable	Select correct input source, check HDMI/AV cable connections.
No sound, but picture is present	Volume muted or too low, external audio system issue	Increase volume, check mute status, verify external audio connections.
Remote control not working	Dead batteries, obstruction, remote not paired	Replace batteries, remove obstructions, re-pair remote if applicable.
Smart features not responding / Network issues	Wi-Fi disconnected, router issue	Check Wi-Fi connection in settings, restart router, try wired connection.

If the problem persists after trying these solutions, please contact customer support.

7. Specifications

Feature	Description
Model Number	LD55HTS02U-CO4K
Display Type	LED 4K UHD
Display Resolution	3840 x 2160 (ULTRA HD)

Feature	Description
Screen Size	55 Inches
Operating System	Android 5.1.1 OS
Processor	64-Bit Quad Core Processor
Audio Power Output	2 x 8W
Connectivity	HDMI x 3, USB x 2, LAN, Wi-Fi Direct, nScreen, VGA Mirroring
Tuner	DVB T 2 Tuner
Best Viewing Angle	178°
Dimensions (with stand)	1244 x 765.8 x 212 mm (L x H x D)
Dimensions (without stand)	1244 x 720 x 69.6 mm (L x H x D)
Net Weight	14.5 Kg
Gross Weight	19.0 Kg
Color	Black

8. Warranty and Support

Your Hitachi TV comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty period and coverage details. For technical support, service, or warranty claims, please contact your local Hitachi authorized service center or the retailer from whom you purchased the product. Keep your proof of purchase for warranty validation.

Related Documents - LD55HTS02U-CO4K

[Hitachi 75" Ultra HD Android TV 75QLEDSM20 Quick Start Guide](#)

Quick start guide for the Hitachi 75" Ultra HD Android TV (Model: 75QLEDSM20). Covers unboxing, TV stand attachment, port connections, remote control functions, and initial on-screen setup. Includes troubleshooting tips and support contact information.

[Hitachi 65" 4K UHD TV 65HL7101U Instruction Manual](#)

This is the instruction manual for the Hitachi 65-inch 4K UHD Television, model 65HL7101U. It provides detailed guidance on setup, connections, operation, safety precautions, features, and technical specifications for optimal use.

[Hitachi 55HK6200U 55-inch Colour TV Instruction Manual](#)

Comprehensive instruction manual for the Hitachi 55HK6200U 55-inch Colour TV, covering setup, connections, first-time installation, internet connectivity, safety precautions, and remote control functions.

[Hitachi 43HAK5360 Ultra HD 4K Android TV Specifications](#)

Detailed specifications for the Hitachi 43HAK5360 Ultra HD 4K Android TV, including display, smart features, connectivity, sound, and energy efficiency.

[Hitachi Instruction Manual: Setup, Operation, and Features](#)

Comprehensive instruction manual for Hitachi televisions, covering setup, safety, operation, features like Ultra HD, HDR, Dolby Vision, and troubleshooting. Learn how to get the best from your Hitachi TV.

[Hitachi 65QLEDSM20 Ultra HD Android TV User Manual](#)

Hitachi 65QLEDSM20 User Manual: A comprehensive guide to setting up, operating, and troubleshooting your 65-inch Ultra HD Android TV. Learn about smart features, settings, and more.