Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Duracell DURDMLIONPB1

Duracell Rechargeable Powerbank 3350 mAh User Manual

Model: DURDMLIONPB1 | Brand: Duracell

Introduction

The Duracell Powerbank is engineered to provide a dependable power source for your USB-powered devices, ensuring you stay connected on the go. Featuring fast charge technology and a high capacity, this portable charger extends the battery life of your smartphone or other compatible devices without interruption. It incorporates 10 essential safety features for secure and worry-free operation.

Key Features:

- **3350 mAh Capacity:** Provides up to one extra charge for most smartphones.
- **Dual Charge Technology:** Allows simultaneous charging of the power bank and a connected USB device.
- **10 Safety Features:** Includes protection against over-charge, over-discharge, over-heating, short circuit, over-voltage, and more.
- **Compact and Portable:** Designed for easy transport and TSA carry-on compliance.





Image: The Duracell Rechargeable Powerbank 3350 mAh, highlighting its compact design and 3350 mAh capacity, capable of providing up to 1.8X extra charges.



Image: A visual representation of the 10 safety features integrated into the Duracell Powerbank, including protection against short circuit, over-voltage, fire resistance, dual safety circuits, under-temperature operation, output overload, over and under voltage at input, cable loop protection, over-temperature protection, and over-charge/discharge.

Setup

Your Duracell Powerbank comes pre-charged and ready to use. Before first use, it is recommended to fully charge the power bank to ensure optimal performance.

Package Contents:

- 1 x Duracell 3350 mAh Powerbank
- 1 x Micro USB Charging Cable

Identifying Components:

- **Micro USB Input Port:** Used to recharge the power bank.

- **USB Output Port:** Used to charge your devices.
- **LED Indicator Lights:** Display the power bank's charge level.
- **Power Button:** Activates charging and checks battery status.



Image: A detailed close-up of the Duracell Powerbank, highlighting the power button, LED indicator lights, and the top section where the USB output and Micro USB input ports are located.

Operating Instructions

Charging Your Device:

1. Connect one end of your device's charging cable (or the included micro USB cable if compatible) to the USB output port on the Duracell Powerbank.
2. Connect the other end of the cable to your device.
3. Press the power button on the power bank to initiate charging. The LED indicator lights will illuminate to show the remaining charge.
4. Once your device is fully charged, disconnect it from the power bank.





Image: A person holding the Duracell Powerbank connected via a cable to a smartphone, demonstrating the device charging process.



Image: The Duracell Powerbank connected to a smartphone, with text indicating an output charging speed of 1.2 Amps, ensuring efficient power delivery.

Recharging the Powerbank:

1. Connect the included micro USB cable to the micro USB input port on the power bank.
2. Connect the other end of the micro USB cable to a USB wall adapter (not included) or a computer's USB port.
3. The LED indicator lights will flash to indicate charging progress. All four lights will be solid when the power bank is fully charged.

Checking Battery Status:

Briefly press the power button. The LED indicator lights will illuminate to show the current charge level:

- 4 LEDs: 75-100% charged
- 3 LEDs: 50-75% charged
- 2 LEDs: 25-50% charged

- 1 LED: 0-25% charged (recharge soon)

Maintenance

Proper care and maintenance will extend the life of your Duracell Powerbank.

Cleaning:

- Wipe the exterior of the power bank with a soft, dry cloth.
- Do not use harsh chemicals, cleaning solvents, or strong detergents.

Storage:

- Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures.
- For long-term storage, it is recommended to charge the power bank to approximately 50% every 3-6 months to maintain battery health.

Battery Care:

- Avoid completely discharging the power bank regularly, as this can reduce battery lifespan.
- Do not expose the power bank to water or excessive moisture.
- Do not disassemble, short circuit, or expose to fire or high temperature.

Troubleshooting

If you encounter issues with your Duracell Powerbank, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
Power bank not charging device.	Ensure the power bank has sufficient charge (check LED indicators). Press the power button to activate charging. Verify the charging cable is securely connected to both the power bank and your device. Try a different charging cable or device to rule out cable/device issues.
Power bank not recharging.	Ensure the micro USB cable is securely connected to the power bank's input port and the power source. Try a different USB wall adapter or computer USB port. Verify the charging cable is not damaged.
LED indicators not lighting up.	Press the power button firmly. The power bank might be completely discharged; try recharging it for a few minutes.

If problems persist, please contact Duracell customer support or visit their official website for further assistance.

Specifications

Feature	Detail
Model Number	DURDMLIONPB1

Feature	Detail
Battery Capacity	3350 mAh
Voltage	5 Volts
Connector Type	USB (Output), Micro USB (Input)
Product Dimensions	7.76 x 4.12 x 1.1 inches
Item Weight	0.01 ounces
Batteries Required	1 Lithium Ion battery (included)
Manufacturer	Duracell Distributing, Inc
First Available Date	June 18, 2019

Warranty and Support

For detailed warranty information, product registration, and customer support, please visit the official Duracell website. Keep your proof of purchase for any warranty claims.

You can find more information and support at theDuracell Store on Amazon.

© 2024 Duracell. All rights reserved. Duracell is a registered trademark.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07RQ9SXVX

More documents and user manuals: **https://manuals.plus/**