Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Duracell DURDMLIONPB3

Duracell Rechargeable Powerbank 10050 mAh User Manual

Model: DURDMLIONPB3

Introduction

The Duracell Rechargeable Powerbank 10050 mAh is designed to provide a reliable and portable power source for your USB-powered devices. With its high capacity and fast charge technology, it helps extend the battery life of smartphones, tablets, and other compatible devices, ensuring uninterrupted use. This power bank incorporates 10 essential safety features for secure and worry-free operation.





Image: Front packaging of the Duracell Powerbank, highlighting its 10050 mAh capacity, up to 2X faster charging, and up to 5.5X extra charges for smartphones. It also indicates that it's pre-charged, ready to use, and has 2 USB outputs.

Safety Information

Your Duracell Powerbank is equipped with multiple safety features to ensure safe operation. Please read and understand the following precautions before use:

- Do not disassemble, short circuit, or expose to fire or high temperature.
- Properly connect to specified devices.
- Recycle battery according to local, state and national regulations.





Image: A visual representation of the 10 safety features integrated into the Duracell Powerbank. These include protection against short circuit (input, output), over voltage at output port, flame retardant case, dual safety circuits, under temperature operation, output over load, over and under voltage at the input, cable loop protection, over temperature protection, and over charge/discharge at cell level.

10 Integrated Safety Features:

1. **Short circuit protection:** For input and output.
2. **Over voltage protection:** At the output port.
3. **Flame retardant case:** Enhances physical safety.
4. **Dual safety circuits:** Provides redundant protection.

5. **Under temperature operation protection:** Ensures safe operation in cold conditions.
6. **Output over load protection:** Prevents damage from excessive current draw.
7. **Over and under voltage protection:** At the input.
8. **Cable loop protection:** Safeguards against cable-related issues.
9. **Over temperature protection:** Prevents overheating.
10. **Over charge/discharge protection:** At the cell level, prolonging battery life.

Package Contents

Upon opening the package, please verify that all items are present and in good condition:

- 1 x Duracell Lithium Ion Powerbank (10050 mAh)
- 1 x Micro USB Charging Cable

Setup

Charging the Powerbank

Before initial use, it is recommended to fully charge your Duracell Powerbank. The power bank comes pre-charged, but a full charge ensures optimal performance.

1. Connect the supplied Micro USB charging cable to the Micro USB input port on the power bank.
2. Connect the other end of the Micro USB cable to a USB wall adapter (not included) or a computer's USB port.
3. The LED indicators on the power bank will illuminate to show the charging status. When all LEDs are solid, the power bank is fully charged.

Checking Battery Level

Press the power button on the power bank to check the current battery level. The LED indicators will light up to show the remaining charge:

- 4 LEDs: 75-100% charge
- 3 LEDs: 50-75% charge
- 2 LEDs: 25-50% charge
- 1 LED: 0-25% charge (recharge soon)

Operating Instructions

Charging Your Devices

The Duracell Powerbank features dual USB outputs, allowing you to charge up to two devices simultaneously. It also supports dual charge technology, meaning you can charge the power bank itself while it charges your devices.



Image: A person holding the Duracell Powerbank in one hand and a smartphone in the other, with a charging cable connecting the two, demonstrating the power bank in use.

1. Connect your device's USB charging cable (e.g., USB-A to Lightning, USB-A to USB-C, or USB-A to Micro USB) to one of the USB output ports on the power bank.
2. Connect the other end of the cable to your smartphone, tablet, or other compatible USB-powered device.
3. The power bank will automatically begin charging your device. If it does not, press the power button on the power bank to initiate charging.
4. The LED indicators will show the power bank's remaining charge during the charging process.
5. Disconnect your device once it is fully charged or when you no longer need to charge it.

The 10050 mAh capacity can deliver up to three extra charges for a typical smartphone (e.g., iPhone 8), though results may vary by device and usage conditions.

Maintenance

- Keep the power bank away from extreme temperatures, direct sunlight, and humid environments.
- Do not expose the power bank to water or other liquids.
- Clean the power bank with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Store the power bank in a cool, dry place when not in use for extended periods.
- For optimal battery health, fully charge and discharge the power bank at least once every three months if not used regularly.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Power bank not charging	Loose cable connection, faulty cable, low power source, power bank fully charged.	Ensure Micro USB cable is securely connected. Try a different Micro USB cable. Use a different USB wall adapter or computer USB port. Check LED indicators; if all are solid, it's fully charged.
Device not charging from power bank	Power bank is depleted, faulty device cable, device not compatible, power bank in standby.	Recharge the power bank. Try a different charging cable for your device. Ensure your device is USB-powered. Press the power button on the power bank to activate charging.
Slow charging	Using a low-power USB port, cable resistance, device drawing high current.	Use a higher amperage USB wall adapter (e.g., 2A or higher) to charge the power bank. Ensure your device's charging cable is of good quality.
LED indicators not working	Power bank is completely discharged or damaged.	Try charging the power bank for an extended period. If still unresponsive, the unit may be faulty.

SPECIFICATIONS

Model Number	DURDMLIONPB3
Battery Capacity	10050 mAh (36.5 Wh)
Product Dimensions	1.1 x 4.12 x 7.6 inches
Item Weight	0.019 ounces
Input Connector	Micro USB
Output Connectors	2 x USB-A
Color	Black
Special Features	Fast Charging, Portable Charger, 10 Safety Features, Dual Charge Technology
TSA Compliant	Yes (Carry-On Compliant)



Image: The back of the Duracell Powerbank packaging, illustrating the capacities of different models (3,350 mAh, 6,700 mAh, 10,050 mAh) and their respective charging capabilities. It confirms the 10,050 mAh model offers up to 3X extra charges and 2 USB ports, along with being up to 2X faster charging vs. the wall.

Warranty and Support

For detailed warranty information, product support, and additional user instructions, please visit the official Duracell website. You can often find FAQs and contact information for customer service there.

Visit Duracell Powerbanks Support Page

© 2023 Duracell. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07RTN91VY

More documents and user manuals: **https://manuals.plus/**