Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Skullcandy S2JPW-M101

Skullcandy Jib+ Wireless Earbuds User Manual

Model: S2JPW-M101

1. Introduction

The Skullcandy Jib+ Wireless Earbuds offer a comfortable and lightweight audio experience with wireless freedom. Designed for everyday use, these earbuds feature Bluetooth 5.0 connectivity, a built-in microphone for calls, and a splash-resistant design, making them suitable for various activities. This manual provides detailed instructions on setting up, operating, and maintaining your Jib+ Wireless Earbuds to ensure optimal performance.



Figure 1: Skullcandy Jib+ Wireless Earbuds (Blue)

2. What's in the Box

Your Skullcandy Jib+ Wireless Earbuds package includes the following items:

- Jib Wireless Earbuds
- Micro USB to USB Charging Cable
- 2 Pair Silicone Ear Gels (small, medium)



Figure 2: Included components (Red colorway shown for illustration)

3. Setup

3.1. Charging Your Earbuds

Before first use, fully charge your Jib+ Wireless Earbuds. Connect the included Micro USB cable to the charging port on the earbuds and the other end to a USB power source. A full charge provides up to 6 hours of continuous playback. The charging time is approximately 6 hours for a full charge.

3.2. Bluetooth Pairing

1. Ensure your earbuds are powered off.

2. Press and hold the power button until the LED indicator flashes blue and red, indicating pairing mode.
3. On your device (iPhone, Android, laptop, etc.), enable Bluetooth and search for available devices.
4. Select "Jib+ Wireless" from the list of devices.
5. Once connected, the LED indicator will turn solid blue.

The earbuds utilize Bluetooth 5.0 for stable and efficient wireless connectivity.

3.3. Achieving a Comfortable Fit

The Jib+ Wireless Earbuds come with two pairs of silicone ear gels (small and medium) to ensure a secure and comfortable fit. Experiment with both sizes to find the one that provides the best seal for optimal sound isolation and comfort. The noise-isolating in-ear design helps block out external distractions.



Figure 3: Close-up view of the earbuds, showing the in-ear design.



Figure 4: Proper placement of the earbuds for a comfortable and secure fit.

4. Operating Instructions

4.1. Controls Overview

The Jib+ Wireless Earbuds feature an inline remote with buttons for easy control of your audio and calls. The control unit includes a microphone for hands-free communication.



Figure 5: Inline control unit with volume and multi-function buttons.

4.2. Music and Call Control

Function	Action
Power On/Off	Press and hold the multi-function button.
Play/Pause Music	Press the multi-function button once.
Next Track	Press the multi-function button twice.
Previous Track	Press the multi-function button three times.
Volume Up	Press the '+' button.
Volume Down	Press the '-' button.
Answer/End Call	Press the multi-function button once.
Reject Call	Press and hold the multi-function button.
Activate Voice Assistant	Press the multi-function button twice (when not on a call).

4.3. Product Overview Video

▶ **Watch video online**
Skullcandy Jib+ In-Ear Wireless Earbuds

Video 1: An overview of the Skullcandy Jib+ In-Ear Wireless Earbuds, highlighting key features and design elements.

5. Maintenance

Proper maintenance ensures the longevity and performance of your earbuds.

- **Cleaning:** Regularly wipe the earbuds and ear gels with a soft, dry cloth. For the ear gels, you can remove them and gently wash with mild soap and water, ensuring they are completely dry before reattaching.
- **Sweat Resistance:** The earbuds are splash-resistant, meaning they can withstand light sweat and splashes. However, they are not waterproof and should not be submerged in water. After intense workouts, wipe them dry.
- **Storage:** When not in use, store your earbuds in a clean, dry place away from extreme temperatures and direct sunlight. Avoid tangling the cables.

6. Troubleshooting

If you encounter issues with your Skullcandy Jib+ Wireless Earbuds, try the following troubleshooting steps:

Problem	Solution
Earbuds not turning on/charging	Ensure the charging cable is securely connected to both the earbuds and a working USB power source. Check if the charging light illuminates. Try a different USB port or charger.
Cannot pair with device	Make sure the earbuds are in pairing mode (flashing blue/red). Turn off and on your device's Bluetooth. Forget the device from your Bluetooth settings and try pairing again. Ensure earbuds are within Bluetooth range (approx. 30 feet).
No sound or low volume	Check the volume levels on both the earbuds and your connected device. Ensure the earbuds are properly seated in your ears and try different ear gel sizes. Re-pair the earbuds with your device.
Poor call quality (microphone issues)	Ensure the microphone is not obstructed. Try moving closer to your device. Disconnect and reconnect the Bluetooth connection. Some user reviews indicate potential issues with microphone sensitivity depending on cable position.
Earbuds frequently disconnect	Ensure no obstacles are between the earbuds and your device. Move closer to your device. Reduce interference from other wireless devices.

7. Specifications

Feature	Detail
Model Name	BT_JIB_PLUS
Model Number	S2JPW-M101
Connectivity Technology	Bluetooth 5.0

Feature	Detail
Ear Placement	In Ear
Noise Control	Sound Isolation
Battery Life	Up to 6 Hours
Charging Time	6 Hours (approx.)
Item Weight	0.6 ounces (17 Grams)
Product Dimensions	7.28 x 3.19 x 1.04 inches
Water Resistance Level	Water Resistant (Splash-resistant)
Included Components	Jib Wireless Earbuds, Micro USB to USB Charging Cable, 2 Pair Silicone Ear Gels (small, med)
UPC	878615098541

8. Warranty and Support

Your Skullcandy Jib+ Wireless Earbuds come with a 1-year US warranty, ensuring peace of mind regarding manufacturing defects and performance issues.
For further assistance, detailed user guides, and warranty information, please refer to the official resources:

- **User Guide (PDF):** Download User Guide
- **Official Brand Store:** Visit Skullcandy Store on Amazon

For direct support, please contact Skullcandy customer service through their official website or the contact information provided in the product packaging.

© 2024 Skullcandy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07RW8NXF8

More documents and user manuals: **https://manuals.plus/**