**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**FreedConn T-MAX**

# FreedConn T-MAX Motorcycle Intercom Mounting Bracket Instruction Manual

## 1. Introduction

This document provides comprehensive instructions for the proper installation, use, and maintenance of the FreedConn T-MAX Motorcycle Intercom Mounting Bracket. This bracket is designed specifically to securely attach your FreedConn T-MAX series motorcycle Bluetooth intercom unit to your helmet. It serves as a reliable holder, ensuring your intercom remains stable during rides.

## 2. Package Contents

Please verify that all components are present in your package before proceeding with installation.

- 1 x FreedConn T-MAX Intercom Mounting Bracket (Clip)

*Note: The FreedConn T-MAX intercom unit itself is not included with this mounting bracket.*

## 3. Setup and Installation

Follow these steps to correctly install the mounting bracket on your motorcycle helmet.

1. **Prepare the Helmet Surface:** Choose a flat, clean area on the side of your helmet where you intend to mount the intercom. Ensure the surface is free from dirt, dust, grease, or moisture. Clean the area thoroughly with an alcohol wipe and allow it to dry completely.
2. **Position the Bracket:** Carefully position the mounting bracket on the chosen area of the helmet. Ensure it is oriented correctly for easy access to the intercom unit and does not obstruct helmet functionality or vision.
3. **Remove Adhesive Backing:** Peel off the protective film from the adhesive backing on the rear of the mounting bracket.
4. **Attach the Bracket:** Press the bracket firmly onto the prepared helmet surface. Apply consistent pressure for at least 30 seconds to ensure a strong bond. For optimal adhesion, allow the adhesive to cure for at least 24 hours before attaching the intercom unit or riding.
5. **Verify Security:** After the curing period, gently test the bracket's adhesion to ensure it is securely attached to the helmet.



Figure 3.1: Rear view of the mounting bracket, illustrating the adhesive backing for secure attachment to the helmet.



Figure 3.2: Front view of the mounting bracket, showing the design for holding the intercom unit.




Figure 3.3: The mounting bracket displayed next to a FreedConn T-MAX intercom unit, demonstrating compatibility and intended use.

## 4. Operating the Mounting Bracket

Once the mounting bracket is securely installed on your helmet, you can attach your FreedConn T-MAX intercom unit.

1. **Attach Intercom Unit:** Align your FreedConn T-MAX intercom unit with the slots or clips on the mounting bracket. Gently slide or snap the intercom unit into place until it is firmly seated.
2. **Ensure Secure Fit:** Verify that the intercom unit is securely attached to the bracket and does not wobble or feel loose. A secure fit is crucial for safe operation during your ride.
3. **Remove Intercom Unit (Optional):** To remove the intercom unit, carefully disengage it from the bracket by sliding or unclipping it, following the specific instructions for your T-MAX intercom model.

## 5. Maintenance

Proper maintenance ensures the longevity and reliability of your mounting bracket.

- **Cleaning:** Clean the bracket periodically with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the plastic material or weaken the adhesive bond.
- **Inspection:** Regularly inspect the bracket for any signs of wear, cracks, or damage. Check the adhesive bond to ensure it remains strong. If the bracket shows significant wear or damage, replace it to prevent potential loss of your intercom unit.
- **Storage:** If removing the bracket from the helmet, store it in a clean, dry place away from direct sunlight and extreme temperatures.

## 6. Troubleshooting

Refer to this section for solutions to common issues.

- **Bracket Not Sticking Securely:**
  - Ensure the helmet surface was thoroughly cleaned and dry before application.
  - Apply firm, consistent pressure during installation.
  - Allow the adhesive to cure for the recommended 24 hours without attaching the intercom unit.
  - If the issue persists, the adhesive may be compromised. Consider replacing the bracket.
- **Intercom Unit Feels Loose on Bracket:**
  - Ensure the intercom unit is correctly aligned and fully seated into the bracket's locking mechanism.
  - Inspect the bracket for any deformities or damage that might prevent a snug fit.
  - Verify that you are using the correct mounting bracket for your specific FreedConn T-MAX intercom model.

## 7. Specifications

| Feature | Detail |
|---|---|
| Brand | FreedConn |
| Model Number | T-MAX |
| Item Weight | 0.3 Kilograms (approx. 10.5 ounces) |
| Package Dimensions | 5.94 x 4.29 x 0.47 inches |
| Color | Black |
| Material | Plastic (as observed) |
| Compatibility | FreedConn T-MAX series motorcycle Bluetooth intercoms |

## 8. Warranty and Support

For warranty information or technical support regarding your FreedConn T-MAX Motorcycle Intercom Mounting Bracket, please refer to the official FreedConn website or contact their customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

**Open the live page**

**https://manuals.plus/asin/B07S7QV1S1**

More documents and user manuals: **https://manuals.plus/**