Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TRESKO GTSARL30

TRESKO Automatic Hose Reel User Manual

Model: GTSARL30

1. Introduction

Thank you for choosing the TRESKO Automatic Hose Reel. This product is designed to provide a convenient and efficient solution for your garden watering needs. Featuring an automatic retraction system and a 180-degree swivel function, it ensures hassle-free operation and neat storage. Please read this manual carefully before installation and use to ensure proper function and safety.



Figure 1: TRESKO Automatic Hose Reel

2. Safety Instructions

Always observe the following safety precautions to prevent injury or damage:

- Do not allow children to operate the hose reel unsupervised. The retraction mechanism is powerful.
- Ensure the wall mounting is secure and can support the weight of the hose reel, especially when filled with water.
- Do not attempt to disassemble or repair the unit yourself. Contact qualified personnel for service.
- Release water pressure from the hose before disconnecting it from the tap or storing the unit.
- Protect the unit from frost during winter months by removing it and storing it indoors.
- Do not use the hose reel with hot water or corrosive liquids.

3. Package Contents

Please check that all items are present in the package:

- Automatic Hose Reel Unit
- 30m Garden Hose (integrated)

- 2m Connection Hose
- Hose Connector
- Spray Nozzle with Quick Connector
- Wall Mount Bracket
- Mounting Hardware (4 screws and dowels)
- User Manual



Figure 2: Product Components Overview



Figure 3: Included Mounting Hardware and Manual

4. Setup and Installation

4.1 Wall Mounting

1. Choose a suitable location on a sturdy wall, ensuring it can support the weight of the unit and allow for the 180-degree swivel.
2. Use the wall mount bracket as a template to mark the drilling points.
3. Drill four holes at the marked positions. Insert the provided dowels into the holes.
4. Secure the wall mount bracket to the wall using the provided screws. Ensure it is firmly attached.
5. Slide the hose reel unit onto the wall mount bracket until it clicks securely into place.

4.2 Connecting to Water Supply

1. Connect the 2m connection hose to the water inlet on the side of the hose reel unit.

2. Attach the other end of the connection hose to your garden tap using the appropriate hose connector (compatible with 1/2" and standard systems).
3. Ensure all connections are tight to prevent leaks.



Figure 4: Universal Connection and Tap Connection

5. Operating Instructions

5.1 Unwinding the Hose

To unwind the hose, simply pull it out to the desired length. The hose will automatically lock into place at intervals. You will hear a clicking sound as it locks. To unlock and pull further, give a slight tug.

5.2 Automatic Retraction

To retract the hose, give it a short, sharp tug. The locking mechanism will release, and the hose will automatically rewind into the casing. Guide the hose as it retracts to prevent kinks or tangles.



Figure 5: Hose Locking Mechanism and 180-Degree Pivot

5.3 180-Degree Swivel Function

The hose reel can pivot up to 180 degrees on its wall mount. This allows you to easily direct the hose in various directions without kinking, providing flexibility for watering different areas of your garden. After use, you can swivel the unit flat against the wall for space-saving storage.



Figure 6: 180-Degree Swivel and Integrated Handle

6. Maintenance

- **Cleaning:** Clean the exterior of the hose reel with a damp cloth. Do not use abrasive cleaners or solvents.
- **Frost Protection:** For frost-free storage, the hose reel can be easily removed from its wall mount. Disconnect the water supply, drain any remaining water from the hose, and store the unit indoors in a dry, frost-free environment during winter.
- **UV Protection:** The casing is designed to protect the hose from UV exposure, extending its lifespan.
- **Hose Inspection:** Periodically inspect the hose for any signs of wear, cracks, or damage. Replace if necessary.

7. Troubleshooting

- **Hose not retracting:** Ensure the hose is not kinked or tangled. Give a firm, short tug to release the locking mechanism. If the issue persists, check for any obstructions in the retraction path.
- **Water leaks:** Check all connections (tap, connection hose, spray nozzle) for tightness. Ensure rubber seals are properly seated and not damaged.
- **Low water pressure:** Verify that your water tap is fully open and there are no kinks in the supply hose or the integrated hose.

8. Specifications

Brand	TRESKO
Model Number	GTSARL30
Dimensions	50cm x 27cm x 42cm (Unit)

Weight	Approx. 12.94 kg
Material	Polypropylene (PP) and Polyvinyl Chloride (PVC)
Hose Length	30m (main hose) + 2m (connection hose)
Hose Diameter	16mm
Connection	1/2" (compatible with 3/4" and 1" taps)
Max. Pressure	Up to 10 bar
Swivel Angle	180 degrees

9. Warranty and Support

This TRESKO product comes with a manufacturer's warranty. Please refer to the warranty information provided at the time of purchase or contact your retailer for details regarding warranty terms and conditions.
For technical support, spare parts, or any questions not covered in this manual, please contact the seller or the manufacturer directly. Keep your purchase receipt as proof of purchase.

© 2024 TRESKO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07SSCH4YR

More documents and user manuals: **https://manuals.plus/**