**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**PKPOWER AC DC Adapter**

# PK Power AC DC Adapter for Venturer SBT1739BWSE Soundbar

USER MANUAL

## Introduction

Thank you for choosing the PK Power AC DC Adapter. This adapter is designed as a replacement power supply for Venturer SBT1739BWSE, SBT1739-SW, and SBT1739-SWE soundbar home theater systems. This manual provides essential information for the safe and effective use of your new power adapter. Please read it thoroughly before use and retain it for future reference.

## Safety Information

To ensure safe operation and prevent damage, please observe the following safety precautions:

- **Input Voltage:** This adapter is designed for an input voltage range of 100-240V AC, 50-60Hz. Ensure your power outlet matches these specifications.
- **Protection Features:** The adapter incorporates Over Voltage Protection (OVP), Over Current Protection (OCP), and Short Circuit Protection (SCP) to safeguard your devices.
- **Certification:** PK Power products are CE, FCC, and RoHS certified, indicating compliance with relevant safety and environmental standards.
- **Proper Use:** Do not expose the adapter to water, moisture, or extreme temperatures. Avoid dropping or subjecting it to severe impacts.
- **Ventilation:** Ensure adequate ventilation around the adapter during use to prevent overheating. Do not cover it with cloths or place it in enclosed spaces.
- **Disconnection:** Always disconnect the adapter from the power outlet before cleaning or if it will be unused for an extended period.
- **Proposition 65 Warning:** This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

## Setup

Follow these steps to set up your PK Power AC DC Adapter:

1. **Unpack:** Carefully remove the AC DC adapter from its packaging.
2. **Inspect:** Check the adapter and cables for any visible damage. Do not use if damaged.

3. **Connect to Device:** Plug the output connector of the AC DC adapter into the power input port of your Venturer SBT1739BWSE, SBT1739-SW, or SBT1739-SWE soundbar. Ensure a secure connection.
4. **Connect to Power Outlet:** Insert the AC input plug of the adapter into a standard wall power outlet (100-240V AC).
5. **Power On:** Once connected, your soundbar should receive power. Refer to your soundbar's manual for specific power-on instructions.



Figure 1: Top view of the PK Power AC DC Adapter, showing the main unit and connected cables.



Figure 2: Angled view of the PK Power AC DC Adapter, highlighting the compact design and cable connections.

## Operating Instructions

The PK Power AC DC Adapter functions as a direct power supply for your compatible Venturer soundbar. Once properly connected as described in the Setup section, the adapter continuously supplies power to the device. There are no user-adjustable settings or operational controls on the adapter itself.

- Ensure the adapter is securely plugged into both the wall outlet and your soundbar.
- The soundbar will draw power as needed. Refer to your soundbar's user manual for its specific power-on and operation procedures.
- If the soundbar does not power on, verify all connections and check the power outlet.

## Maintenance

Proper maintenance ensures the longevity and reliable performance of your AC DC adapter:

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and moisture. Avoid tightly coiling the cables to prevent damage.
- **Cable Care:** Do not bend, twist, or pull the cables excessively. Avoid placing heavy objects on the cables.
- **Inspection:** Periodically inspect the adapter and cables for any signs of wear, cuts, or damage. If damage is found, discontinue use and replace the adapter.

## Troubleshooting

If you encounter issues with your PK Power AC DC Adapter, refer to the following troubleshooting steps:

| Problem | Possible Cause | Solution |
|---|---|---|
| No power to soundbar | Adapter not plugged in securely.<br>Power outlet is not active.<br>Faulty adapter or cable. | Ensure both ends of the adapter are firmly connected.<br>Test the power outlet with another device.<br>Inspect adapter and cables for damage. If damaged, replace the adapter. |
| Intermittent power | Loose connection.<br>Damaged cable. | Check all connections for tightness.<br>Inspect cables for fraying or cuts. Replace if damaged. |
| Adapter feels hot | Normal operation (slight warmth).<br>Poor ventilation.<br>Overload or internal fault. | A slight warmth is normal. Ensure adapter is in a well-ventilated area.<br>Disconnect immediately if excessively hot or emitting smoke/smell. Contact support. |

If the problem persists after following these steps, please contact PK Power customer support.

## Specifications

- **Brand:** PKPOWER
- **Model:** AC DC Adapter (Replacement for Venturer SBT1739BWSE, SBT1739-SW, SBT1739-SWE)
- **Input:** 100-240V AC, 50-60Hz
- **Output:** Designed to match the original power requirements of Venturer SBT1739BWSE series soundbars.
- **Connector Type:** Auxiliary
- **Main Power Connector Type:** 2 Pin
- **Color:** Black
- **Certifications:** CE, FCC, RoHS

## Warranty and Support

PK Power stands behind the quality of its products. For any inquiries or support needs, please contact our customer service team.

- **Customer Service:** Our friendly and reliable customer service team is available to assist you and will respond within 24 hours.
- **Manufacturer:** PKPOWER

Please visit the PKPOWER Store on Amazon for more information or to contact support.

© 2023 PKPOWER. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B07TT5F3QM**

More documents and user manuals: **https://manuals.plus/**