Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

FITHOOD CS-NP45FU

FITHOOD Replacement Battery CS-NP45FU User Manual

Model: CS-NP45FU | Brand: FITHOOD

Introduction

This manual provides essential instructions for the safe and effective use of your FITHOOD CS-NP45FU replacement battery. This high-quality Lithium-Ion battery is designed to be compatible with various FUJIFILM FinePix camera models and the Share SP2, serving as a direct replacement for NP-45A, NP-45B, NP-45S, and NP-45 battery part numbers. Please read this manual thoroughly before use.

Safety Information

To ensure safe operation and prolong the life of your battery, observe the following precautions:

- **DO NOT OPEN OR CRUSH** the battery.
- **DO NOT PUNCTURE** the battery.
- **DO NOT SHORT EXTERNAL CONTACTS.**
- **DO NOT DISPOSE OF IN FIRE OR WATER.**
- Replace only with the battery pack designated for your product.
- **DO NOT STORE ABOVE 60°C (140°F).**
- **DO NOT DISASSEMBLE** the battery.
- Keep the battery away from children.
- If the battery shows signs of damage, swelling, or leakage, discontinue use immediately.



This image displays the FITHOOD replacement battery, highlighting its label. The label includes important safety warnings such as 'DO NOT OPEN OR CRUSH, PUNCTURE THE BATTERY,' 'DO NOT SHORT EXTERNAL CONTACTS,' and 'DO NOT DISPOSE OF IN FIRE OR WATER.' It also specifies the battery's rating: 3.7V, 2.5Wh, 660mAh, Model No.: CS-NP45FU, and Part No.: NP-45A.

Compatible Devices

This FITHOOD replacement battery is compatible with the following FUJIFILM camera models and devices:

- FUJIFILM FinePix L30
- FUJIFILM FinePix L50
- FUJIFILM FinePix L55
- FUJIFILM FinePix T200
- FUJIFILM FinePix T300
- FUJIFILM FinePix T305
- FUJIFILM FinePix T310
- FUJIFILM FinePix T350
- FUJIFILM FinePix T360
- FUJIFILM FinePix T400
- FUJIFILM Share SP2

It is designed to replace original batteries with part numbers: NP-45A, NP-45B, NP-45S, NP-45.


Setup

Package Contents

Your package should contain one (1) FITHOOD CS-NP45FU replacement Lithium-Ion battery.

Battery Installation

1. Ensure your camera or device is powered off before attempting to install or remove the battery.
2. Locate the battery compartment on your camera or device. Refer to your device's original manual if unsure.
3. Open the battery compartment cover.
4. Align the FITHOOD battery with the compartment, paying attention to the 'Insert this direction' indicator and the electrical contacts.
5. Gently slide the battery into the compartment until it clicks into place or is fully seated.
6. Close the battery compartment cover securely.



This image presents the FITHOOD replacement battery from a different angle, emphasizing the 'Insert this direction' indicator printed on the side. This marking guides users on the correct orientation for battery insertion into compatible devices.



This image shows a side view of the FITHOOD replacement battery, clearly displaying the gold-colored electrical contact points. These contacts are essential for connecting the battery to the camera or charger.

Initial Charging

For optimal performance, it is recommended to fully charge the battery before its first use. Use a compatible charger designed for NP-45 series batteries. The battery features a fully decoded chip, ensuring it functions like an original battery with your device's charging system.

Operating Instructions

Once the battery is correctly installed and charged, your camera or device should power on normally. The battery's decoded chip allows for accurate power level display on your device's screen, just like an original battery.

- Turn on your camera or device as per its manufacturer's instructions.
- Monitor the battery level indicator on your device.
- When the battery level is low, remove the battery and recharge it using a compatible charger.

Maintenance

Charging

- Always use a charger compatible with NP-45 series Lithium-Ion batteries.
- Avoid overcharging the battery by removing it from the charger once fully charged.
- Charge the battery in a well-ventilated area, away from flammable materials.

Storage

- Store the battery in a cool, dry place, away from direct sunlight and extreme temperatures.
- For long-term storage, it is recommended to store the battery with approximately 50% charge.
- Do not store the battery above 60°C (140°F).

Cleaning

If the battery contacts become dirty, gently wipe them with a clean, dry cloth. Do not use liquids or abrasive cleaners.

Troubleshooting

- **Battery not powering on device:**
  Ensure the battery is fully charged and correctly inserted into the compartment. Check if the battery contacts on both the battery and the device are clean.
- **Battery not charging:**
  Verify that the charger is functioning correctly and is compatible with NP-45 series batteries. Ensure the battery is properly seated in the charger. If the issue persists, try a different compatible charger.
- **Short battery life:**
  Battery life can be affected by usage patterns, device settings, and environmental conditions. Ensure the battery has been fully charged. If the battery's performance significantly degrades over time, it may be reaching the end of its lifespan.
- **Battery swelling or damage:**
  Immediately discontinue use and safely dispose of the battery according to local regulations. Do not attempt to charge or use a damaged battery.

If you encounter issues not covered here or require further assistance, please refer to the 'Warranty and Support' section.

Specifications

Feature	Specification
Model Number	CS-NP45FU
Battery Type	Lithium Ion
Voltage	3.7V
Capacity	660mAh
Watt-Hours (Wh)	2.44Wh
Dimensions (L x W x H)	40.00 x 31.10 x 5.90mm (1.57 x 1.22 x 0.23 inches)
Weight	60g / 2.12oz
Certifications	ISO9001, RoHS, CE

Feature	Specification
Recommended Use	Camera

Warranty and Support

All FITHOOD batteries are certified with ISO9001, RoHS, and CE standards, ensuring quality and safety.

It is crucial to ensure both the model and battery part number are matched with your device before purchase and use. If you are uncertain about compatibility or have any questions regarding your battery, please contact the seller with your battery details or pictures for professional suggestions and support.

© 2023 FITHOOD. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07TXTG4YK

More documents and user manuals: **https://manuals.plus/**