**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Epesl EL22GWSLUS-ML

# Epesl 25m/82ft 220 LED Multi Color String Lights Instruction Manual

Model: EL22GWSLUS-ML

## 1. Introduction

Thank you for choosing Epesl 25m/82ft 220 LED Multi Color String Lights. This manual provides essential information for the safe and efficient use of your new string lights. Please read it thoroughly before installation and operation, and retain it for future reference.




Image 1.1: Epesl 220 LED Multi Color String Lights in packaging.

## 2. Safety Information

- **Power Source:** Ensure the power source voltage matches the product's requirements (29 Volts).
- **Water Resistance:** The string lights are IP44 waterproof, suitable for indoor and outdoor use. However, the power plug should be protected from direct water exposure.
- **Installation:** Do not install the lights in a way that could damage the wiring or bulbs. Avoid sharp objects or abrasive surfaces.
- **Overloading:** Do not connect more than 6 sets of these string lights end-to-end to prevent electrical overload. The maximum extendable length is 492ft.
- **Maintenance:** Disconnect from power before any maintenance or cleaning.
- **Children and Pets:** Keep the lights and power adapter out of reach of children and pets.

## 3. Package Contents

Upon opening the package, verify that all components are present:

- 1 x Epesl 25m/82ft 220 LED Multi Color String Lights
- 1 x Power Adapter with Controller

## 4. Features

- **LED Count:** 220 individual LED bulbs.
- **Length:** 25 meters (82 feet) of illuminated length.
- **Color:** Multi-color (Colorful) LEDs.
- **Lighting Modes:** 8 distinct lighting modes with memory function.
- **Expandability:** End-to-end connectable design, allowing up to 6 sets to be linked for a maximum total length of 492 feet.
- **Waterproof Rating:** IP44 for both indoor and outdoor applications.
- **Power:** Electric powered, low voltage (29V) for safety.
- **Material:** Durable copper wiring.

## 5. Setup Instructions

### 5.1 Unpacking

1. Carefully remove the string lights and power adapter from the packaging.
2. Gently uncoil the string lights, ensuring not to tangle or damage the wires.

### 5.2 Connecting Multiple Sets (Optional)

If you wish to extend the length, up to 6 sets of these lights can be connected end-to-end:

1. Locate the connection plug at the end of the first string and the input connector on the next string.
2. Align the connectors and firmly push them together.
3. Twist the waterproof cap to secure the connection.
4. Repeat for additional sets, ensuring the total connected length does not exceed 492 feet.




Image 5.1: Diagram illustrating end-to-end connection for multiple light sets.

### 5.3 Power Connection

1. Connect the power adapter to the main string light.
2. Plug the power adapter into a standard electrical outlet.

### 5.4 Placement

These lights are versatile for various decorative purposes:

- **Indoor Use:** Ideal for decorating Christmas trees, mantels, windows, or creating ambient lighting.
- **Outdoor Use:** Suitable for wrapping around trees, bushes, railings, or outlining patios and gardens. Ensure the power plug is protected from rain or moisture.



Image 5.2: String lights installed on an outdoor staircase.



Image 5.3: String lights used for indoor Christmas decoration.

## 6. Operating Instructions

### 6.1 Changing Lighting Modes

The string lights feature 8 different lighting modes. To cycle through the modes, press the button on the power adapter/controller. The lights have a memory function, meaning they will resume the last selected mode when turned on again.




Image 6.1: Power adapter with mode selection button.

## 6.2 Available Modes:

1. Combination
2. In Waves
3. Sequential
4. Slogs (Slow Glow)
5. Chasing/Flash
6. Slow Fade
7. Twinkle/Flash
8. Steady On

▶ **Watch video online**
Christmas String Lights

Video 6.1: Demonstration of the 8 lighting modes for Epesl string lights.

## 7. Maintenance

### 7.1 Cleaning

To clean the string lights, ensure they are unplugged from the power source. Use a soft, dry cloth to gently wipe away dust or dirt. Do not use harsh chemicals or abrasive cleaners.

### 7.2 Storage

When not in use, carefully coil the string lights and store them in their original packaging or a suitable container in a cool, dry place, away from direct sunlight and extreme temperatures. This helps prevent tangling and extends the product's lifespan.

## 8. Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Lights do not turn on. | No power supply. | Ensure the power adapter is securely plugged into a working outlet. Check if the outlet has power. |
| Lights are dim or flickering. | Loose connection or power issue. | Check all connections, especially if multiple sets are linked. Ensure the power adapter is functioning correctly. |
| Mode button is unresponsive. | Controller malfunction. | Unplug the lights for a few minutes, then plug them back in to reset the controller. If the issue persists, contact customer support. |
| Some bulbs are not lit. | Individual LED failure. | LED bulbs are typically non-replaceable. The string is designed so that the failure of one LED does not affect others. If many bulbs are out, contact customer support. |

## 9. Specifications

| Feature | Detail |
|---|---|
| Model Number | EL22GWSLUS-ML |
| Brand | Epesl |
| Light Source | LED |
| Number of LEDs | 220 |
| Total Length | 25m (82ft) |

| Feature | Detail |
|---|---|
| Light Color | Multi-color (Colorful) |
| Power Source | Electric |
| Voltage | 29 Volts |
| Wattage | 8.80 Watts |
| Waterproof Rating | IP44 |
| Indoor/Outdoor Use | Yes |
| Expandability | Up to 6 sets (max 492ft) |
| Control Method | Touch button on adapter |
| Material | Copper |
| Item Weight | 1.1 pounds |
| UPC | 778601187641 |

## 10. Warranty and Support

Epesl string lights undergo quality checks and testing before shipment. We provide a**6-month replacement guarantee** from the date of purchase. If you encounter any issues or have questions regarding your product, please contact Epesl customer support. We aim to respond and assist within 24 hours.
For support, please visit the official Epesl store or contact us through the platform where you purchased the product.

Epesl Store: https://www.amazon.com/stores/EPESL/page/49C1802A-98B5-415F-89D0-EA9E88C6264E

© 2025 Epesl. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B07V38DVJ1**

More documents and user manuals: **https://manuals.plus/**