Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SIMPLI-MAGIC 79207

SIMPLI-MAGIC 13-Gallon Stainless Steel Automatic Touchless Sensor Trash Can Instruction Manual

Model: 79207

1. Product Overview

The SIMPLI-MAGIC 13-Gallon Automatic Touchless Sensor Trash Can is designed for convenient and hygienic waste disposal in various environments such as homes, kitchens, bedrooms, offices, and commercial areas. Constructed from durable stainless steel, it features a modern design and advanced sensor technology for touch-free operation.





Figure 1: SIMPLI-MAGIC 13-Gallon Stainless Steel Automatic Touchless Sensor Trash Can

Key Features:

- **Stainless Steel Construction:** Durable and modern design suitable for various settings.
- **Fingerprint-Proof Surface:** Easy to clean and maintain a pristine appearance.
- **Motion Sensor Technology:** Automatic lid opening for touchless operation.
- **Space-Saving Design:** Efficiently fits in tight spaces and corners.
- **User-Friendly Experience:** Designed for ease of use and convenience.
- **13-Gallon Capacity:** Accommodates common trash bag sizes.



Figure 2: Visual representation of key product features

2. Setup

2.1 Unboxing and Initial Inspection

Carefully remove all components from the packaging. Inspect the trash can for any signs of damage. Ensure all parts are present before proceeding with setup.

2.2 Battery Installation

The sensor lid requires 4 AA batteries (not included) for operation. Locate the battery compartment on the underside of the lid. Open the compartment, insert the batteries according to the polarity indicators, and securely close the cover.

2.3 Power On

After installing the batteries, locate the power switch on the back of the lid. Flip the switch to the 'ON' position. The sensor will activate, and the trash can is ready for use.

2.4 Placement

Place the trash can in your desired location. Its space-saving design allows it to fit efficiently in tight spaces and corners. Ensure the sensor area is clear of obstructions for optimal performance.

3. Operation

3.1 Automatic Sensor Operation

To open the lid automatically, pass your hand or debris within approximately ten inches from the sensor located

on the front of the lid. The lid will open smoothly. It will remain open as long as your hand or debris is within the sensor's range. After a few seconds of no activity, the lid will automatically close.



Figure 3: Automatic lid opening via motion sensor



Figure 4: Automatic lid closing

3.2 Manual Operation

In case of low batteries or if you prefer manual control, the lid can be lifted manually. Simply lift the lid by hand to open it and push it down to close. This function is available even if the sensor is not active.

3.3 Trash Bag Installation and Replacement

To install or replace a trash bag:

1. Remove the sensor lid from the trash can body.
2. Place a standard 13-gallon trash bag into the can, ensuring the top edge of the bag is folded over the rim of the can.
3. Carefully place the sensor lid back onto the trash can body, ensuring it is securely seated.



Figure 5: Proper trash bag installation

4. Maintenance

4.1 Cleaning

The stainless steel body features a fingerprint-proof surface, making it easy to clean. Use a soft, damp cloth to wipe down the exterior. For stubborn marks, a mild stainless steel cleaner can be used. Avoid abrasive cleaners or scouring pads that may scratch the surface.



Figure 6: Fingerprint-proof surface for easy cleaning

For the sensor lid, wipe with a dry or slightly damp cloth. Do not submerge the lid in water or allow excessive moisture to enter the battery compartment or sensor area, as this can damage the electronic components.

5. Troubleshooting

- **Lid does not open automatically:**
  - Check if the power switch on the back of the lid is in the 'ON' position.
  - Ensure batteries are correctly installed and not depleted. Replace batteries if necessary.
  - Verify there are no obstructions blocking the sensor.
- **Lid does not close automatically:**
  - Ensure no objects are within the sensor's range, preventing it from detecting a clear path to close.
  - Check for any physical obstructions preventing the lid from fully closing.
- **Trash bag tears during removal:**
  - Ensure the trash bag is not overfilled.
  - Use high-quality, durable trash bags designed for 13-gallon cans.
  - When removing, gently lift the bag to avoid snagging on the rim.

6. Specifications

Feature	Detail
Brand	SIMPLI-MAGIC
Model Number	79207
Capacity	13 Gallons

Color	Stainless Steel
Opening Mechanism	Motion-Sensor
Material	Stainless Steel
Product Dimensions	15.5"L x 12.2"W x 26.3"H
Item Weight	9.48 Pounds
Batteries Required	4 AA Batteries (Not Included)
Assembly Required	Yes (Minor, for lid placement)



Figure 7: Product dimensions

7. Official Product Video

▶ **Watch video online**
Sensor Trash Can (13 Gallon Capacity)

Video 1: Overview of the SIMPLI-MAGIC Sensor Trash Can (13 Gallon Capacity) by International Textile & Apparel, Inc.

8. Warranty and Support

8.1 Warranty Information

This SIMPLI-MAGIC product comes with a**1-year warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. Please retain your proof of purchase for warranty claims.

8.2 Customer Support

For any questions, parts, or support inquiries, please contact SIMPLI-MAGIC customer service. Refer to the product packaging or official website for the most current contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07V4NJQ1B

More documents and user manuals: **https://manuals.plus/**