Manuals+
Q & A | Deep Search | Upload

Tihebeyan AKB73655806

Tihebeyan AKB73655806 Universal Remote Control User Manual

Model: AKB73655806 | Brand: Tihebeyan

Introduction

This manual provides instructions for the Tihebeyan AKB73655806 Universal Remote Control, designed as a replacement for LG Smart LED LCD TVs. This remote offers a compact design and dedicated navigation keys for ease of use. It requires no programming or complex setup, functioning directly upon battery installation.

Setup

The Tihebeyan AKB73655806 remote control is designed for immediate use without requiring any programming. Follow these steps to prepare your remote for operation:

1. **Open the Battery Compartment:** Locate the battery compartment cover on the back of the remote control. Slide or lift the cover to open it.
2. **Insert Batteries:** Insert two (2) AA batteries (not included) into the compartment. Ensure the positive (+) and negative (-) terminals of the batteries align correctly with the markings inside the compartment.
3. **Close the Battery Compartment:** Replace the battery compartment cover, ensuring it clicks securely into place.
4. **Ready for Use:** The remote control is now ready to operate your compatible LG TV. No further setup or pairing is required.

Image: The remote control with its battery cover removed, illustrating the correct orientation for inserting two AA batteries.

Operating Instructions

This universal remote control is compatible with various LG Smart LED LCD TV models. Its intuitive layout allows for straightforward operation.

- **Power On/Off:** Press the **POWER** button to turn your LG TV on or off.
- **Channel Selection:** Use the number pad (0-9) for direct channel access. Use the **CH +/-** buttons to navigate through channels sequentially.
- **Volume Control:** Adjust the volume using the **VOL +/-** buttons. Press the **MUTE** button to silence the TV audio.
- **Navigation:** Use the directional arrow buttons (Up, Down, Left, Right) and the **OK** button for menu navigation and selection.
- **Menu Access:** Press the **Q.MENU** or **SETTINGS** button to access your TV's quick menu or full settings.
- **Input Selection:** Use the **INPUT** button to cycle through available input sources (HDMI, AV, etc.).
- **Remote Control Distance:** The remote operates effectively at a distance of more than 10 meters (approximately 32.81 feet), though actual range may vary depending on environmental factors and TV model.

Image: The remote control being held, demonstrating its ergonomic design and ease of use in a typical home environment.

Maintenance

To ensure the longevity and optimal performance of your Tihebeyan AKB73655806 remote control, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the remote control regularly with a soft, dry cloth to remove dust and fingerprints. For stubborn dirt, lightly dampen the cloth with water; avoid using harsh chemicals or abrasive cleaners.
- **Battery Replacement:** Replace batteries when the remote's responsiveness decreases or it stops functioning. Always replace both AA batteries at the same time with new ones. Do not mix old and new batteries, or different types of batteries.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage, which can damage the device. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops and Impacts:** Protect the remote from physical damage by avoiding drops and impacts.

Troubleshooting

If you encounter issues with your Tihebeyan AKB73655806 remote control, refer to the following common problems and solutions:

- **Remote Not Responding:**
  - Check the batteries. Ensure they are inserted correctly with the correct polarity (+/-).
  - Replace the batteries with fresh AA batteries. Weak or depleted batteries are a common cause of unresponsiveness.
  - Ensure there are no obstructions between the remote control and the TV's infrared receiver.
  - Confirm the remote is pointed directly at the TV.
- **Buttons Not Working Consistently:**
  - This can sometimes indicate low battery power. Try replacing the batteries.
  - Ensure the buttons are not stuck or obstructed by debris. Gently clean around the buttons if necessary.
- **Limited Remote Control Range:**
  - Ensure there are no strong light sources (like direct sunlight or bright fluorescent lights) interfering with the IR signal.
  - Replace the batteries, as low battery power can reduce the effective range.
- **Remote Does Not Control TV:**
  - Verify that your TV is an LG Smart LED LCD TV, as this remote is specifically designed for LG models.
  - Ensure the TV itself is powered on and functioning correctly.

Specifications

Feature	Description
Model	AKB73655806
Compatibility	LG Smart LED LCD TVs
Battery Model	2 x AA Batteries (not included)
Remote Control Distance	More than 10 Meters (32.81 FT)
Power Type	DC 3V
Case Material	ABS
Color	Black
Product Size (L x W x H)	18.7 x 5.1 x 2 CM (7.36 x 2.01 x 0.79 Inch)
Weight	66 Grams (2.29 Ounces)
Max Number of Supported Devices	1

Image: The remote control displaying its physical dimensions for reference.

Image: A visual comparison between the 'New Type' and 'Old Type' models of the AKB73655806 remote control, indicating that variations may be shipped.

Warranty Information

Specific warranty details for the Tihebeyan AKB73655806 Universal Remote Control are typically provided with the product packaging or by the retailer at the time of purchase. Please refer to the documentation included with your remote control for comprehensive warranty terms and conditions. For any warranty-related inquiries, it is recommended to contact the seller or manufacturer directly.

Customer Support

For further assistance, technical support, or inquiries regarding your Tihebeyan AKB73655806 Universal Remote Control, please contact the retailer from whom you purchased the product. You may also visit the official Tihebeyan brand store on Amazon for additional product information or to contact their customer service if available.

Tihebeyan Store Link: Visit the Tihebeyan Store on Amazon