Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Joyroom JR-H16

Joyroom Wireless Headset with Microphone (JR-H16) User Manual

Model: JR-H16

Introduction

This manual provides detailed instructions for the proper use and maintenance of your Joyroom Wireless Headset with Microphone, model JR-H16. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.



Image 1: Joyroom JR-H16 Wireless Headset. This image displays the black over-ear headphones with subtle blue LED accents on the earcups, showcasing their sleek design.

Product Overview

The Joyroom JR-H16 is a versatile wireless headset designed for audio playback and communication. It features multiple connectivity options and a comfortable design.

Key Features:

- Bluetooth 5.0 for stable wireless connection.
- Integrated microphone for calls.
- Support for TF card playback.
- 3.5mm audio cable input for wired use.
- Long battery life with 1000 mAh capacity.



Image 2: Multi-mode Switching. This graphic illustrates the three primary connectivity options: TF card slot, 3.5mm audio cable input, and Bluetooth 5.0 wireless connection.

Setup

1. Charging the Headset

Before first use, fully charge the headset. Connect the charging cable (not specified if included, assume standard USB) to the charging port on the headset and a compatible USB power source. The indicator light will typically show red during charging and turn off or blue when fully charged.

- Battery Capacity: 1000 mAh
- Working Time: Approximately 8.5 hours
- Play Time: Approximately 38.5 hours

- Standby Time: Approximately 300 hours

2. Bluetooth Pairing

1. Ensure the headset is powered off.
2. Press and hold the Power button until the indicator light flashes blue and red alternately, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "JR-H16" from the list of found devices.
5. Once paired, the indicator light will typically flash blue slowly or turn solid blue.
6. Effective Bluetooth distance is approximately 10 meters.

3. Wired Connection (3.5mm Audio Cable)

To use the headset in wired mode, connect one end of a 3.5mm audio cable (not specified if included) to the headset's audio jack and the other end to your audio source's 3.5mm output. The headset can be used passively in wired mode without power.

4. TF Card Playback

Insert a TF (MicroSD) card with audio files into the designated TF card slot on the headset. The headset will automatically switch to TF card playback mode or can be switched manually using the mode button (if available).

Operating Instructions

Power On/Off:

- **Power On:** Press and hold the Power button for approximately 3 seconds.
- **Power Off:** Press and hold the Power button for approximately 3-5 seconds.

Music Playback:

- **Play/Pause:** Press the Multi-function button (often the Power button or a dedicated play/pause button) once.
- **Volume Up:** Press the Volume Up (+) button.
- **Volume Down:** Press the Volume Down (-) button.
- **Next Track:** Press and hold the Volume Up (+) button (or a dedicated button).
- **Previous Track:** Press and hold the Volume Down (-) button (or a dedicated button).

Call Management:

- **Answer Call:** Press the Multi-function button once when an incoming call rings.
- **End Call:** Press the Multi-function button once during a call.
- **Reject Call:** Press and hold the Multi-function button for approximately 2 seconds when an incoming call rings.

Mode Switching:

If your headset supports multiple modes (Bluetooth, TF Card, Wired), there may be a dedicated 'M' (Mode) button. Press this button to cycle through the available modes.

Maintenance

Cleaning:

- Wipe the headset with a soft, dry cloth.

- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Keep the charging port and audio jack free of dust and debris.

Storage:

- Store the headset in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid placing heavy objects on the headset.
- If storing for an extended period, charge the battery to about 50% every few months to preserve battery health.

Battery Care:

- Avoid fully discharging the battery frequently.
- Do not expose the battery to high temperatures.



Image 3: Headband and Earcup Details. This image provides a close-up view of the headset's features, including the skin-friendly headband material, the 'CD texture' on the earcups, and the laser-engraved Joyroom logo.

Troubleshooting

If you encounter issues with your Joyroom JR-H16 headset, refer to the following common solutions:

- **Headset does not power on:**
  Ensure the headset is fully charged. Connect it to a power source and try again after a few minutes.
- **Cannot pair with device:**
  Make sure the headset is in pairing mode (indicator flashing blue and red). Ensure Bluetooth is enabled on your device and it is within the 10-meter effective range. Try restarting both the headset and your device.
- **No sound or poor sound quality:**
  Check the volume levels on both the headset and your connected device. If using Bluetooth, ensure the connection is stable and there are no obstructions. If using a wired connection, ensure the 3.5mm cable is fully inserted and not damaged. For TF card playback, ensure the audio files are in a compatible format and the card is inserted correctly.
- **Microphone not working:**
  Ensure the headset is properly connected and selected as the input device on your computer or smartphone. Check for any mute functions on the headset or device.

- **Short battery life:**
  Ensure the headset is fully charged before use. Battery performance can degrade over time with extensive use. Avoid extreme temperatures during charging and operation.

Specifications

Brand	Joyroom
Model Number	JR-H16
Bluetooth Version	5.0
Battery Capacity	1000 mAh
Working Time	8.5 hours
Play Time	38.5 hours
Standby Time	300 hours
Effective Distance	10 meters
Product Dimensions	8 x 5 x 15 cm
Product Weight	90 g
Headphone Jack	3.5 mm Jack
Connectivity Technology	Wired, Wireless (Bluetooth)
Included Components	Ear Cushions, Headband

Warranty and Support

Warranty information for the Joyroom JR-H16 headset is not explicitly provided in the product details. Please refer to your purchase documentation or contact the retailer/manufacturer directly for warranty terms and support inquiries.

© 2023 Joyroom. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07VF6QCJC

More documents and user manuals: **https://manuals.plus/**