Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

iHome iBTW281V2BC

iHome iBTW281v2 Wireless Charging Alarm Clock

Instruction Manual

Introduction

Thank you for purchasing the iHome iBTW281v2 Wireless Charging Alarm Clock with Bluetooth Speaker and Color Changing Lights. This device combines multiple functionalities to enhance your daily routine, offering wireless charging, high-quality audio streaming, and customizable lighting. Please read this manual thoroughly to understand the features and ensure proper operation.



Front view of the iHome iBTW281v2 Wireless Charging Alarm Clock, displaying the digital time and date, with a vibrant color-changing light effect.

Safety Information

- Do not expose the unit to rain or moisture.
- Do not place objects filled with liquids, such as vases, on the unit.
- Ensure proper ventilation; do not block any ventilation openings.
- Use only attachments/accessories specified by the manufacturer.
- Unplug the unit during lightning storms or when unused for long periods.

- Refer all servicing to qualified service personnel.

Package Contents

- iHome iBTW281v2 Wireless Charging Alarm Clock
- AC Power Adapter

Product Overview

Familiarize yourself with the various buttons and ports on your iBTW281v2 unit.



Diagram illustrating the various components and controls of the iHome iBTW281v2, including the wireless charging pad, speakerphone button, snooze/dimmer button, light mode button, USB charging port, dual alarms, and Bluetooth speaker.

- **Wireless Charging Pad:** Located on top for Qi-compatible devices.
- **Speakerphone Button:** For answering/ending calls.
- **Snooze/Dimmer Button:** Activates snooze for alarms and adjusts display brightness.
- **Light Mode Button:** Cycles through various color-changing light modes.
- **USB Charging Port:** Located on the back for wired charging of devices.
- **Dual Alarms:** Two independent alarms with separate settings.
- **Bluetooth Speaker:** Integrated speaker for audio playback.

Setup

Power Connection

Connect the included AC power adapter to the DC jack on the back of the unit and plug the other end into a working wall outlet. The unit is powered by corded electric.

Battery Backup

The unit requires 1 Lithium Ion battery (not included) for backup power to maintain time and alarm settings during a power outage. Install the battery in the compartment on the bottom of the unit.

Setting the Time

1. Press and hold the **Time Set** button (usually located on the back or top) until the time display flashes.
2. Use the **+/-** buttons to adjust the hour. Press **Time Set** again to confirm.
3. Use the **+/-** buttons to adjust the minute. Press **Time Set** again to confirm.
4. The time is now set.

Operating Instructions

Wireless Charging

Place your Qi-compatible smartphone on the wireless charging pad located on the top of the unit. The unit supports up to 10W wireless charging. Ensure the device is centered on the pad for optimal charging. The charging pad is case-friendly (up to 2mm thick), features foreign object detection, a non-slip surface, and overheat protection.



The iHome iBTW281v2 with a smartphone placed on its top for Qi wireless charging, highlighting its case-friendly design, foreign object detection, non-slip surface, and overheat protection.

USB Charging

A 5W USB charging port is located on the back of the unit. Use this port to charge devices that do not support wireless charging, such as tablets, smartwatches, or phones with metal cases.



Rear view of the iHome iBTW281v2 showing a smartphone connected to the 5W USB charging port, demonstrating its capability to charge non-wireless devices.

Bluetooth Speaker

The iBTW281v2 features a built-in Bluetooth speaker with Reson8 speaker technology for clear, rich sound. To pair your device:

1. Press the **Bluetooth Pairing** button on the unit. The Bluetooth indicator will flash.
2. Enable Bluetooth on your smartphone or audio device and select "iHome iBTW281v2" from the list of available devices.
3. Once paired, the Bluetooth indicator will glow solid, and you can stream audio wirelessly.

The unit also supports hands-free conversations via its speakerphone with echo noise cancellation.



The iHome iBTW281v2 with a smartphone wirelessly connected via Bluetooth, emphasizing its audio streaming capabilities and speakerphone function with echo noise cancellation.

Digital Alarm Clock

The iBTW281v2 features dual alarms that can be set and used independently. You can wake to light, Bluetooth audio, or preset tones. There are 3 adjustable alarm schedules: weekdays only, weekends only, or 7 days a week. The SureAlarm feature ensures alarm settings are maintained during power failures.



An image highlighting the alarm features of the iHome iBTW281v2, including Scheduled Dimmer, Dual Alarms (wake to light and Bluetooth or tone), and SureAlarm for power failure backup.

Color Changing Lights

Set the lighting to match your mood with 7 distinct glow modes. Press the**Light Mode** button to cycle through the options:

- Slow Fade
- Fast Change
- Favorite Color
- Twinkle
- Pulse To Music
- Sky Gradient
- Nightlight



Multiple iHome iBTW281v2 units in various color-changing light modes, illustrating the 7 available glow modes: Slow Fade, Fast Change, Favorite Color, Twinkle, Pulse To Music, Sky Gradient, and Nightlight.

Maintenance

To keep your iBTW281v2 in optimal condition:

- Clean the unit with a soft, dry cloth. Do not use liquid cleaners or abrasive sprays.
- Keep the unit away from direct sunlight, heat sources, and excessive dust.
- Do not attempt to disassemble or modify the unit. This will void the warranty.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Unit does not power on.	Power adapter not connected or outlet is faulty.	Ensure the AC adapter is securely plugged into the unit and a working wall outlet.
Wireless charging is not working.	Device not Qi-compatible, not aligned, or foreign object detected.	Ensure your device supports Qi wireless charging. Re-position the device on the pad. Remove any foreign objects between the device and the pad.
Bluetooth device cannot pair.	Unit is not in pairing mode or device is too far.	Press the Bluetooth pairing button on the unit. Move your Bluetooth device closer to the unit.
Alarm does not sound.	Alarm is not set or volume is too low.	Verify alarm settings and ensure alarm volume is audible. Check battery backup if power was interrupted.

Specifications

Brand: iHome

Model: iBTW281V2BC

Color: Blue

Display Type: Digital

Power Source: Corded Electric

Product Dimensions: 8.9"W x 3.07"H

Item Weight: 2.51 Pounds

Battery Requirement: 1 Lithium Ion battery (for backup, not included)

Wireless Charging Output: Up to 10W

USB Charging Output: 5W

Special Features: Alarm, Auto Dimmable, Snooze, Bluetooth Speaker, Color Changing Lights, Wireless Charging, USB Charging

Material: Acrylonitrile Butadiene Styrene

Warranty and Support

iHome products are designed to provide reliable performance. For warranty information or technical support, please refer to the warranty card included with your product or visit the official iHome website. Keep your purchase receipt as proof of purchase for warranty claims.
For further assistance, you may visit the iHome Store on Amazon: iHome Amazon Store

© 2024 iHome. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07VKBPWRD

More documents and user manuals: **https://manuals.plus/**