Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GUESS W1280L2

GUESS W1280L2 Analog Watch User Manual

Model: W1280L2

1. Introduction

Thank you for choosing the GUESS W1280L2 Analog Watch. This manual provides essential information for the proper setup, operation, and maintenance of your timepiece. Please read it carefully to ensure optimal performance and longevity of your watch.

2. Product Overview

The GUESS W1280L2 is an elegant analog watch featuring a gold PVD-coated steel case and bracelet. It is designed for daily wear with a focus on style and reliable timekeeping.




Figure 2.1: Front view of the GUESS W1280L2 watch. This image displays the watch's main face, highlighting its gold-tone finish, the decorative crystals around the bezel, and the GUESS branding on the dial.

Key Components:

- **Case:** Round, 38mm diameter, made of steel with gold PVD coating.
- **Dial:** Gold-tone with hour markers and hands.
- **Crown:** Located on the right side of the case, used for setting the time.
- **Bracelet:** Gold PVD-coated steel bracelet with a deployment clasp.
- **Bezel:** Adorned with crystals.

3. Setup and Initial Use

3.1 Unpacking

- Carefully remove the watch from its packaging.
- Remove any protective films from the crystal, case back, and bracelet.

3.2 Setting the Time



Figure 3.1: Side view of the GUESS W1280L2 watch, illustrating the position of the crown for time adjustment.

1. Gently pull the crown (the small knob on the side of the watch) outwards to the first position.
2. Rotate the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time.
3. Once the time is set, push the crown back in firmly against the watch case to engage the movement and ensure water resistance.

4. Operating Your Watch

The GUESS W1280L2 is an analog watch designed for accurate time display. Once the time is set as described in Section 3.2, the watch will continuously display the current time. There are no additional operational functions beyond timekeeping.

5. Maintenance

5.1 Cleaning

- Wipe the watch case and bracelet regularly with a soft, dry cloth to remove dust and fingerprints.
- For more thorough cleaning, a slightly damp cloth can be used, followed immediately by a dry cloth. Avoid using harsh chemicals or abrasive materials.

5.2 Water Resistance

Your GUESS W1280L2 watch has a water resistance rating of 30 ATM (30 meters / 100 feet). This means it is suitable for everyday use and can withstand splashes, rain, and brief immersion in water. However, it is **not** suitable for swimming, showering, or diving. Always ensure the crown is fully pushed in to maintain water resistance.

5.3 Battery Replacement

The watch is powered by a lithium metal battery. When the watch stops running, it indicates the battery needs replacement. Battery replacement should be performed by a qualified watch technician to avoid damaging the watch and to ensure proper resealing for water resistance.



Figure 5.1: Back view of the GUESS W1280L2 watch, showing the case back and the deployment clasp on the bracelet.

6. Troubleshooting

- **Watch not running:** Check if the crown is fully pushed in. If it is, the battery may need replacement.
- **Time is inaccurate:** Reset the time as per Section 3.2. If the issue persists, the watch may require professional

inspection.

7. Specifications

Feature	Detail
Model Number	W1280L2
Brand	GUESS
Case Diameter	38mm
Case Material	Steel, Gold PVD
Bracelet Material	Steel, Gold PVD
Water Resistance	30 ATM (30 meters / 100 feet)
Movement Type	Analog (Quartz)
Battery Type	1 Lithium metal
Approximate Weight	101.5 grams

8. Warranty and Support

8.1 Warranty Information

Your GUESS W1280L2 watch comes with a 2-year manufacturer's warranty from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage resulting from improper handling, accidents, unauthorized repairs, or normal wear and tear.

8.2 Customer Support

For warranty claims, service, or technical assistance, please contact your authorized GUESS retailer or visit the official GUESS website for customer service contact information in your region. Please have your proof of purchase and watch model number (W1280L2) available when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07VQ1LTRN

More documents and user manuals: **https://manuals.plus/**