Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER AC DC Adapter

PKPOWER AC DC Adapter User Manual

For Plextalk PTR2 and Compatible Devices

1. Introduction

This manual provides instructions for the safe and effective use of your PKPOWER AC DC Adapter. Please read this manual thoroughly before use and retain it for future reference. This adapter is designed to provide power to compatible electronic devices, including the Plextalk PTR2 Digital Daisy Audio Book Player and similar portable recorders.

2. Important Safety Information

To ensure safe operation and prevent damage, please observe the following safety precautions:

- Read all instructions carefully before using the adapter.
- Do not expose the adapter to liquids, rain, or moisture.
- Do not disassemble, modify, or attempt to repair the adapter. Refer all servicing to qualified personnel.
- Ensure the input voltage of the adapter (100-240V AC) matches the wall outlet's voltage.
- Disconnect the adapter from the power outlet when not in use or during electrical storms.
- This product is designed for indoor use only.
- Keep the adapter out of reach of children.
- Do not use the adapter if the cables or housing are damaged.

3. Product Overview

3.1 Components

The PKPOWER AC DC Adapter consists of the main adapter unit (power brick), a detachable AC input power cord, and an integrated DC output cable with a compatible connector.



Image: The PKPOWER AC DC Adapter showing the main power brick, the detachable AC input cable (left), and the integrated DC output cable (right).

3.2 Features

- **Input Voltage:** Universal 100-240V AC, 50-60Hz, suitable for worldwide use.
- **Safety Certifications:** CE, FCC, RoHS certified for quality and safety standards.
- **Protection Features:** Equipped with Over Voltage Protection (OVP), Over Current Protection (OCP), and Short Circuit Protection (SCP) to safeguard your devices.
- **Design:** Compact and portable, making it suitable for travel.

4. Setup

4.1 Connecting the Adapter

Follow these steps to properly connect your AC DC Adapter:

1. **Step 1:** Connect the detachable AC input power cord firmly into the AC input port on the adapter unit.
2. **Step 2:** Plug the AC input power cord into a standard wall outlet (100-240V AC).
3. **Step 3:** Connect the DC output plug from the adapter's integrated cable to the power input port of your compatible electronic device (e.g., Plextalk PTR2). Ensure the connection is secure.



Image: A close-up view of the PKPOWER AC DC Adapter block, showing the output cable connected and ready for use.

5. Operating

5.1 Powering Your Device

Once the adapter is properly connected to both the wall outlet and your device, it will begin supplying power. The adapter is designed to provide stable and regulated power within its specified voltage and current limits. Always ensure that your device's power requirements (voltage and current) match the adapter's output specifications to prevent damage.

6. Maintenance

6.1 Care and Cleaning

- Keep the adapter clean and dry.
- Wipe the surface of the adapter with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or aerosols.

- Avoid exposing the adapter to extreme temperatures, direct sunlight, or high humidity.
- Ensure that any ventilation openings on the adapter (if present) are not blocked during operation.
- Regularly inspect the AC input cord and DC output cable for any signs of fraying, cuts, or other damage. If damage is found, discontinue use immediately and replace the adapter.

7. Troubleshooting

7.1 Common Issues

- **No Power to Device:**
  - *Check 1:* Ensure the AC input cord is securely plugged into both the adapter unit and a functional wall outlet.
  - *Check 2:* Verify the wall outlet is supplying power by testing it with another known working device.
  - *Check 3:* Confirm the DC output plug is firmly connected to your device's power input port.
  - *Check 4:* Ensure your device is compatible with this adapter's output specifications.
- **Adapter Overheating:**
  - *Action:* Disconnect the adapter from the power source and your device immediately. Ensure the adapter is used in a well-ventilated area and not covered by cloths or other materials. If overheating persists after allowing it to cool, discontinue use and contact customer support.
- **Device Not Charging/Functioning Properly:**
  - *Check:* Double-check that the adapter's output voltage and current specifications precisely match your device's power requirements. Refer to your device's instruction manual for its specific power input needs.

8. Specifications

8.1 Technical Data

Feature	Specification
Input Voltage	100-240V AC, 50-60Hz
Protection Features	OVP (Over Voltage Protection), OCP (Over Current Protection), SCP (Short Circuit Protection)
Certifications	CE, FCC, RoHS
Color	Black
Weight	Approximately 4 ounces (113 grams)
Special Feature	Travel-friendly design



Image: A close-up view of the AC input plug of the adapter, showing printed specifications including input voltage range and certifications.

9. Warranty and Support

9.1 Customer Service

PKPOWER products are manufactured with a commitment to quality and reliability. For any questions, concerns, or support needs regarding your AC DC Adapter, please contact our customer service team.

- Our friendly and reliable customer service team aims to respond to inquiries within 24 hours.
- Please refer to your purchase documentation or the seller's information for specific warranty terms and contact details.

Note: *This adapter is compatible with Plextalk PTR2, Plextor Plex Talk Digital Daisy Audio Book Player, Walkman CD Player, Portable Recorder, and other devices requiring similar power specifications. Always verify compatibility with your specific device before use.*

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07XB5ZGDM

More documents and user manuals: **https://manuals.plus/**