Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER AC DC Adapter (for Hannspree HANNSpad series)

PK Power AC DC Adapter User Manual

Model: AC DC Adapter (for Hannspree HANNSpad series)
Brand: PKPOWER

Introduction

This manual provides essential information for the safe and effective use of your PK Power AC DC Adapter. Please read this manual thoroughly before using the product and retain it for future reference.
This adapter is designed to provide reliable power to compatible Hannspree HANNSpad tablets, including models SN14TP1B2A, SN14TP1B, SN14TP1, HSG1351, and 133 Titan2.

Product Overview



Image 1: The PK Power AC DC Adapter, showing the main power brick, the detachable input power cord (for wall outlet connection), and the integrated output cable with the connector for the tablet.



Image 2: A side view of the adapter's main unit, highlighting its compact design and the attached output cable that connects to the tablet.



Image 3: A close-up of the wall plug portion of the adapter, showing the input specifications (100-240VAC, 50/60Hz) and safety certifications (FCC, CE).

Safety Precautions

- Ensure the adapter's input voltage (100-240V) matches your local power supply.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not disassemble or attempt to repair the adapter. Refer to qualified personnel for service.
- Keep out of reach of children.

- Unplug the adapter from the wall outlet when not in use for extended periods.
- This adapter is equipped with Over Voltage Protection (OVP), Over Current Protection (OCP), and Short Circuit Protection (SCP) for enhanced safety.

Setup

1. **Connect the Power Cord:** If your adapter has a detachable power cord, firmly insert the 2-pin connector of the power cord into the input port of the AC DC adapter brick.
2. **Plug into Wall Outlet:** Insert the wall plug end of the power cord into a standard electrical wall outlet (100-240V, 50/60Hz).
3. **Connect to Device:** Carefully insert the output connector of the adapter's integrated cable into the charging port of your compatible Hannspree HANNSpad tablet.
4. **Verify Connection:** Ensure all connections are secure. Your tablet should indicate that it is charging.

Operating Instructions

Once connected, the adapter will automatically begin supplying power to your tablet. It is designed for continuous use during charging or powering the device. The adapter's built-in safety features protect both the adapter and your device from electrical anomalies.

- Always use the adapter with compatible devices as specified.
- Avoid bending or crimping the cables excessively to prevent damage.
- Do not cover the adapter during operation to ensure proper ventilation.

Maintenance

- **Cleaning:** Disconnect the adapter from the power outlet and your device before cleaning. Use a soft, dry cloth to wipe the surface of the adapter. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly winding the cables.
- **Inspection:** Periodically inspect the adapter and cables for any signs of damage, such as frayed wires, cracks, or loose connections. If damage is found, discontinue use immediately.

Troubleshooting

Problem	Possible Cause	Solution
Tablet not charging.	Adapter not properly plugged into wall outlet. Output connector not fully inserted into tablet. Tablet charging port issue. Faulty adapter or cable.	Ensure adapter is securely plugged into a working wall outlet. Verify the output connector is fully seated in the tablet's charging port. Test with another compatible charger if available, or try charging another device with this adapter (if compatible). If issues persist, contact customer support.

Problem	Possible Cause	Solution
Adapter feels hot.	Normal operation (slight warmth is expected). Poor ventilation. Overload or internal fault.	Ensure the adapter is in a well-ventilated area and not covered. If it's excessively hot or emits smoke/smell, unplug immediately and discontinue use. Contact customer support.

Specifications

Feature	Detail
Input Voltage	100-240V AC, 50-60Hz
Compatible Devices	Hannspree HANNSpad SN14TP1B2A, SN14TP1B, SN14TP1, HSG1351, 133 Titan2 Tablets
Safety Features	OVP (Over Voltage Protection), OCP (Over Current Protection), SCP (Short Circuit Protection)
Certifications	CE, FCC, RoHS
Power Source	Corded Electric
Main Power Connector Type	2 Pin (for wall outlet connection)
Item Weight	Approximately 4 ounces

Warranty and Support

PK-Power products are manufactured to high standards and undergo rigorous testing. Our friendly and reliable customer service team is available to assist you with any questions or concerns.
For support, please contact our customer service. We aim to respond to all inquiries within 24 hours.
Please refer to your purchase documentation for specific warranty terms and conditions.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07XFCGHKZ

More documents and user manuals: **https://manuals.plus/**