Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Paladone PP5852PS

Paladone PlayStation Icons Light XL User Manual

Model: PP5852PS | Brand: Paladone

Introduction

This manual provides essential instructions for the safe and efficient operation of your Paladone PlayStation Icons Light XL. Please read this manual thoroughly before use and retain it for future reference.

What's in the Box

- Paladone PlayStation Icons Light XL Unit
- USB Power Cable
- Instruction Manual

Note: 3 x AAA batteries are required for battery operation and are not included.

Setup

1. **Unpacking:** Carefully remove the PlayStation Icons Light XL from its packaging.
2. **Power Options:** The light can be powered via USB or 3x AAA batteries (not included).
    - **USB Power:** Connect the provided USB cable to the micro USB port on the back of the light unit and plug the other end into a compatible USB power source (e.g., computer, USB wall adapter).
    - **Battery Power:** Locate the battery compartment on the underside of the unit. Unscrew the cover, insert 3x AAA batteries, ensuring correct polarity (+/-), then replace the cover and screw it securely.
3. **Placement:** Place the light on a stable, flat surface.



Image: The PlayStation Icons Light XL can be powered by either a micro USB cable or 3 AAA batteries, as shown with the USB port on the side and the battery compartment on the bottom.

Operating Instructions

The PlayStation Icons Light XL features multiple lighting modes, controlled by a single button located on the unit's base.

1. **Power On/Off:** Press the power button once to turn the light on. Press it repeatedly to cycle through the different modes. Press and hold the button to turn the light off.
2. **Lighting Modes:**
    - **Standard Mode:** All icons illuminate with a steady, soft glow.
    - **Color Phasing Mode:** The icons will cycle through various colors and patterns.
    - **Music Reactive Mode:** The lights will respond to sounds and music, creating a dynamic display.



Image: The light offers three distinct modes: Standard, Color Phasing, and Music Reactive.

▶ **Watch video online**
PlayStation Icons Light XL

Video: Official demonstration of the PlayStation Icons Light XL, showcasing its various lighting effects and features.

Maintenance

- **Cleaning:** Wipe the unit with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** If using batteries, replace all three AAA batteries simultaneously when the light dims or stops functioning.
- **Storage:** When not in use for extended periods, remove batteries and store the unit in a cool, dry place.

Troubleshooting

Problem	Solution
Light does not turn on.	Ensure USB cable is securely connected to both the unit and a power source. If using batteries, check that they are inserted correctly and are not depleted. Replace if necessary.
Lights are dim or flickering.	If using batteries, they may be low. Replace all three AAA batteries. Ensure the USB power source provides sufficient power (5V DC, 500mA).
Music Reactive mode is not responding.	Ensure there is sufficient ambient sound for the microphone to pick up. Adjust the volume of the audio source.

Specifications

Feature	Detail
Model Name	Playstation Icons Light XL
Model Number	PP5852PS
Brand	Paladone
Product Dimensions	2.36"D x 12.6"W x 13.78"H (approx. 30cm wide x 10cm tall)
Item Weight	14.1 Ounces
Material	Plastic
Power Source	USB (cable included) or 3x AAA Batteries (not included)
Light Source Type	LED
Special Features	3 Light Modes (Standard, Color Phasing, Music Reactive)
Indoor/Outdoor Usage	Indoor

Warranty and Support

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Paladone website.

Safety Information

- This product is for indoor use only.
- Do not expose to water or excessive moisture.
- Keep out of reach of small children.

- Do not attempt to disassemble or modify the unit.
- Dispose of batteries responsibly according to local regulations.

© 2023 Paladone. All rights reserved. PlayStation is a registered trademark of Sony Interactive Entertainment Inc.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07XRP3PCW

More documents and user manuals: **https://manuals.plus/**