Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Power Craze 798753221109

Power Craze High Speed Mini RC Car Instruction Manual

Model: 798753221109

Introduction

Thank you for purchasing the Power Craze High Speed Mini RC Car. This manual provides essential information for the safe operation, setup, and maintenance of your new remote control vehicle. Please read this manual thoroughly before use to ensure proper function and to maximize your enjoyment of the product.

Safety Information

Always observe the following safety precautions to prevent injury or damage to the product:

- This product is recommended for ages 22 months to 5 years. Adult supervision is highly recommended for younger users.
- Do not operate the RC car near people, pets, or obstacles.
- Keep fingers, hair, and loose clothing away from moving parts, especially the wheels.
- Do not operate in wet conditions or near water to prevent electrical damage.
- Use only the specified batteries (2 AA batteries for the controller) and ensure correct polarity.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries from the controller when not in use for extended periods.
- Do not attempt to modify or disassemble the RC car or controller. This may void the warranty and cause damage.
- Avoid severe crashes, as this can damage the vehicle's components, particularly the axles.

Package Contents

Verify that all items are present in the package:

- Power Craze High Speed Mini RC Car (Blue)
- Remote Controller



Image: The Power Craze High Speed Mini RC Car, blue in color, is shown alongside its black remote controller. The car features a robust frame and large wheels, while the controller has a pistol-grip design with an antenna.



Image: The retail packaging for the Power Craze High Speed Mini RC Car. The box highlights features such as 'Ages 8+', 'High-Speed Vehicle', and '28 KM/H Speeds Up To'. The car and controller are visible through the packaging.

Setup

Follow these steps to prepare your RC car for its first use:

1. Controller Battery Installation

1. Locate the battery compartment on the back of the remote controller.
2. Open the battery compartment cover.
3. Insert 2 AA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Close the battery compartment cover securely.



Image: A close-up view of the black Power Craze remote controller. It features a pistol-grip design with a steering wheel on the side and a trigger for acceleration/braking. The Power Craze logo is visible on the steering wheel.

2. RC Car Charging

The RC car has a built-in rechargeable battery. Refer to the specific charging instructions provided with your car's charging cable. Typically, a full charge is required before first use.

Operating Instructions

Once the batteries are installed and the car is charged, you are ready to operate your Power Craze RC Car:

1. Turn on the RC car using the power switch, usually located on the underside or side of the vehicle.
2. Turn on the remote controller. An indicator light on the controller should illuminate.
3. Pairing: The car and controller should automatically pair. If not, turn both off and then on again.
4. **Driving Forward/Backward:** Pull the trigger on the controller towards you to move the car forward. Push the trigger away from you to move the car backward or to brake.
5. **Steering:** Use the steering wheel on the side of the controller to turn the car left or right.
6. **Steering Trim:** If the car does not drive straight, locate the steering trim adjustment on the bottom of the car and adjust it slightly until the car tracks straight.



Image: A detailed view of the blue Power Craze High Speed Mini RC Car. The car features a durable roll cage design, large off-road tires with blue rims, and a detailed interior. The 'SOUL DESERT' decal is visible on the side.



Image: The blue Power Craze High Speed Mini RC Car is depicted in motion on a rocky, dusty surface, suggesting its capability for off-road use. The car's front wheels are slightly lifted, indicating speed or a jump.

Maintenance

Proper maintenance will extend the life of your RC car:

- **Cleaning:** After each use, gently wipe down the car with a dry cloth to remove dirt and dust. Do not use water or chemical cleaners.
- **Storage:** Store the RC car and controller in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Always remove batteries from the controller if not used for a long period. For the car's rechargeable battery, follow the manufacturer's guidelines for charging and storage to maintain battery health.
- **Inspection:** Periodically check for loose screws, damaged wires, or obstructions (like hair or threads) in the wheels or motor.

Troubleshooting

If you encounter issues with your Power Craze RC Car, try these solutions:

Problem	Possible Cause	Solution
Car does not respond to controller.	Low batteries in controller or car; Car/controller not turned on; Not paired.	Replace controller batteries; Charge car battery; Ensure both are ON; Turn both OFF then ON again to re-pair.
Car drives slowly or inconsistently.	Low battery in car; Obstruction in wheels/motor.	Recharge car battery; Check wheels and motor for debris and remove.
Car does not drive straight.	Steering trim needs adjustment.	Adjust the steering trim knob/slider on the bottom of the car until it drives straight.
Wheels are not spinning, but motor runs.	Damaged axle or gear.	Inspect axles for damage. If broken, contact customer support.

Specifications

- **Product Dimensions:** 4.75 x 3.4 x 2.25 inches
- **Item Weight:** 2.1 pounds
- **Model Number:** 798753221109
- **ASIN:** B07YNFSCTS
- **Manufacturer Recommended Age:** 22 months - 5 years
- **Controller Batteries:** 2 AA batteries (not included)
- **Manufacturer:** Power Craze
- **Release Date:** May 22, 2019

Warranty and Support

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Power Craze website. Do not return the product to the retailer without first contacting the manufacturer's support for troubleshooting or return authorization.
Please retain your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why do the headlights on my Power Craze Soul Desert RC truck stay on while charging, and is there a fix for this?

Based on the Power Craze High Speed Mini RC Car manual and general operation for this model, here is information regarding the headlights and charging: Normal Charging Behavior: For many Power Craze models, the...

Read full answer

Open the live page

https://manuals.plus/asin/B07YNFSCTS

More documents and user manuals: **https://manuals.plus/**