Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire EFIC121SSRED/EFIC123SSRED

Frigidaire Compact Countertop Ice Maker User Manual

Model: EFIC121SSRED/EFIC123SSRED

Introduction Safety Information Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

This manual provides essential information for the safe and efficient operation of your Frigidaire Compact Countertop Ice Maker. Please read all instructions carefully before use and retain this manual for future reference.
The Frigidaire Compact Countertop Ice Maker is designed to produce bullet-shaped ice cubes quickly and conveniently, making it ideal for kitchens, offices, home bars, and parties. It can produce up to 26 lbs of ice per day and stores up to 1.7 lbs at a time.

2. Important Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before operating the appliance.
- Do not immerse cord, plug, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Do not use appliance for other than intended use.
- This ice maker is designed to produce ice, not store it. The unit does not keep ice frozen once it's made. To prevent melting, transfer the ice to your freezer promptly after it is produced.

3. Setup and First Use

3.1 Unpacking and Placement

Carefully remove the ice maker from its packaging. Ensure all packing materials are removed. Place the ice maker on a stable, level surface away from direct sunlight and heat sources. Allow at least 4 inches of space around the unit for proper ventilation. The compact design (13.5"D x 10"W x 14"H) makes it suitable for most countertops.



Figure 3.1: Frigidaire Compact Countertop Ice Maker with included accessories.



Figure 3.2: Product dimensions for optimal placement.

3.2 Initial Cleaning

Before first use, clean the interior of the ice maker. Remove the ice basket and wash it with warm water and mild detergent. Wipe the interior with a soft cloth. Ensure the drain plug is securely closed after cleaning.

3.3 Adding Water

Open the lid and fill the water reservoir with potable water up to the MAX fill line. Do not overfill. The reservoir has a 1.7-liter capacity.



Figure 3.3: Open lid to access water reservoir and ice basket.

3.4 Power Connection

Plug the ice maker into a grounded electrical outlet. The unit operates on 126 Volts and consumes 200 watts.

4. Operating Instructions

4.1 Control Panel Overview

The ice maker features an intuitive digital LED control panel for easy operation.



Figure 4.1: Digital LED Control Panel.

- **ON/OFF Button:** Press to turn the ice maker on or off.
- **SELECT Button:** Press to choose between small (S) or large (L) bullet-shaped ice cubes.
- **ADD WATER Indicator:** Illuminates when the water reservoir needs refilling.
- **ICE FULL Indicator:** Illuminates when the ice basket is full.
- **POWER Indicator:** Illuminates when the unit is powered on.

4.2 Making Ice

1. Ensure the unit is plugged in and the water reservoir is filled.
2. Press the **ON/OFF** button to start the ice making cycle. The POWER indicator will light up.
3. Use the **SELECT** button to choose your desired ice cube size (Small or Large).
4. The ice maker will begin producing ice. The first batch of ice may take slightly longer. Subsequent batches are produced in less than 9 minutes.
5. When the ice basket is full, the **ICE FULL** indicator will light up, and the unit will pause ice production. Remove ice

from the basket to resume production.

6. When the water reservoir is low, the **ADD WATER** indicator will light up. Refill the reservoir to continue ice production.



Figure 4.2: Accessing the ice basket and scoop.

4.3 Using the Ice Scoop and Basket

The ice maker comes with an ice basket and a scoop for convenient ice retrieval. Use the scoop to transfer ice from the basket to your beverages or a separate freezer for storage.

5. Maintenance and Cleaning

5.1 Regular Cleaning

To ensure optimal performance and hygiene, regularly clean your ice maker. Unplug the unit before cleaning.

- Remove the ice basket.

- Drain any remaining water from the reservoir by opening the drain plug located at the bottom of the unit.
- Clean the interior with a soft cloth and a mild, non-abrasive cleaner. Rinse thoroughly.
- Wipe the exterior with a damp cloth. The stainless steel finish may require buffing to remove fingerprints.
- Ensure all parts are dry before reassembling and storing the unit.

5.2 Ice Storage Note

It is important to note that this ice maker is designed to produce ice, not to store it long-term. The unit does not maintain freezing temperatures in the ice basket. For prolonged storage, transfer the produced ice to a freezer immediately after it is made.

6. Troubleshooting

Problem	Possible Cause	Solution
Ice maker not turning on.	No power.	Check if the unit is properly plugged into a working outlet. Check circuit breaker.
"ADD WATER" indicator is on.	Water reservoir is empty or low.	Fill the water reservoir up to the MAX fill line.
"ICE FULL" indicator is on.	Ice basket is full.	Remove ice from the basket.
Ice melts quickly in the basket.	Unit is not a freezer.	Transfer ice to a freezer for long-term storage immediately after production.
Ice cubes are not forming or are too small.	Insufficient water, water too warm, or first cycle.	Ensure water is cold. Allow several cycles for optimal ice production. Check water level.

7. Product Specifications

Brand: Frigidaire

Model Name: EFIC121SSRED/EFIC123SSRED

Product Dimensions: 13.5"D x 10"W x 14"H

Capacity: 26 Pounds (ice production per day)

Ice Storage: 1.7 lbs (basket capacity)

Wattage: 200 watts

Voltage: 126 Volts

Refrigerant: R134a

Material: Metal, Plastic

Color: Red Stainless

Item Weight: 31.9 pounds

Installation Type: Countertop

Included Components: Ice Maker, Basket, Scoop

8. Warranty and Support

For warranty information, product registration, or technical support, please refer to the official Frigidaire website or contact their customer service. Keep your purchase receipt for warranty claims.
Frigidaire is a trusted leader in home appliances with over 100 years of excellence, committed to making everyday living easier and more efficient.
For more information, visit the **Frigidaire Store on Amazon**.

© 2025 Frigidaire. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07YT38JVW

More documents and user manuals: **https://manuals.plus/**