Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire EFMIS155

Frigidaire EFMIS155 Beverage Refrigerator User Manual

Model: EFMIS155

1. Introduction

This manual provides essential information for the safe and efficient operation of your Frigidaire EFMIS155 Beverage Refrigerator. Please read this manual thoroughly before installation and use, and keep it for future reference.
The Frigidaire EFMIS155 is a 4.4 cubic feet beverage center designed to store up to 126 (12 oz.) beverage cans. It features digital touch controls, an LED display for temperature adjustment, blue LED interior lighting, and four removable shelves for flexible storage. The unit is equipped with a tinted double-pane glass door and a stainless steel frame and handle for durability and a modern aesthetic. Adjustable feet allow for optimal placement.

2. Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Ensure the appliance is properly grounded.
- Do not operate if the power cord is damaged.
- Keep ventilation openings clear of obstruction.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Unplug the appliance before cleaning or maintenance.
- This appliance is intended for household use only.

3. Setup and Installation

The Frigidaire EFMIS155 is designed for freestanding installation. Choose a location with a solid, level surface away from direct sunlight and heat sources.

3.1 Unpacking

- Carefully remove all packaging materials, including foam and adhesive tape.
- Inspect the appliance for any damage. Report any damage to your retailer immediately.
- Keep packaging materials out of reach of children.

3.2 Placement

- Place the refrigerator on a flat, stable surface.
- Allow at least 4 inches (10 cm) of space around the back and sides for proper ventilation.
- Avoid placing the unit near heat-generating appliances or in direct sunlight.

3.3 Leveling the Unit

The appliance features adjustable feet to ensure stability and proper door alignment.

- Turn the leveling feet clockwise to raise the unit, and counter-clockwise to lower it.
- Ensure the unit is level to prevent vibrations and ensure proper door sealing.



Figure 3.1: Front view of the Frigidaire EFMIS155 Beverage Refrigerator, showcasing its stainless steel finish and glass door.



Figure 3.2: Diagram illustrating the dimensions of the beverage refrigerator: 20.5"W x 21.3"D x 31.4"H, with a 125L capacity indicated.

4. Operating Instructions

Your Frigidaire EFMIS155 Beverage Refrigerator is equipped with user-friendly controls for optimal performance.

4.1 Digital Temperature Control

The unit features digital touch controls and an LED display located at the top of the interior. The temperature can be adjusted between 40°F (4°C) and 60°F (15°C).

- Press the **Temperature Up (▲)** button to increase the temperature setting.
- Press the **Temperature Down (▼)** button to decrease the temperature setting.
- The LED display will show the current temperature.



Figure 4.1: Detailed view of the digital temperature controls and LED display, showing buttons for LED light, temperature adjustment, and the current temperature reading.

4.2 Interior LED Lighting

The blue LED interior lighting showcases the contents of your beverage refrigerator. This light can be turned on or off using the light button on the control panel.

- Press the **Light ( )** button to toggle the interior LED light.



Figure 4.2: Interior view of the beverage refrigerator filled with various cans, illuminated by the blue LED lighting, demonstrating its storage capacity and visual appeal.

4.3 Adjustable Shelves

The four removable shelves provide flexible storage options, allowing you to accommodate various bottle and can sizes.

- To adjust a shelf, carefully lift it and slide it out.
- Reinsert the shelf into the desired grooves, ensuring it is securely seated.



Figure 4.3: A hand demonstrating the removal or adjustment of one of the four wire shelves, highlighting the flexible storage options within the unit.

5. Maintenance and Care

Regular maintenance ensures the longevity and optimal performance of your beverage refrigerator.

5.1 Cleaning

- Always unplug the unit before cleaning.
- Clean the interior and exterior surfaces with a soft cloth and a mild detergent.
- Do not use abrasive cleaners or solvents.
- Wipe down the door gasket regularly to ensure a tight seal.
- The shelves are removable for easy cleaning.

5.2 Defrosting

This unit features an automatic defrost system, minimizing the need for manual defrosting.

5.3 Power Outage

In case of a power outage, keep the door closed to maintain the internal temperature for as long as possible. The unit will resume operation automatically once power is restored.

6. Troubleshooting

Before contacting customer support, please refer to the following common issues and their solutions.

Problem	Possible Cause	Solution
Unit does not operate.	No power; power cord unplugged; circuit breaker tripped.	Check power supply, plug, and circuit breaker.
Temperature is not cold enough.	Temperature setting too high; door opened too frequently; poor ventilation; overloaded with warm items.	Adjust temperature setting lower; minimize door openings; ensure proper clearance around unit; allow warm items to cool before placing inside.
Unit is making unusual noises.	Normal operating sounds (compressor, refrigerant flow); unit not level.	These sounds are normal. If excessive, ensure unit is level using adjustable feet.
Door does not close properly.	Unit not level; door gasket dirty or damaged; shelves are out of place.	Level the unit; clean or replace door gasket; reposition shelves.

7. Specifications

Feature	Detail
Brand	Frigidaire
Model	EFMIS155
Capacity	4.4 Cubic Feet (approx. 126 x 12 oz. cans)
Product Dimensions (D x W x H)	20" x 22" x 31"
Item Weight	50 Pounds
Temperature Range	40°F - 60°F (4°C - 15°C)
Installation Type	Freestanding
Defrost System	Automatic
Shelves	4 (Removable, Wire or Plastic)
Door Material Type	Stainless Steel, Glass
Special Features	Reversible door, Digital Thermostatic controls, Blue LED interior lighting
Included Components	Cooler, 4 Shelves, Owners Manual

8. Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Frigidaire website. You may also contact customer support via the retailer where the product was purchased. For additional assistance, please visit the Frigidaire Store on Amazon.

© 2024 Frigidaire. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07YT3HQDM

More documents and user manuals: **https://manuals.plus/**