Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire EFIC123-SSBLACK

Frigidaire EFIC123-SSBLACK Compact Countertop Ice Maker Instruction Manual

Model: EFIC123-SSBLACK | Brand: Frigidaire

1. Introduction

This manual provides comprehensive instructions for the safe and efficient operation of your Frigidaire EFIC123-SSBLACK Compact Countertop Ice Maker. Please read all instructions carefully before use and retain this manual for future reference.

Product Overview

The Frigidaire EFIC123-SSBLACK Compact Countertop Ice Maker is designed to produce up to 26 lbs of bullet-shaped ice per day. Its compact and sleek design makes it suitable for various settings, including kitchens, offices, home bars, and parties. The unit features intuitive controls and a transparent window for easy monitoring of ice production.

- **Sleek Design:** Produces up to 26 lbs. of ice per day with a countertop design.
- **Fast Ice Production:** Churns out bullet-shaped ice cubes every 6 minutes, with two size options.
- **Intuitive Control:** Digital LED control panel and transparent window for monitoring.
- **Large Water Capacity:** 2.3 qt. water tank capacity for uninterrupted ice making.
- **Easy Maintenance:** Drain plug feature for easy emptying and cleaning.
- **Included Accessory:** Comes with an ice scoop for convenient ice retrieval.
- **Important Note:** This ice maker is designed to produce ice, not store it. Transfer ice to a freezer promptly to prevent melting.

2. Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before use.
- Do not touch the evaporator with your hands while the unit is operating.
- Do not immerse the cord, plug, or any part of the unit in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Avoid using attachments not recommended by the manufacturer.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been

damaged in any manner.

- Use only potable water.
- Do not puncture refrigerant tubing.
- This appliance is for household use only.

3. Setup

1. **Unpacking:** Carefully remove all packaging materials and inspect the ice maker for any damage. Ensure all accessories (ice basket, ice scoop) are present.
2. **Placement:** Place the ice maker on a flat, stable surface away from direct sunlight and heat sources (e.g., stove, oven, radiator). Ensure there is at least 5 inches of space around the unit for proper ventilation.
3. **Initial Cleaning:** Before first use, clean the interior of the ice maker. Remove the ice basket and wash it with warm water and mild detergent. Wipe the interior with a soft cloth. Rinse thoroughly.
4. **Power Connection:** Plug the ice maker into a grounded electrical outlet. Ensure the voltage matches the specifications of the unit.



Image: The Frigidaire EFIC123-SSBLACK Compact Countertop Ice Maker in black stainless steel, shown on a kitchen countertop with an ice scoop and ice basket.

4. Operating Instructions

1. **Add Water:** Open the top lid and remove the ice basket. Fill the water reservoir with potable water up to the "MAX" fill line. Do not overfill.
2. **Power On:** Close the lid and press the "ON/OFF" button on the control panel. The "POWER" indicator light will illuminate.
3. **Select Ice Size:** Press the "SELECT" button to choose between small (S) or large (L) bullet-shaped ice cubes. The corresponding indicator light will illuminate.

4. **Ice Production:** The ice maker will begin the ice-making cycle. The first batch of ice will be ready in approximately 6-7 minutes.
5. **Ice Full Notification:** When the ice basket is full, the "ICE FULL" indicator light will turn on, and the unit will automatically stop making ice.
6. **Add Water Notification:** If the water level in the reservoir is too low, the "ADD WATER" indicator light will turn on, and the unit will stop making ice. Refill the reservoir to resume operation.
7. **Retrieve Ice:** Use the provided ice scoop to remove ice from the basket. Transfer the ice to a freezer for storage, as the ice maker does not keep ice frozen.
8. **Power Off:** To turn off the ice maker, press the "ON/OFF" button.



Image: The ice maker with its lid open, showing the ice basket filled with bullet-shaped ice cubes. An ice scoop is visible next to the basket.



Image: A close-up view of the digital LED control panel, showing indicator lights for "ADD WATER", "ICE FULL", "POWER", and ice size selection (S/L).

5. Maintenance

Regular Cleaning

Regular cleaning helps maintain ice quality and extends the life of your ice maker.

1. **Daily Cleaning:** After each use, drain any remaining water from the reservoir using the drain plug located at the bottom of the unit. Wipe the interior with a soft cloth.
2. **Weekly Cleaning:** For a more thorough cleaning, remove the ice basket and wash it with warm water and mild detergent. Clean the water reservoir and the ice-making components with a solution of water and vinegar (10:1 ratio) or a mild disinfectant. Rinse all parts thoroughly with clean water.
3. **Exterior Cleaning:** Wipe the exterior of the unit with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.

Storage

If the ice maker will not be used for an extended period, drain all water, clean the unit, and allow it to dry completely before storing. Store in a cool, dry place.



Image: The ice maker with its lid open, highlighting the removable ice basket and the location of the drain plug for easy cleaning.

6. Troubleshooting

Problem	Possible Cause	Solution
"ADD WATER" indicator light is on.	Water reservoir is empty or low.	Fill the water reservoir with potable water up to the MAX line.
"ICE FULL" indicator light is on.	Ice basket is full.	Remove ice from the basket. The unit will resume ice production automatically.

Problem	Possible Cause	Solution
Ice maker is not producing ice.	Unit is not powered on, water reservoir is empty, or ambient temperature is too high.	Ensure unit is plugged in and powered on. Fill water reservoir. Move unit to a cooler location if ambient temperature exceeds recommended operating range.
Ice cubes are too small or not forming properly.	Water temperature is too high, or unit needs cleaning.	Use colder water. Perform a thorough cleaning of the unit.
Unit is noisy.	Normal operation sounds (compressor, water pump) or unit is not level.	Ensure the unit is on a flat, stable surface. If noise is excessive or unusual, contact customer support.

7. Specifications

Feature	Detail
Brand	Frigidaire
Model Name	EFIC123-SSBLACK
Product Dimensions	12.3"D x 8.7"W x 12.5"H
Ice Production Capacity	26 Pounds per Day
Water Tank Capacity	2.3 Quarts (approx. 1.9 Liters)
Ice Storage Capacity	1.5 Pounds
Wattage	1000 watts
Voltage	120V
Refrigerant	R410a
Material	Metal, Plastic
Installation Type	Countertop
Color	Black Stainless
Included Components	Ice Maker, Basket, Scoop

8. Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your product or contact Frigidaire customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.
You can visit the official Frigidaire website for more information:Frigidaire Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07YT3HQND

More documents and user manuals: **https://manuals.plus/**