Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire EFIC123-SS

Frigidaire EFIC123-SS Countertop Ice Maker User Manual

Model: EFIC123-SS

Introduction

This Compact Ice Cube Maker will be your kitchen's biggest asset. Make 2 different sizes of bullet shaped ice cubes in less than 6 minutes and store up to 2 lbs. at a time. Not only will it keep your sodas, lemonades, cocktails, smoothies and other beverages nice and chilled, but it will produce day after day up to 26 lbs. of ice cubes. The Large see-through window will let you watch your ice being made. Ideal for kitchens, offices, home bars and parties.
This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new Frigidaire Countertop Ice Maker.

Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This ice maker is designed to produce ice, not store it. The unit does not keep ice frozen once it's made. To prevent melting, transfer the ice to your freezer promptly after it is produced.

Product Overview

The Frigidaire EFIC123-SS Countertop Ice Maker is designed for convenience and efficiency, producing bullet-shaped ice cubes quickly.



Front view of the Frigidaire EFIC123-SS Countertop Ice Maker in stainless steel, showing the clear lid, control panel, and a pile of bullet ice cubes with a scoop.



Diagram illustrating the dimensions of the Frigidaire EFIC123-SS Ice Maker: 12.5 inches high, 12.3 inches deep, and 8.7 inches wide. It highlights its capacity to produce 26 lbs of bullet ice per day.

Key Features:

- **Compact Design:** Fits easily on countertops. Dimensions: 12.3"D x 8.7"W x 12.5"H.
- **High Efficiency:** Produces up to 26 lbs of ice per day.
- **Fast Ice Production:** Makes bullet-shaped ice cubes in less than 6 minutes.
- **Quiet Operation:** Designed with a silent cooling function.
- **Customizable Ice Sizes:** Choose between 2 different ice cube sizes (Small and Large).
- **Modern Aesthetic:** Stainless steel finish with a transparent viewing window.
- **Included Accessories:** Ice basket and scoop.

Setup

1. **Unpacking:** Carefully remove the ice maker from its packaging. Retain packaging for future storage or transport.

2. **Placement:** Place the unit on a stable, level surface away from direct sunlight and heat sources. Ensure adequate ventilation around the unit.
3. **Initial Cleaning:** Before first use, clean the interior of the ice maker. Refer to the "Maintenance and Cleaning" section for detailed instructions.
4. **Water Fill:** Open the lid and fill the water reservoir with potable water up to the MAX fill line. Do not overfill.
5. **Power Connection:** Plug the power cord into a grounded electrical outlet (115 Volts).



Image showing water being poured into the Frigidaire EFIC123-SS Ice Maker's reservoir, demonstrating its large water capacity of 1.9 quarts for uninterrupted ice making.

Operating Instructions

Control Panel:



Close-up of the intuitive digital LED control panel on the Frigidaire EFIC123-SS Ice Maker, showing indicators for "Add Water", "Ice Full", "Power", and size selection buttons for "S" (Small) and "L" (Large) cubes, along with ON/OFF and SELECT buttons.

- **ON/OFF Button:** Press to turn the unit on or off.
- **SELECT Button:** Press to toggle between Small (S) and Large (L) ice cube sizes.
- **ADD WATER Indicator:** Illuminates when the water reservoir needs refilling.
- **ICE FULL Indicator:** Illuminates when the ice basket is full.
- **POWER Indicator:** Illuminates when the unit is powered on.

Making Ice:

1. Ensure the unit is plugged in and the water reservoir is filled.
2. Press the **ON/OFF** button to start the ice making cycle. The POWER indicator will light up.
3. Press the **SELECT** button to choose your desired ice cube size (Small or Large). The corresponding indicator (S or L) will light up.
4. The ice maker will begin producing ice. The first batch may take slightly longer.

5. When the ice basket is full, the ICE FULL indicator will light up, and the unit will pause operation. Remove ice from the basket to resume production.
6. If the ADD WATER indicator lights up, refill the water reservoir to continue ice production.
7. To stop ice production, press the **ON**/**OFF** button.



The Frigidaire EFIC123-SS Ice Maker in operation, showing bullet-shaped ice cubes being produced and collected in the basket. This image highlights the fast ice production capability.



A user removing the ice basket filled with bullet ice cubes from the Frigidaire EFIC123-SS Ice Maker, demonstrating the ease of access and the included ice scoop.

Maintenance and Cleaning

Regular cleaning and maintenance will ensure optimal performance and longevity of your ice maker.

Daily Maintenance:

- After each use, drain any remaining water from the reservoir.
- Wipe the interior and exterior surfaces with a soft, damp cloth.

Weekly Cleaning:

1. Unplug the ice maker from the power outlet.
2. Remove the ice basket and clean it with warm, soapy water. Rinse thoroughly.
3. Drain all water from the reservoir by removing the drain plug located at the bottom of the unit.
4. Clean the interior of the water reservoir and ice-making components with a solution of water and mild detergent. For stubborn mineral deposits, a solution of water and vinegar (1:1 ratio) can be used.
5. Rinse all internal parts thoroughly with clean water to remove any detergent or vinegar residue.
6. Wipe the exterior with a soft, damp cloth.
7. Ensure all parts are dry before reassembling and storing or using the unit.

Note: *Do not immerse the appliance in water. Do not use abrasive cleaners or sharp objects to clean the unit.*

Troubleshooting

Troubleshooting Guide

Problem	Possible Cause	Solution
Ice maker does not turn on.	No power supply.	Check if the unit is properly plugged into a working outlet. Check circuit breaker.
"ADD WATER" indicator is on.	Water reservoir is empty or low.	Fill the water reservoir to the MAX fill line.
"ICE FULL" indicator is on.	Ice basket is full.	Remove ice from the basket.
Ice cubes are too small or not forming properly.	Insufficient water or water temperature too high. Ambient temperature too high.	Ensure water reservoir is full. Use colder water. Operate in a cooler environment.
Ice melts quickly in the basket.	This unit is designed to produce ice, not store it.	Transfer ice to a freezer immediately after production to prevent melting.
Unusual noise during operation.	Normal operation sounds (water pump, ice dropping) or unit not level.	Ensure the unit is on a stable, level surface. If noise persists and is abnormal, contact customer support.

Specifications

Specification	Detail
Brand	Frigidaire
Model Name	EFIC123-SS
Product Dimensions (D x W x H)	12.3" x 8.7" x 12.5"
Capacity (Ice Production)	Up to 26 lbs per day
Water Tank Capacity	1.9 quarts (approx.)
Wattage	1000 watts
Voltage	115 Volts
Refrigerant	R134a
Material	Plastic, Metal (Stainless Steel)
Item Weight	15.92 pounds
Included Components	Ice Maker, Basket, Scoop

Warranty and Support

For warranty information and customer support, please refer to the product packaging or contact Frigidaire customer service directly. Keep your purchase receipt for warranty claims.
Manufacturer: Frigidaire
Model: EFIC123-SS
UPC: 058465813376
For further assistance, visit the official Frigidaire website or contact their customer support line.

© 2025 Frigidaire. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07YT3S4YK

More documents and user manuals: **https://manuals.plus/**