Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER W08

PKPOWER AC DC Adapter W08 User Manual

Model: W08 | Brand: PKPOWER

1. Introduction

This manual provides essential information for the safe and effective use of your PKPOWER AC DC Adapter, Model W08. This adapter is designed to provide a reliable power supply for compatible NIX Nixplay W08A, W08C, W08D, W08E Edge 8-Inch Wi-Fi Cloud Digital Photo Frames.

Please read this manual thoroughly before using the product and retain it for future reference.

2. Safety Information

- **Indoor Use Only:** This adapter is designed for indoor use in dry locations. Do not expose it to rain, moisture, or extreme temperatures.
- **Proper Ventilation:** Ensure adequate ventilation around the adapter during use. Do not cover it with cloth or other materials.
- **Avoid Damage:** Do not use the adapter if the casing or cable is damaged. Avoid bending, twisting, or pulling the cable excessively.
- **Electrical Safety:** Always plug the adapter into a properly grounded and accessible wall outlet. Disconnect from the power source before cleaning or if not in use for extended periods.
- **Protection Features:** This PKPOWER adapter is equipped with advanced safety features including**OVP** (Over Voltage Output Protection), **OCP** (Over Current Output Protection), and **SCP** (Short Circuit Output Protection) to ensure safe and stable power delivery.
- **Certifications:** The product is CE, FCC, and RoHS certified, indicating compliance with health, safety, and environmental protection standards.

3. Package Contents

- 1 x PKPOWER AC DC Adapter (Model W08)



Image: The PKPOWER AC DC Adapter with its integrated power cable coiled neatly.

4. Setup

1. **Verify Compatibility:** Before connecting, ensure that your NIX Nixplay digital photo frame (models W08A, W08C, W08D, W08E) requires a power input matching the specifications of this adapter.
2. **Connect to Device:** Carefully insert the adapter's DC output connector into the power input port of your NIX Nixplay digital photo frame. Ensure a snug fit.
3. **Connect to Power Outlet:** Plug the adapter's AC input plug (Type A or Type B) into a standard 100-240V wall electrical outlet.
4. **Power On:** Your digital photo frame should now power on or begin charging, depending on its current state.





Image: Side view of the PKPOWER AC DC Adapter, highlighting the standard US AC plug for wall outlets.

5. Operating Instructions

Once properly connected, the PKPOWER AC DC Adapter will continuously supply power to your compatible NIX

Nixplay digital photo frame. No further user interaction is typically required for basic operation.

- To disconnect power, first unplug the adapter from the wall outlet.
- Then, gently disconnect the DC output connector from your digital photo frame.

6. Maintenance

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and moisture. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the adapter and its cable for any signs of damage, such as cuts, fraying, or exposed wires. Discontinue use if damage is found.
- **No User Serviceable Parts:** Do not attempt to open or repair the adapter. Doing so will void any warranty and may pose a safety risk.

7. Troubleshooting

- **Device Not Powering On:**
  - Ensure the adapter is securely plugged into both the wall outlet and the digital photo frame.
  - Test the wall outlet with another device to confirm it is functional.
  - Verify that the adapter is the correct model (W08) and compatible with your specific NIX Nixplay digital photo frame model (W08A, W08C, W08D, W08E).
- **Adapter Feels Warm:**
  - It is normal for the adapter to feel slightly warm during operation.
  - If the adapter becomes excessively hot, disconnect it immediately from the wall outlet and your device. Allow it to cool down. Ensure it is not covered and has adequate ventilation. If the issue persists, contact customer support.

8. Specifications

Feature	Description
Brand	PKPOWER
Model Number	W08
Input Voltage	100-240V AC, 50/60Hz
Compatibility	NIX Nixplay W08A, W08C, W08D, W08E Edge 8-Inch Wi-Fi Cloud Digital Photo Frames
Certifications	CE, FCC, RoHS
Protection Features	OVP, OCP, SCP
Item Weight	3 ounces (approx. 85 grams)
AC Plug Format	Type A or Type B (Standard US 2-prong)

Cable Length	1 Meter (approx. 3.3 feet)
Dimensions (Adapter Body)	Approx. 2.92 in (L) x 1.58 in (W) x 1.18 in (H)



Image: The PKPOWER AC DC Adapter with its approximate dimensions (length, width, height) indicated.





Image: Front view of the PKPOWER AC DC Adapter, displaying the input voltage (100-240VAC 0.3A 50/60Hz) and certification logos (FCC, CE, RoHS).

9. Warranty and Support

PKPOWER is committed to providing high-quality products and excellent customer service. If you encounter any issues or have questions regarding your AC DC Adapter, please do not hesitate to contact us.

Our friendly and reliable customer service team aims to respond to all inquiries within 24 hours.

For further assistance or to explore other PKPOWER products, please visit our official store:

Visit the PKPOWER Store on Amazon

© 2026 PKPOWER. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07Z3FCG4L

More documents and user manuals: **https://manuals.plus/**