Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun 5050cs

Braun Series 5 5050cs Electric Razor User Manual

Model: 5050cs

Introduction

Welcome to the user manual for your Braun Series 5 5050cs Electric Razor. This manual provides essential information on the safe operation, setup, maintenance, and troubleshooting of your new electric shaver. Designed for a close and comfortable shave, the Braun Series 5 features flexible blades, a powerful Li-Ion battery, and the convenient EasyClean system. Please read this manual thoroughly before first use to ensure optimal performance and longevity of your device.

Safety Information

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions should always be followed, including the following: Read all instructions before using this appliance. When disconnected, the hand-held part of this shaving appliance may be used in a bath or shower. For safety reasons this appliance can only be operated cordless.

DANGER: To reduce the risk of electric shock:

1. The charger unit is not for immersion in water or for use in shower.
2. Do not reach for a charger that has fallen into water. Unplug immediately.
3. Do not place, store or charge the appliance where it can fall or be pulled into a tub or sink. Do not place in or drop into water or other liquid.
4. Except when charging, always unplug this appliance from the electrical outlet immediately after using.
5. This appliance is provided with a special cord set with integrated Safety Extra Low Voltage power supply. Do not exchange or manipulate any part of it.
6. Do not use an extension cord with this appliance.
7. Unplug this appliance before cleaning.

WARNING: To reduce the risk of burns, fire, electric shock, or injury to persons:

1. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

2. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
3. Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or if the power supply has been dropped into water. Return the appliance to a service center for examination and repair.
4. Keep the cord away from heated surfaces.
5. Never drop or insert any object into any opening of the appliance.
6. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
7. Do not use this appliance with a damaged or broken foil, as serious skin injuries may occur.
8. Always attach plug to appliance first, then to outlet. To disconnect, turn all controls off, then remove plug from outlet.
9. When plugging to an electrical outlet outside North America, use a plug adapter to match the outlet's pin configuration.
10. Caution: The battery used in this device may present a fire or chemical burn hazard if mistreated. Do not disassemble, heat above 100 °C (212 °F), or incinerate.
11. To recharge the battery, only use the detachable power supply provided with this appliance. If the appliance is marked 492, only use Braun power supplies coded 492-XXXX.

What's Included

Your Braun Series 5 5050cs package includes the following components:



Image: All components included in the Braun Series 5 5050cs package.

- 1x Series 5 Electric Razor
- 1x Charging Stand
- 1x Precision Trimmer attachment
- 1x Body Groomer attachment
- 1x Smart plug (charging cable)
- 1x Cleaning Brush

Key Features

The Braun Series 5 5050cs is engineered with advanced features for an efficient and comfortable shaving experience.



Image: Key features of the Braun Series 5 shaver.

Flexible Blades

The shaver features 3 flexible blades that adapt to your facial contours, ensuring a close and comfortable shave even in hard-to-reach areas.



Image: The 3 flexible blades adapting to facial contours.

100% Waterproof for Wet & Dry Use

This shaver is designed for both wet and dry use. You can shave with foam, gel, or even in the shower for added comfort and convenience.



Image: The shaver being used with foam, highlighting its 100% waterproof design.

EasyClean System

The EasyClean system allows for fast and simple cleaning without needing to remove the shaver head. Simply rinse under running water.



Image: The EasyClean system in action, showing water rinsing through the shaver head.

Long-lasting Li-Ion Battery

The powerful Li-Ion battery provides up to 50 minutes of shaving time on a full charge, which typically lasts up to 3 weeks of shaving. A quick 5-minute charge is sufficient for one shave.



Image: The shaver on its charging stand, illustrating its battery life.

Built to Last

The Braun Series 5 shaver is made in Germany and designed for durability, with the shaver handle built to last up to 7 years. The shaver head should be replaced approximately every 18 months for optimal performance.



Image: Durability claim for the shaver, indicating it's made in Germany and lasts up to 7 years.



Image: Guidance on replacing the shaver head every 18 months for continued performance.

Setup

Charging the Shaver

Before first use, fully charge your Braun Series 5 shaver. Connect the smart plug to the shaver and then to an electrical outlet. The charging indicator lights will show the charging progress. A full charge takes approximately 1 hour and provides up to 50 minutes of cordless shaving. For a quick shave, a 5-minute charge is sufficient.



Image: The shaver connected to its charging stand.

Operating Instructions

Basic Shaving

Press the power button to turn on the shaver. For a dry shave, ensure your skin is clean and dry. For a wet shave, apply shaving foam or gel to your face. Hold the shaver at a right angle (90°) to your skin and shave against the direction of hair growth. Apply gentle, even pressure. The flexible blades will adapt to your facial contours for an efficient shave.

Using EasyClick Attachments

The Braun Series 5 5050cs comes with EasyClick attachments for versatile grooming. To attach, simply remove the shaver head by pulling it off, and then click the desired attachment (Precision Trimmer or Body Groomer) onto the shaver handle until it locks into place. To remove, pull the attachment off.

- **Precision Trimmer:** Ideal for shaping sideburns, mustaches, and beards.

- **Body Groomer:** Use for trimming body hair.

Maintenance

Cleaning the Shaver

Regular cleaning ensures optimal performance and hygiene. The EasyClean system allows for quick cleaning without removing the shaver head. After each use, simply rinse the shaver head under warm running water while the shaver is turned on. For a more thorough cleaning, you can use the included cleaning brush to remove any trapped hair.



Image: Demonstrating the EasyClean system by rinsing the shaver under water.

Replacing Shaver Parts

For continued optimal shaving performance, it is recommended to replace the shaver head (foil and cutter block) approximately every 18 months. You can purchase genuine Braun replacement parts from authorized retailers.



Image: Reminder for replacing the shaver head for sustained performance.

Troubleshooting

If you encounter any issues with your Braun Series 5 5050cs electric razor, please refer to the following common solutions:

- **Shaver not turning on:** Ensure the battery is charged. Connect the shaver to the charger and allow it to charge for at least 5 minutes.
- **Reduced shaving performance:** The shaver head may be worn. Replace the shaver head (foil and cutter block) every 18 months. Ensure the shaver is clean and free of hair debris.
- **Shaver not charging:** Check that the smart plug is securely connected to both the shaver and the electrical outlet. Ensure the outlet is functional.
- **Skin irritation:** Ensure your skin is clean before shaving. Shave against the direction of hair growth with gentle pressure. Consider using a wet shave with foam or gel.

If the problem persists, please contact Braun customer support for further assistance.

Specifications

Feature	Detail
Model Name	5050cs
Product Dimensions	5.39 x 2.64 x 9.92 inches
Item Weight	13.44 ounces
Power Source	Battery Powered (1 Lithium Ion battery included)
Special Feature	Easy Clean, Wet & Dry Use, Flexible Blades
Recommended Uses	Beard, Face, Body
Manufacturer	Procter & Gamble

Warranty and Support

Product Warranty

The Braun Series 5 5050cs electric razor is designed and manufactured in Germany to high-quality standards. The shaver handle is built to last for up to 7 years. For optimal shaving performance, the shaver head (foil and cutter block) should be replaced approximately every 18 months.

Customer Support

For any questions, concerns, or technical support regarding your Braun Series 5 5050cs electric razor, please visit the official Braun website or contact their customer service department. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2025 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07Z6HWZX4

More documents and user manuals: **https://manuals.plus/**