Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Coleman 2000024289

Coleman 4-Person Carlsbad Dark Room Dome Camping Tent with Screen Room Instruction Manual

Model: 2000024289

Product Overview

The Coleman 4-Person Carlsbad Dark Room Dome Camping Tent with Screen Room is designed for comfortable outdoor adventures. It features Dark Room Technology, which blocks 90% of sunlight and reduces heat inside the tent, allowing for more comfortable rest at any time. A separate screen room lets you watch nature unfold while keeping the bugs away. With a full floor in the screen room, you can also use it as extra sleeping space on warmer nights.



Image: Coleman branding on the tent fabric.

Setup Instructions

Setting up your Coleman Carlsbad tent is a straightforward process, typically taking around 15 minutes. Follow these steps for a quick and secure setup:

1. **Prepare the Area:** Choose a flat, clear spot for your tent. Lay the tent body flat on the ground.
2. **Stake Down the Tent:** Use the provided metal stakes to secure the corners of the tent body to the ground.
3. **Assemble Tent Poles:** Connect the sections of the fiberglass tent poles. You will have two longer poles for the main tent structure and one shorter pole for the rainfly.
4. **Insert Main Poles:** Thread the two longer poles through the sleeves on the tent body, forming an 'X' pattern.

Insert the ends of these poles into the pins located at the corner rings. Gently bow the poles to create the dome shape.

5. **Attach Pole Clips:** Secure the tent body to the poles using the plastic clips located along the tent fabric.
6. **Position Rainfly:** Drape the rainfly over the tent, ensuring the Coleman logo faces up and is positioned correctly over the door.
7. **Insert Rainfly Pole:** Slide the shorter tent pole under the rainfly and into the designated pockets at the center. Secure it with the Velcro straps.
8. **Secure Rainfly:** Attach the S-hooks on the rainfly to the rings at the base of the tent where the main poles are attached. Extend the rainfly sides by untying the attached strings, staking them into the ground about 5-6 feet away from the tent, and tightening them.
9. **Open Ventilation Flap:** On the back of the tent, there is a ventilation flap. Open it by pulling the loop and securing it with a stake to enhance airflow.

▶ **Watch video online**
How to Set Up the Coleman Carlsbad 4

Video: Detailed guide on how to set up the Coleman Carlsbad 4-person tent, demonstrating each step from laying out the tent to securing the rainfly and poles.

▶ **Watch video online**
Coleman Sundome Tent - Overview, Setup, Takedown

Video: Overview, setup, and takedown instructions for a Coleman Sundome Tent, showcasing general tent pitching techniques applicable to similar dome tents.

Key Features

- **Dark Room Technology:** Blocks 90% of sunlight (compared to a standard Coleman tent) to help you sleep longer and reduces heat inside for comfort.
- **Weatherproof Design:** Features a durable rainfly for extra weather protection, welded corners, and inverted seams to prevent water intrusion. The strong frame is designed to withstand winds up to 35+ mph.
- **Integrated Screen Room:** A 9 x 4 ft. full-floor screen room provides a bug-free lounging area and can be used for additional sleeping space.
- **E-Port Access:** An E-Port allows for easy electrical power access inside the tent.
- **Spacious Interior:** The tent measures 9 x 7 ft. with a 4 ft. 11 in. center height, comfortably fitting 1 queen-size air bed.
- **Storage Pockets:** Internal storage pockets help keep your gear organized and off the tent floor.



Image: Interior view of the tent highlighting the Dark Room Technology, which significantly reduces light penetration.



Image: Close-up of the tent's screen room, showing the mesh walls for ventilation and insect protection.

▶ **Watch video online**
How Spacious is the Coleman Carlsbad 4?

Video: Demonstrates the interior spaciousness of the Coleman Carlsbad 4-person tent, showing how much room is available for occupants and gear.

Specifications

Feature	Detail
Brand	Coleman
Model Name	Coleman Dome
Model Number	2000024289
Occupancy	4 Person
Dimensions (Tent)	9 x 7 ft. (Floor Area: 63 sq ft)
Center Height	4 ft. 11 in.
Screen Room Dimensions	9 x 4 ft. (full-floor)
Material Type	Polyester (Rainfly), Polyethylene 1000D (Tent Floor)
Pole Material Type	Fiberglass
Water Resistance Technology	WeatherTec™ system with welded floors and inverted seams
Number of Doors	1
Number of Rooms	2
Included Components	Pole, Storage Bag

Maintenance

To ensure the longevity and performance of your Coleman tent, proper care is essential:

- **Cleaning:** Hand wash only. Do not machine wash or dry clean. Use mild soap and water for cleaning.
- **Drying:** Always ensure the tent is completely dry before packing it away to prevent mildew and odors.
- **Storage:** Store the tent in a cool, dry place away from direct sunlight.

- **Pole Care:** Inspect poles for damage before and after each use. Replace any cracked or broken poles promptly.

Troubleshooting

If you encounter issues with your tent, consider the following common solutions:

- **Condensation:** Ensure proper ventilation by opening windows and the rear ventilation flap. Condensation is natural and can be reduced with good airflow.
- **Leaks:** Check all seams for proper sealing. If leaks occur, seam sealer can be applied. Ensure the rainfly is correctly positioned and taut.
- **Poles Not Fitting:** Double-check that you are using the correct poles for each section (longer for main tent, shorter for rainfly). Ensure all pole sections are fully connected.
- **Tent Stability:** Make sure all stakes are firmly in the ground and guy lines are properly tensioned to secure the tent against wind.

Warranty & Support

This Coleman tent comes with a **1-YEAR LIMITED WARRANTY**. For warranty claims or product support, please contact Coleman customer service directly. Keep your proof of purchase for any warranty-related inquiries.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07ZHYS73W

More documents and user manuals: **https://manuals.plus/**