Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun 9-030

Braun Silk-épil 9 Flex 9-030 Epilator User Manual

Model: 9-030

1. Introduction

This manual provides essential instructions for the safe and effective use of your Braun Silk-épil 9 Flex 9-030 epilator. This device is designed for efficient hair removal, offering a flexible head for adapting to body contours and various attachments for comprehensive skin care.



Image: The Braun Silk-épil 9 Flex 9-030 epilator, showcasing its flexible head and included accessories, with a woman in the background.

2. Important Safety Information

Read all instructions before using this appliance.

This appliance is provided with a special cord set with an integrated Safety Extra Low Voltage power supply. Do not exchange or manipulate any part of it. When disconnected, the hand-held part of this appliance may be used in a bath or shower.

DANGER: To reduce the risk of electric shock:

1. The charger unit is not for immersion in water or for use in shower.
2. Do not reach for a charger that has fallen into water. Unplug immediately.
3. Do not place, store or charge the appliance where it can fall or be pulled into a tub or sink. Do not place in or drop into water or other liquid.
4. Except when charging, always unplug this appliance from the electrical outlet.
5. Unplug this appliance before cleaning.

6. Do not use an extension cord with this appliance.

WARNING: To reduce the risk of burns, fire, electric shock, or injury to persons:

1. Close supervision is necessary when this appliance is used by, on, or near children or persons with disabilities.
2. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
3. Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or if the power supply has been dropped into water. Return the appliance to a service center for examination and repair.
4. Keep the cord away from heated surfaces.
5. Never drop or insert any object into any opening.
6. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
7. Do not use this appliance with a damaged or broken foil, as serious skin injuries may occur.
8. Always attach plug to appliance first, then to outlet. To disconnect, turn all controls to «off», then remove plug from outlet.
9. When plugging to an electrical outlet outside the USA, use a plug adapter to match the outlet's pin configuration.
10. Caution: The battery used in this device may present a fire or chemical burn hazard if mistreated. Do not disassemble, heat above 100 °C (212 °F) or incinerate.
11. To recharge the battery, only use the detachable power supply provided with this appliance. If the appliance is marked 492-XXXX, only use Braun power supplies coded 492-XXXX.

3. Setup and Initial Use

Before using your Braun Silk-épil 9 Flex 9-030, ensure it is properly charged and the correct attachment is selected.

3.1. Charging the Device

- Charge the device for 1 hour before first use.
- Ensure the device is completely dry before connecting it to the charger.

3.2. Attaching and Changing Heads

The epilator comes with several interchangeable heads. To change a head, press the release button (if applicable) and slide the current head off. Align the new head with the body of the epilator and push until it clicks into place.



Image: The Braun Silk-épil 9 Flex 9-030 epilator body and its various interchangeable heads, including the epilator head, shaver head, and exfoliation brush.

▶ **Watch video online**

Video: A demonstration of unboxing the Braun Silk-épil 9 Flex, showing the device and its accessories.

4. Operating Instructions

The Braun Silk-épil 9 Flex 9-030 can be used wet or dry. For optimal results and reduced discomfort, follow these guidelines.

4.1. Epilation

- Use the epilator on clean, dry skin for best results, or in the shower/bath for a gentler experience.
- Select the appropriate attachment for the area you wish to epilate.
- Press the power button and gently move the epilator against the direction of hair growth.
- For first-time users, allow hair to grow for 3-4 days after shaving to ensure optimal length for epilation.
- Epilate in slow, long strokes to ensure thorough hair removal.

▶ **Watch video online**

Video: A short guide offering 5 top tips for first-time epilator users, including hair length and direction of use.



Image: A close-up view of the flexible head of the Braun Silk-épil 9 Flex epilator, demonstrating its ability to pivot and adapt to body contours.

4.2. Using the Shaver and Trimmer Head

For sensitive areas or quick touch-ups, attach the shaver and trimmer head. This head allows for close shaving and precise trimming.

4.3. Using the Body Exfoliation Brush

Attach the body exfoliation brush to gently exfoliate your skin. Use on dry skin before epilating for smoother results and to help prevent ingrown hairs.



Image: The Braun Silk-épil 9 Flex 9-030 epilator shown with its three primary attachments: the epilator head, the shaver/trimmer head, and the body exfoliation brush.

▶ **Watch video online**

Video: An official product video demonstrating the flexible head, wet & dry use, and the exfoliation and massage attachments of the Braun Silk-épil 9 Flex.

5. Maintenance

Regular cleaning and proper care will extend the life of your epilator and ensure optimal performance.

5.1. Cleaning the Epilator Head

- After each use, rinse the epilator head under running water.
- Use the provided cleaning brush to remove any trapped hairs from the epilation tweezers.
- Ensure the head is completely dry before reattaching or storing.

▶ **Watch video online**

Video: A demonstration of cleaning the Braun Silk-épil 9 Flex epilator head after use, showing how to remove trapped hairs.

5.2. Battery Care

- To maintain battery life, avoid completely draining the battery frequently.
- Store the device in a cool, dry place when not in use.

6. Troubleshooting

If you encounter any issues with your Braun Silk-épil 9 Flex 9-030, refer to the following common solutions:

- **Device not turning on:** Ensure the device is fully charged. Check the charging light indicator.
- **Reduced epilation efficiency:** Ensure the epilator head is clean and free of trapped hairs. Make sure hair is the optimal length (3-4 days growth after shaving).
- **Skin irritation:** Use the epilator in the shower or bath with warm water to reduce discomfort. Apply a soothing body lotion after epilation. Ensure you are epilating against the direction of hair growth.
- **Battery not holding charge:** Over time, rechargeable batteries may degrade. If the battery life significantly decreases, contact Braun customer support for potential replacement options or consider purchasing a new device if outside warranty.

7. Specifications

Feature	Detail
Product Dimensions	10.24 x 2.76 x 7.76 inches
Item Weight	0.94 Pounds (15.04 ounces)
Power Source	Battery Powered (1 Lithium Ion battery included)
Water Resistance Level	Waterproof (Wet & Dry use)
Model Number	9-030
Manufacturer	Procter & Gamble
UPC / GTIN	069055886403

8. Warranty and Support

For warranty information, product registration, or further assistance, please visit the official Braun website or contact their customer support. Keep your proof of purchase for any warranty claims.
Official Braun Website: www.braun.com

© 2024 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the

question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07ZHZJ4X8

More documents and user manuals: **https://manuals.plus/**