Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TRESKO EKATM20

TRESKO 20L 2500W Hot Beverage Dispenser Instruction Manual

Model: EKATM20

Introduction

Thank you for choosing the TRESKO 20L 2500W Hot Beverage Dispenser. This appliance is designed for heating and keeping warm various hot beverages such as mulled wine, punch, tea, or coffee. Constructed from high-quality stainless steel, it ensures a neutral taste and durability. Please read this manual carefully before first use to ensure safe and efficient operation.



Image: The TRESKO Hot Beverage Dispenser in a kitchen setting, demonstrating its sleek design and stainless steel finish.

Safety Instructions

To prevent injury or damage, always observe the following safety precautions:

- Read all instructions before using the appliance.
- This appliance is for household use only. Do not use outdoors or for commercial purposes.
- Ensure the voltage indicated on the appliance matches your local power supply before connecting.
- Do not immerse the appliance, cord, or plug in water or any other liquid.
- Always place the appliance on a stable, heat-resistant, and level surface, away from edges.
- Keep the appliance out of reach of children and pets.
- The exterior surfaces of the appliance become hot during operation. Use the heat-resistant handles and exercise caution when handling.
- Do not fill above the maximum fill line to prevent overflow.
- Unplug the appliance from the power outlet when not in use and before cleaning. Allow it to cool completely before handling or cleaning.
- Do not operate the appliance with a damaged cord or plug, or if it malfunctions or has been damaged in any way.
- **Important:** This appliance is not suitable for heating milk or cocoa, as these can burn and stick to the bottom, causing damage and difficult cleaning.

Product Overview

Familiarize yourself with the components of your TRESKO Hot Beverage Dispenser:

1. **Main Unit:** Stainless steel body with double-walled insulation.
2. **Lid:** Protects from heat and allows for safe transport.
3. **Heat-Resistant Handles:** For safe carrying.
4. **Integrated Tap:** For easy dispensing, with continuous flow option.
5. **Temperature Control Dial:** Adjustable from 30°C to 110°C.
6. **ON/OFF Switch:** Splash-proof for enhanced safety.
7. **Indicator Lights:** Separate lights for 'Heating' (red) and 'Keep Warm' (orange).
8. **Water Level Indicator:** For monitoring the remaining liquid volume.



Image: Front view of the TRESKO Hot Beverage Dispenser, showing the temperature dial, ON/OFF switch, and indicator lights.



Image: A detailed view of the control panel, highlighting the splash-proof ON/OFF switch and the heating/keep warm indicators.



Image: The TRESKO Hot Beverage Dispenser featuring its robust, heat-resistant handle for secure transportation.

Setup

Before using your beverage dispenser for the first time:

1. **Unpack:** Carefully remove all packaging materials and inspect the appliance for any damage.
2. **Clean:** Wash the interior of the dispenser and the lid with warm soapy water. Rinse thoroughly with clean water and dry. Wipe the exterior with a damp cloth.
3. **Placement:** Place the dispenser on a stable, flat, and heat-resistant surface, ensuring adequate ventilation around the unit.
4. **First Use Rinse:** For the first use, fill the dispenser with clean water up to the MAX line. Heat the water to 100°C, then dispense it through the tap. Discard this water. This helps to clean any manufacturing residues.

Operating Instructions

Follow these steps to operate your TRESKO Hot Beverage Dispenser:

1. **Fill:** Ensure the tap is closed. Fill the dispenser with your desired beverage (e.g., mulled wine, tea, coffee) up to the maximum fill line indicated on the water level indicator. Do not overfill.
2. **Secure Lid:** Place the lid securely on the dispenser.
3. **Connect Power:** Plug the power cord into a suitable 230V ~ 50Hz electrical outlet.
4. **Power On:** Flip the ON/OFF switch to the 'ON' position. The red 'Heating' indicator light will illuminate.
5. **Set Temperature:** Turn the temperature control dial to your desired temperature between 30°C and 110°C. The appliance will begin heating.
6. **Heating Process:** The red 'Heating' light will remain on until the set temperature is reached. Once the temperature is achieved, the red light may turn off, and the orange 'Keep Warm' light will illuminate, indicating the appliance is maintaining the temperature. The heating element will cycle on and off to maintain the set

temperature.

7. **Dispense:** To dispense the beverage, open the tap. You can use the tap for continuous flow or for serving individual portions.
8. **After Use:** Once you have finished using the dispenser, turn the ON/OFF switch to the 'OFF' position and unplug the appliance from the power outlet. Allow the appliance to cool down completely before cleaning or storing.



Image: The interior of the dispenser filled with mulled wine and fruit, illustrating its capacity and suitability for various hot beverages.



Image: A close-up view of the integrated tap and the clear water level indicator, allowing for easy monitoring and dispensing.

Maintenance and Cleaning

Regular cleaning ensures the longevity and hygiene of your appliance:

1. **Unplug and Cool:** Always unplug the dispenser and allow it to cool down completely before cleaning.
2. **Interior Cleaning:** Wash the interior with warm water and a mild dish soap. Use a soft sponge or brush to remove any residue. Rinse thoroughly with clean water to ensure no soap residue remains.
3. **Exterior Cleaning:** Wipe the exterior of the dispenser with a damp cloth. Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the stainless steel finish.
4. **Tap Cleaning:** Ensure the tap is clean and free of blockages. Run clean water through it after each use.
5. **Descaling:** If you notice mineral buildup (limescale), descale the appliance regularly using a suitable descaling solution designed for kitchen appliances. Follow the descaling product's instructions carefully.
6. **Storage:** Store the clean and dry appliance in a cool, dry place.
7. **Do Not Immerse:** Never immerse the main unit of the dispenser in water or any other liquid.

Troubleshooting

If you encounter any issues, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not heat.	Not plugged in; ON/OFF switch is off; Temperature dial set too low.	Ensure plug is securely in outlet; Turn ON/OFF switch to 'ON'; Adjust temperature dial to desired setting.
Beverage is not hot enough.	Temperature dial set too low.	Increase the temperature setting on the dial.
Tap is leaking.	Tap not fully closed; Residue in tap mechanism.	Ensure the tap handle is pushed fully closed; Clean the tap thoroughly to remove any blockages.
Appliance overheats.	Overheat protection activated.	Unplug the appliance and allow it to cool down for at least 30 minutes before attempting to use it again. Ensure proper ventilation.

Specifications

Feature	Specification
Brand	TRESKO
Model Number	EKATM20
Capacity	20 Liters
Power	2500 Watts
Voltage	230 Volts
Frequency	50 Hz
Temperature Range	30°C - 110°C
Material	Stainless Steel
Product Dimensions (L x W x H)	29 cm x 29 cm x 53 cm
Cable Length	Approx. 1.25 meters
Special Features	Rapid boiling, Overheat protection, Water level indicator, Double-walled insulation

Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your purchase or contact

your retailer. Keep your proof of purchase for any warranty claims.

© 2024 TRESKO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B081RX953J

More documents and user manuals: **https://manuals.plus/**