Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VECELO KHD-XJM-CD03-BRN

VECELO Corner Computer Desk User Manual

Model: KHD-XJM-CD03-BRN

Brand: VECELO

Introduction

Thank you for purchasing the VECELO Corner Computer Desk. This manual provides detailed instructions for assembly, usage, maintenance, and troubleshooting to ensure optimal performance and longevity of your desk. Please read this manual thoroughly before beginning assembly or use.

Important Safety Information

Please read and understand all safety warnings before assembly and use.

- Ensure not to exceed the maximum weight limit of**200 pounds**. Overloading the desk can lead to structural damage or injury.
- Use caution while placing the L-shaped desk in your room to avoid damage to walls or other furniture.
- Keep all small parts and packaging materials away from children during assembly to prevent choking hazards.
- Assemble the desk on a soft, clean surface to prevent scratches.
- Periodically check all connections and fasteners to ensure they remain tight.

Components List

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

Part	Description	Quantity
A	Main Desktop Panel	1
B	Keyboard Tray	1

Part	Description	Quantity
C	Lower Shelf (Left)	1
D	Lower Shelf (Right)	1
E	Left Frame Leg	1
F	Right Frame Leg	1
G	Keyboard Tray Rails	2
H	Assembly Hardware Kit	1 (Includes screws, bolts, Allen wrench)

Note: The exact appearance of parts may vary slightly from illustrations.

Setup and Assembly

Assembly is required for this product. It is recommended that **one person** performs the assembly. All necessary tools are included.

Preparation:

- Clear a spacious area for assembly.
- Lay out all components on a soft, clean surface (e.g., a carpet or blanket) to prevent scratches.
- Identify all parts using the Components List.

Assembly Steps:

1. **Attach Frame Legs:** Securely attach the Left Frame Leg (E) and Right Frame Leg (F) to the underside of the Main Desktop Panel (A) using the provided hardware from Kit (H). Ensure the legs are oriented correctly for the corner design.
2. **Install Keyboard Tray Rails:** Attach the Keyboard Tray Rails (G) to the designated slots on the underside of the Main Desktop Panel (A) and the Keyboard Tray (B). Ensure they are aligned for smooth operation.
3. **Insert Keyboard Tray:** Slide the Keyboard Tray (B) onto the installed rails (G) until it clicks into place. Test the sliding mechanism to ensure it moves freely.
4. **Attach Lower Shelves:** Fasten the Lower Shelf (Left) (C) and Lower Shelf (Right) (D) to the inner sides of the frame legs using the remaining hardware. These shelves provide additional storage space.
5. **Final Tightening:** Once all components are in place, carefully tighten all screws and bolts. Do not overtighten.
6. **Positioning:** Carefully move the assembled desk to its desired corner location.



Figure 1: Desk Dimensions. This diagram illustrates the overall dimensions of the desk, including the main desktop, keyboard tray, and lower shelves.

Operating and Usage

The VECELO Corner Computer Desk is designed for efficient use of space in home office or study environments.

Main Desktop Surface:

The main desktop provides ample space for a laptop, monitor, or other essential work items. Its corner design allows it to fit snugly into room corners, maximizing usable floor space.



Figure 2: Desk in use with a monitor. This image demonstrates the desk's capacity to hold a computer monitor and other office essentials.



Figure 3: Desk in use with a laptop. This image shows the desk accommodating a laptop setup, highlighting its compact and functional design.

Keyboard Tray:

The smooth-gliding keyboard tray can be pulled out for comfortable typing and pushed in to save space when not in use. It is suitable for most standard keyboards and mice.



Figure 4: Keyboard Tray Extended. A detailed view of the keyboard tray, showing it extended with a keyboard and mouse, ready for use.



Figure 5: Keyboard Tray Mechanism. This image highlights the smooth sliding mechanism of the keyboard tray.

Storage Shelves:

Two open storage shelves are located beneath the main desktop, providing convenient space for books, office supplies, or decorative items. These shelves contribute to the desk's overall functionality and organization.



Figure 6: Lower Storage Shelves. This image illustrates the practical use of the lower shelves for storing various items.

Maintenance

Proper care and maintenance will extend the life of your VECELO Corner Computer Desk.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as they may damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or water damage to the engineered wood.
- **Fasteners:** Periodically check all screws and bolts to ensure they are tight. Retighten if necessary to maintain stability.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the wood finish.
- **Heat and Moisture:** Do not place hot items directly on the desk surface. Use coasters or protective pads for drinks and hot dishes. Avoid excessive moisture.

Troubleshooting

If you encounter any issues with your VECELO Corner Computer Desk, refer to the following common problems and solutions:

- **Desk is Wobbly:**
  - Ensure all screws and bolts are fully tightened.
  - Check that the desk is placed on a level surface. If not, consider using furniture pads or shims to stabilize it.
  - Verify that all frame components are correctly assembled according to the instructions.
- **Keyboard Tray Does Not Slide Smoothly:**
  - Check if the rails are properly aligned and securely attached.
  - Ensure there are no obstructions in the rail mechanism.
  - Clean the rails with a dry cloth to remove any dust or debris.
- **Missing or Damaged Parts:**

  If you find any parts missing or damaged upon opening the package, do not proceed with assembly. Contact VECELO customer support immediately for assistance and replacement parts.

Product Specifications

Feature	Detail
Brand	VECELO
Model Number	KHD-XJM-CD03-BRN
Product Dimensions	29.5"D x 29.5"W x 30"H
Color	Natrual Wood
Style	Rustic
Base Material	Engineered Wood
Top Material Type	Engineered Wood
Special Feature	Compact, Keyboard Tray, Exterior Shelving
Item Weight	18.1 Kilograms
Maximum Weight Recommendation	200 Pounds
Assembly Required	Yes (Recommended 1 person)
Includes All Assembly Tools	Yes

Feature	Detail
Number Of Shelves	2

Warranty and Support

Warranty Information:

This VECELO product comes with a **Limited Warranty**. The manufacturer provides a **3-Year Warranty** covering parts and labor for defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

Customer Support:

For any questions, concerns, or assistance with assembly, missing parts, or warranty claims, please contact VECELO customer support. Refer to the contact information provided with your product packaging or visit the official VECELO website for support details.
You can also visit the VECELO Store on Amazon for more information and product updates.

© 2023 VECELO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0828PZ53Y

More documents and user manuals: **https://manuals.plus/**