Aonerex New Maps of North America

Aonerex 7-Inch GPS Navigation System User Manual

Model: New Maps of North America

1. Introduction

This manual provides essential instructions for the setup, operation, and maintenance of your Aonerex 7-inch GPS Navigation System. Please read this manual thoroughly to ensure proper use and to maximize the device's features.

2. Package Contents

Verify that all items listed below are included in your package:

- Aonerex 7-inch GPS Navigation Device
- Car Charger
- USB Cable
- Suction Cup Mount
- Clip Holder
- User Manual (this document)
- Sunshade

Figure 2.1: Included accessories with the Aonerex GPS Navigation System.

3. Product Overview

The Aonerex GPS Navigation System features a 7-inch high-brightness touch screen for clear visibility. It is designed for ease of use with intuitive controls and multiple connectivity options.

Figure 3.1: Aonerex 7-inch GPS Navigation System.

3.1 Device Ports and Buttons

The device includes several ports for connectivity and expansion:

- **Headphone Jack:** For private audio output.
- **SD Card Slot:** For additional storage or map data.
- **USB-C Port:** For charging and data transfer.

Figure 3.2: Side view of the GPS device highlighting connectivity ports.

4. Setup and Installation

4.1 Attaching the Mount

1. Connect the clip holder to the suction cup mount. Ensure it clicks securely into place.
2. Attach the GPS device to the clip holder by gently sliding it until it snaps into position.
3. Choose a suitable location on your car's windshield or dashboard. Ensure the surface is clean and dry.
4. Press the suction cup firmly against the chosen surface and push down the lever on the mount to create a strong vacuum seal.
5. Adjust the angle of the device for optimal viewing.

Figure 4.1: GPS device installed in a vehicle.

4.2 Installing the Sunshade

The included sunshade helps reduce glare on the screen, improving visibility in bright conditions.

1. Identify the four prongs on the sunshade.
2. Align the prongs with the corresponding slots on the back of the GPS device.
3. Gently push the prongs into the slots and slide them to lock the sunshade into place.

Figure 4.2: Sunshade attached to the GPS device.

5. Basic Operation

5.1 Powering On/Off

Press and hold the power button located on the side of the device to turn it on or off. The Aonerex logo will appear during startup.

5.2 Main Menu

Upon startup, the main menu will display various options for navigation, settings, and other functions. The touch screen interface allows for easy selection.

Figure 5.1: Main menu interface.

6. Navigation Features

The Aonerex GPS provides comprehensive navigation capabilities with detailed maps and intelligent routing.

6.1 Destination Input

You can search for destinations using various methods:

- **Postcode:** Enter the postal code of your destination.
- **Address:** Input the street address.
- **Coordinates:** Use geographical coordinates for precise locations.
- **Favorites:** Select from your saved favorite locations.
- **Points of Interest (POI):** Search for nearby gas stations, restaurants, parking, and accommodation.



Figure 6.1: Points of Interest (POI) search options.

6.2 Route Planning

The device offers multiple route options to suit your preferences:

- **Fast:** Prioritizes the quickest route.
- **Green:** Focuses on fuel efficiency.
- **Short:** Selects the shortest distance.
- **Easy:** Avoids complex turns and highways where possible.

Figure 6.2: 3D map view with active navigation.

6.3 Voice Guidance and Warnings

The system provides clear voice instructions and alerts for a safer driving experience.

- **Street Names Broadcast:** Announces street names for upcoming turns.
- **Current Speed and Active Lane Assistant:** Displays current speed and guides you to the correct lane.
- **Speed Camera Alerts:** Provides intelligent warnings for speed cameras.
- **Sound Warning:** Alerts for speeding and other critical events.
- **Traffic Light, Speed Limit, Height Limit Reminders:** Visual and audio cues for important road signs.

Figure 6.3: Multilingual Intelligent Voice Assistant.

Figure 6.4: Various safety reminders displayed by the GPS.

6.4 Vehicle Modes and Truck Routing

The Aonerex GPS supports multiple vehicle types, including a professional truck mode that allows for custom vehicle parameters.

- **Multiple Vehicle Modes:** Select from Car, Truck, Lorry, RV, Hiking, or Bus modes for optimized routing.
- **Professional Truck Route Planning:** Input specific vehicle dimensions (length, width, height), weight, and

number of axles to ensure routes are suitable for your truck, avoiding restricted roads or low bridges.

Figure 6.5: Professional Truck Mode settings.

Figure 6.6: Multiple vehicle modes supported by the GPS.

7. Map Updates

The Aonerex GPS Navigation System comes with pre-installed North American maps and offers free lifetime map updates.

7.1 Updating Maps

Map updates are typically released annually (March-April). Devices purchased after April each year usually have the latest maps pre-installed.

- Refer to page 9 of the user manual (if a physical copy is provided) for detailed instructions on map updates.
- You can update maps for various regions including Europe, Australia, Africa, and South America.

Figure 7.1: Map update process for the GPS device.

8. Settings

Access the 'Settings' menu from the main screen to customize your device.

- **Volume:** Adjust audio output levels.
- **Backlight:** Modify screen brightness.
- **Language:** Select your preferred language for the interface and voice guidance.
- **System Info:** View device information and software version.
- **Date/Time:** Set or synchronize date and time.
- **USB:** Configure USB connection options (e.g., Mass Storage).
- **FM Transmitter:** Use FM broadcast to transfer GPS audio to your car's radio.

9. Troubleshooting

9.1 Poor or No Satellite Signal

GPS devices rely on a clear line of sight to satellites. Signal reception can be affected by:

- **Tunnels:** Signal loss inside tunnels.
- **Urban Canyons:** Tall buildings in cities can obstruct signals.
- **Dense Forest Areas:** Heavy tree cover can interfere.
- **Indoors:** GPS signals are typically unavailable inside buildings.
- **Bad Weather:** Severe weather conditions (snow, rain, heavy clouds) can weaken signals.
- **Under Bridges:** Obstruction from overhead structures.

If you experience signal issues, move to an open area with a clear view of the sky.

Figure 9.1: Locations that may cause GPS signal interference.

9.2 Device Not Responding

If the device becomes unresponsive, perform a soft reset by pressing the reset button (usually a small pinhole) with a thin object like a paperclip.

10. Specifications

Feature	Detail
Item Weight	1.61 pounds
Product Dimensions	6.3 x 4.3 x 4.7 inches
Item Model Number	New Maps of North America
Batteries	1 Lithium Ion battery required (included)
Display Size	7 Inches
Battery Life	2 Hours (on internal battery)
Voice Command	Touchscreen
Vehicle Service Type	Truck
Special Feature	Latest Maps, Lifetime Maps Update, Touchscreen, Voice Navigation
Connectivity Technology	USB
Map Type	Australia, Europe, North America

Resolution	800 x 480

11. Warranty and Support

The Aonerex GPS Navigation System comes with a **2-Year Warranty**. For technical support or warranty claims, please refer to the contact information provided in your purchase documentation or visit the official Aonerex website.