Elook UsElcbaB0101

Elook Bluetooth Cassette Adapter EK001 User Manual

MODEL: USELCBAB0101

This manual provides instructions for the Elook Bluetooth Cassette Adapter EK001.

1. Introduction

The Elook Bluetooth Cassette Adapter EK001 is designed to bring modern Bluetooth audio streaming to vintage car cassette players and other cassette-enabled audio systems. This device allows you to connect your Bluetooth-enabled smartphone, tablet, or MP3 player to your existing cassette deck, enabling wireless audio playback.

Image: The Elook Bluetooth Cassette Adapter EK001, a black cassette-shaped device with the Elook logo and model number.

2. Product Overview

Familiarize yourself with the components of your Elook Bluetooth Cassette Adapter.

Image: Close-up view of the Elook Bluetooth Cassette Adapter highlighting its key components: Micro USB Charging Port, Power Button, and LED Indicator.

1. **Micro USB Charging Port:** Used for charging the internal battery of the adapter.
2. **Power Button (On/Off):** Activates or deactivates the device.
3. **LED Indicator:** Provides visual feedback on the device's status (power, pairing, battery).

The adapter features Bluetooth 5.0 for stable connections and is designed for high-fidelity stereo sound output.

Image: Illustration emphasizing the Hi-Fi sound capability and the stereo output converter within the cassette adapter.

3. Specifications

Brand	Elook
Model Number	UsElcbaB0101 (EK001)
Bluetooth Version	5.0
Compatible Devices	MP3 Player, Tablet, Smartphone, Car Audio Systems, Cassette Players
Connector Type	Bluetooth
Color	Black
Item Weight	2.08 ounces
Package Dimensions	5.51 x 3.54 x 0.67 inches
Battery	1 Lithium Metal battery required
Play Time	Up to 12 hours

Wireless Range	Up to 33 feet (10 meters)

4. Setup

4.1 Charging the Adapter

Before first use, fully charge the Elook Bluetooth Cassette Adapter.

- Connect the provided Micro USB cable to the charging port on the adapter.
- Connect the other end of the USB cable to a standard USB power source (e.g., car charger, wall adapter, computer USB port).
- The LED indicator will show the charging status. A full charge typically takes about an hour.

4.2 Pairing with a Bluetooth Device

Follow these steps to pair your adapter with your smartphone or other Bluetooth audio source:

- **Power On:** Press and hold the Power Button on the adapter until the LED indicator begins to flash red and blue alternately. This indicates the adapter is in pairing mode.
- **Activate Bluetooth:** On your audio device (e.g., smartphone), go to the Bluetooth settings and ensure Bluetooth is enabled.
- **Select Device:** Search for available Bluetooth devices. You should see "EK001" or a similar name appear in the list. Select it to connect.
- **Confirm Pairing:** Once successfully paired, the LED indicator on the adapter will turn solid blue.

The adapter supports connection to any device equipped with Bluetooth 5.0.

Image: Diagram illustrating the broad compatibility of the Elook Bluetooth Cassette Adapter with devices such as phones, cars, tablets, computers, and cassette players.

5. Operating Instructions

5.1 Inserting into Cassette Player

- Ensure the adapter is powered on and successfully paired with your audio device.
- Insert the Elook Bluetooth Cassette Adapter into your car's cassette deck or home cassette player, just like a regular audio cassette.
- The cassette player should automatically engage the adapter. If not, press the "Play" button on your cassette player.

5.2 Playing Audio

- Once the adapter is in the cassette player and paired, begin playing audio from your connected Bluetooth device.
- Adjust the volume using both your Bluetooth device and the cassette player's volume controls for optimal sound.

Image: The Elook Bluetooth Cassette Adapter positioned next to a smartphone, illustrating its wireless connection and key features like Bluetooth 5.0 and long battery life.

5.3 Automatic Power Off

The receiver will automatically turn off within 5 minutes if it remains disconnected from any Bluetooth device, conserving battery life.

Image: A collage demonstrating the 'Plug and Play' functionality of the Elook Bluetooth Cassette Adapter, showing its use in a car, with a boombox, and connected to various personal devices.

6. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the adapter. Avoid using liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge it regularly, even if not in constant use.

7. Troubleshooting

Problem	Possible Cause	Solution
No power/Device won't turn on.	Battery is discharged.	Charge the adapter using the Micro USB cable.

Cannot pair with Bluetooth device.	Adapter not in pairing mode; Bluetooth on source device is off or already connected to another device.	Ensure adapter LED flashes red/blue. Turn off and on Bluetooth on your source device. Forget previous connections if necessary.
No sound or low volume.	Volume levels too low on either device; adapter not fully inserted; cassette player not in play mode.	Increase volume on both your Bluetooth device and the cassette player. Ensure the adapter is fully inserted and the cassette player is set to play.
Sound quality is poor or distorted.	Interference; old cassette player head; adapter not seated correctly.	Move closer to the adapter to reduce interference. Ensure the adapter is properly inserted. The quality of the cassette player's head can affect sound.
Adapter automatically turns off.	No Bluetooth connection for 5 minutes.	This is normal behavior to save battery. Re-pair if needed.

LED Indicator Status:

- **Off state:** The light is off (device powered off or insufficient power).
- **Turn on pairing:** Red and blue lights flash alternately.
- **Pairing completed:** Blue light is on.
- **Insufficient power:** Red light is on.

8. Warranty and Support

Elook provides a **12-month replacement guarantee** for this product. If you encounter any issues or have questions, please contact the Elook customer service team. They are available to assist with product inquiries and support.
For further assistance, please refer to the contact information provided with your purchase or visit the official Elook website.

© 2025 Elook. All rights reserved.