## EVER ADVANCED EU-FS-97818

# EVER ADVANCED Camping Stool User Manual

Model: EU-FS-97818

## 1. Introduction

Thank you for choosing the EVER ADVANCED Camping Stool. This manual provides essential information for the safe and effective use of your new portable stool. Designed for outdoor enthusiasts, this lightweight and stable tripod stool offers convenient seating for various activities such as camping, hiking, fishing, and more. Please read these instructions carefully before use and retain them for future reference.

Figure 1: EVER ADVANCED Camping Stools in use by a lake.

## 2. Safety Information

To ensure safe operation and prevent injury or damage, please observe the following safety guidelines:

- **Maximum Weight Capacity:** Do not exceed the maximum load capacity of 102 kg (approximately 225 lbs). Overloading can cause the stool to collapse, leading to injury.
- **Stable Surface:** Always place the stool on a firm, level, and stable surface. Avoid uneven ground, slopes, or slippery areas to prevent tipping.
- **Proper Use:** This stool is designed for sitting only. Do not stand on the stool, use it as a step ladder, or for any purpose other than its intended use.
- **Children:** Keep children under supervision when near or using the stool.
- **Heat Sources:** Keep the stool away from open flames, heaters, or other heat sources to prevent damage to materials.
- **Inspection:** Before each use, inspect the stool for any signs of damage, wear, or loose components. Do not use if damaged.

## 3. Setup Instructions

The EVER ADVANCED Camping Stool is designed for quick and easy setup.

1. Remove the stool from its carrying strap or storage bag.
2. Hold the top of the stool and allow the legs to unfold downwards.
3. Gently pull the legs apart until they are fully extended and locked into position. Ensure all three legs are spread evenly to form a stable tripod base.
4. Verify that the fabric seat is taut and securely attached to the frame.

Figure 2: Stool dimensions and folded state for setup reference.




Figure 3: Detail of the stool's stable joint construction.

To fold the stool for storage or transport, simply push the legs together until they collapse. Secure with the integrated strap.

## 4. Operating Instructions

Once the stool is properly set up on a stable surface, it is ready for use.

- Sit gently onto the center of the stool's fabric seat.
- Ensure your weight is distributed evenly.
- The stool is ideal for providing a comfortable, elevated seat during outdoor activities such as camping, hiking breaks, fishing, or waiting in lines. Its tall design (53.3 cm / 20.98 inches) allows for easier standing up compared to lower stools.

Figure 4: Stool in use during a fishing trip.

Figure 5: Benefit of the tall stool design for comfort.

Figure 6: Portability of the folded stool with a strapping system.

## 5. Maintenance

Proper maintenance will extend the life of your EVER ADVANCED Camping Stool.

- **Cleaning:** Wipe the frame and fabric with a dry cloth to remove dirt and debris. For stubborn stains on the fabric, a damp cloth with mild soap can be used, followed by air drying.
- **Drying:** Ensure the stool is completely dry before folding and storing to prevent mildew and corrosion.
- **Storage:** Store the stool in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically check all joints, rivets, and fabric for any signs of wear, damage, or loosening. Tighten any loose screws if applicable (though this model is primarily riveted).

## 6. Troubleshooting

If you encounter issues with your camping stool, refer to the following common problems and solutions:

- **Stool feels unstable:**
  - Ensure all three legs are fully extended and spread evenly.
  - Verify the stool is placed on a flat, firm surface.

    - Check for any obstructions under the legs.
- **Difficulty folding/unfolding:**
    - Ensure no fabric or debris is caught in the folding mechanism.
    - Apply gentle, even pressure when folding or unfolding.
- **Damaged fabric or frame:**
    - Discontinue use immediately if any structural components are bent, cracked, or broken.
    - Do not attempt to repair major structural damage yourself. Contact customer support.

## 7. Specifications

| Feature | Detail |
|---|---|
| Model Number | EU-FS-97818 |
| Brand | EVER ADVANCED |
| Color | Grey |
| Product Dimensions (Unfolded) | 38.9 cm (W) x 53.3 cm (H) / 15.31"D x 15.31"W x 20.98"H |
| Transport Dimensions (Folded) | 70 cm (L) x 10.2 cm (W) x 9 cm (H) |
| Item Weight | 1 kg / 1.98 pounds |
| Maximum Load Capacity | 102 kg (approximately 225 lbs) |
| Frame Material | Alloy Steel |
| Seat Material Type | Alloy Steel (frame support for seat) |
| Product Care Instructions | Wipe with Dry Cloth |
| Assembly Required | No |

## 8. Warranty and Support

For specific warranty information regarding your EVER ADVANCED Camping Stool, please refer to the documentation provided at the time of purchase or contact your retailer.
For further assistance or inquiries, you may visit the official EVER ADVANCED store:EVER ADVANCED Store on Amazon.

© 2026 EVER ADVANCED. All rights reserved.