Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Skullcandy S2TVW-N743

Skullcandy Sesh Evo Wireless Earbuds User Manual

Model: S2TVW-N743

Introduction

The Skullcandy Sesh Evo In-Ear Wireless Earbuds offer a seamless audio experience with up to 24 hours of total battery life. Designed for convenience and durability, these earbuds feature automatic pairing, intuitive controls, and resistance to water, sweat, and dust. Integrated Tile technology helps you locate your earbuds if they are misplaced. This manual provides essential information for setting up, operating, and maintaining your Sesh Evo earbuds.

What's in the Box

- Skullcandy Sesh Evo Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable
- Ear Gels (various sizes)
- User Manual



Image: Skullcandy Sesh Evo earbuds and their charging case, showing the complete product package.

Setup

Initial Charging

Before first use, fully charge your Sesh Evo earbuds and charging case.

1. Place both earbuds into the charging case.
2. Connect the USB-C charging cable to the port on the back of the charging case and plug the other end into a USB power source.
3. The LED indicators on the case will show charging status. A full charge takes approximately 3 hours for the case and earbuds.



Image: The Skullcandy Sesh Evo charging case open with both earbuds inside, displaying the LED charging indicators.

Pairing Your Earbuds

The Sesh Evo earbuds are designed for easy pairing.

1. When you power on the earbuds for the first time, they will automatically enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for "Sesh Evo" in the list of available devices.
3. Select "Sesh Evo" to connect. Once paired, the earbuds will instantly connect to the last used device when removed from the case.



Image: The Skullcandy Sesh Evo charging case opened, revealing the earbuds nestled in their charging slots.

Operating Your Earbuds

Controls

The Sesh Evo earbuds feature intuitive controls directly on the earbuds themselves.

Earbud Control Functions

Action	Function
Single Press (Left or Right)	Play/Pause Music, Answer/End Call
Double Press (Left)	Volume Down
Double Press (Right)	Volume Up
Triple Press (Left)	Track Back
Triple Press (Right)	Track Forward
Press and Hold (2 seconds)	Activate Voice Assistant

You can also select different EQ modes directly from the earbuds. Refer to the full user manual (PDF) for detailed instructions on EQ mode selection.

Solo Mode

Sesh Evo features a solo mode, allowing you to use either earbud independently. This is useful for taking calls or listening to music while keeping one ear free. Simply remove one earbud from the case, and it will connect automatically.

Battery Life and Charging

Your Sesh Evo earbuds provide up to 24 hours of total battery life.

- **Earbuds:** Up to 5 hours of playback on a single charge.
- **Charging Case:** Provides an additional 19 hours of charge, allowing you to recharge the earbuds approximately 3 times.
- **Rapid Charge:** A quick 10-minute charge provides an extra 2 hours of listening time.



Image: The closed Skullcandy Sesh Evo charging case, showing its compact design and LED indicators.

Maintenance

Water Resistance

Sesh Evo boasts an IP55 rating, making them resistant to sweat, water, and dust. This means they can withstand light rain and heavy workouts without issue. However, they are not designed for submersion in water.

Cleaning Your Earbuds

To ensure optimal performance and hygiene, regularly clean your earbuds:

- Gently wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear gels and clean them with mild soap and water, then dry thoroughly before reattaching.
- Use a dry cotton swab or a small, soft brush to carefully clean the speaker mesh and charging contacts.



Image: A side view of the Skullcandy Sesh Evo earbuds, highlighting their ergonomic shape and ear gel.

Troubleshooting

Finding Misplaced Earbuds with Tile

Sesh Evo earbuds come with built-in Tile technology. If you misplace an earbud, you can use the Tile app to locate it.

1. Download the Tile app from your device's app store.
2. Follow the in-app instructions to activate Tile on your Sesh Evo earbuds.
3. Once activated, you can "ring" your earbuds from the app to hear them, or view their last known location on a map.

Common Issues and Solutions

- **No Sound:** Ensure earbuds are charged, connected to your device, and volume is up.
- **Pairing Issues:** Turn off Bluetooth on other nearby devices. Try resetting the earbuds (refer to the full user manual for reset instructions).
- **One Earbud Not Working:** Ensure both earbuds are charged and properly seated in the case. Try re-pairing.

For more detailed troubleshooting steps, please refer to the officialTroubleshooting Guide (PDF).

Specifications

Skullcandy Sesh Evo Specifications

Feature	Detail
Model Name	Sesh Evo
Connectivity Technology	Bluetooth 5.0, Truewireless

Feature	Detail
Noise Control	Sound Isolation
Water Resistance Level	IP55 (Water Resistant)
Battery Life (Earbuds)	Up to 5 hours
Total Battery Life (with Case)	Up to 24 hours
Charging Time	Approx. 3 hours (full charge)
Charging Interface	USB-C
Control Type	Media Control, Voice
Ear Placement	In Ear
Item Weight	0.005 ounces (earbuds)
Material	Plastic

Warranty Information

The Skullcandy Sesh Evo earbuds come with a **1-year US warranty**. This warranty covers manufacturing defects and ensures your product performs as expected under normal use. For detailed warranty terms and conditions, please refer to the official Warranty Document (PDF).
Additionally, Skullcandy offers a **Fearless Use Promise**: if anything ever happens to a single earbud or the case, you can replace it at a discount. Contact Skullcandy customer support for more information.

Support

For further assistance, please consult the following resources:

- Official User Guide (PDF): Link to User Guide
- Troubleshooting Guide (PDF): Link to Troubleshooting Guide
- Skullcandy Support Website: Visit the official Skullcandy website for FAQs, support articles, and contact information.

© 2024 Skullcandy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0857K6QW7

More documents and user manuals: **https://manuals.plus/**