Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Z-Lite 804-1S-MB

Z-Lite 1 Light Wall Sconce Instruction Manual

Model: 804-1S-MB | Brand: Z-Lite

Introduction

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Z-Lite 1 Light Wall Sconce (Model 804-1S-MB). Please read these instructions thoroughly before beginning installation and retain them for future reference. This wall sconce is designed to provide ambient lighting and features a matte black finish steel and crystal construction with a white fabric shade.



Figure 1: Z-Lite 1 Light Wall Sconce (Model 804-1S-MB)

Important Safety Information

WARNING: To reduce the risk of fire, electric shock, or personal injury, always follow these basic precautions:

- Always disconnect power at the main circuit breaker before installation or servicing.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC).
- Consult a qualified electrician if you are unsure about the installation process.
- This product is intended for indoor use only.
- Do not exceed the maximum wattage specified for the light bulb (60 watts).
- Ensure the fixture is securely mounted to a structural element.
- Please check your local laws before purchasing this product.

Package Contents

Carefully unpack your new light fixture and lay out all parts on a clear area. Ensure all components listed below are present before discarding packaging materials.

- Wall Sconce Fixture (1)
- White Fabric Shade (1)
- Mounting Hardware Kit (1)
- Instruction Manual (1)




Figure 2: Product Dimensions (25.50x7.00x5.50 inches)

Installation Instructions

This fixture is designed for surface mount installation. Assembly is required.

1. **Turn Off Power:** Before starting installation, ensure the power is turned off at the circuit breaker or fuse box to prevent electrical shock.
2. **Prepare Mounting Surface:** Identify the desired location for the wall sconce. Ensure the electrical box is securely mounted in the wall.
3. **Attach Mounting Plate:** Secure the mounting plate (included in hardware kit) to the electrical box using the provided screws.
4. **Make Electrical Connections:**
    - Connect the fixture's black wire to the house's black (hot) wire.
    - Connect the fixture's white wire to the house's white (neutral) wire.
    - Connect the fixture's ground wire to the house's ground wire (bare copper or green).
    - Secure all wire connections with wire nuts (included).
5. **Mount Fixture:** Carefully tuck all wires into the electrical box. Align the fixture's base with the mounting plate and secure it with the provided screws.
6. **Install Light Bulb:** Insert one E26 Medium base candelabra light bulb (not included) into the socket. Do not exceed 60 watts.
7. **Attach Shade:** Secure the white fabric shade to the fixture according to the specific design.
8. **Restore Power:** Once installation is complete, turn the power back on at the main circuit breaker.



Figure 3: Detail of the crystal embellishment

Operating Instructions

The Z-Lite Wall Sconce is designed for simple operation.

- **Power On/Off:** Control the light fixture using your standard wall switch.
- **Dimming Function:** This fixture is dimmable. If connected to a compatible dimmer switch (included components mention "Dimmer"), you can adjust the light intensity. The control method is touch, implying the dimmer switch itself might be touch-sensitive or the fixture is compatible with touch-sensitive dimmers.
- **Light Output:** The fixture provides white light with a brightness of approximately 800 lumens, depending on the installed bulb.

Maintenance

Regular maintenance will help preserve the appearance and functionality of your wall sconce.

- **Cleaning:** To clean the fixture, wipe it with a soft, dry cloth. Do not use abrasive cleaners, polishes, or solvents as they may damage the finish.
- **Bulb Replacement:** Ensure power is off before replacing the light bulb. Allow the bulb to cool completely before touching. Replace with an E26 Medium base candelabra bulb, not exceeding 60 watts.

Troubleshooting

If your wall sconce is not functioning correctly, refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture. Loose wire connections. Defective light bulb.	Check circuit breaker/fuse. Verify all wire connections are secure (turn off power first). Replace light bulb.
Light flickers or dims improperly.	Incorrect dimmer switch. Loose bulb or wiring.	Ensure dimmer is compatible with LED/CFL bulbs if used. Tighten bulb; check wiring connections (turn off power first).

Specifications

Feature	Detail
Brand	Z-Lite
Model Number	804-1S-MB
Color	Matte Black
Material	Steel + Crystal
Style	Ava
Light Fixture Form	Sconce
Room Type	Bathroom, Bedroom
Indoor/Outdoor Usage	Indoor

Feature	Detail
Power Source	Corded Electric
Installation Type	Surface Mount
Special Feature	Dimmable
Control Method	Touch
Light Source Type	Candelabra
Finish Type	Matte Black
Shade Material	Glass
Number of Light Sources	1
Voltage	120 Volts
Light Color	White
Included Components	Dimmer
Embellishment	Crystal
Wattage	60 watts
Bulb Base	E26 Medium
Switch Type	Dimmer
Brightness	800 lumen
Assembly Required	Yes
Item Weight	1 Pounds
Dimensions (LxWxH)	25.50x7.00x5.50 inches

Warranty and Support

This Z-Lite product comes with a**Limited Manufacturer Warranty**. For specific details regarding warranty coverage and claims, please refer to the documentation included with your purchase or contact Z-Lite customer support directly. For technical assistance or further inquiries, please visit the Z-Lite official website or contact their customer service department. Keep your model number (804-1S-MB) and purchase information readily available when seeking support.

© 2024 Z-Lite. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B085FQWQNM

More documents and user manuals: **https://manuals.plus/**