Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Panasonic SR-HVD1090-T

Panasonic IH Rice Cooker (5.5-cup) SR-HVD1090-T Instruction Manual

Model: SR-HVD1090-T | Brand: Panasonic

Introduction Safety Information Package Contents Product Overview Setup Operating Instructions Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

Thank you for purchasing the Panasonic IH Rice Cooker SR-HVD1090-T. This appliance is designed to provide efficient and delicious rice cooking. It features a durable Diamond Hard Coat inner pot with a 3-year warranty and a "New Brown Rice Course" for optimized cooking times. Please read this manual thoroughly before use to ensure safe operation and optimal performance. Keep this manual for future reference.

2. Safety Information

WARNING: Failure to follow these safety instructions could result in electric shock, fire, or serious injury.

- Always connect the appliance to a grounded power outlet.
- Do not immerse the main unit in water or other liquids.
- Do not touch hot surfaces. Use handles or knobs. Steam is extremely hot.
- Keep out of reach of children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Ensure proper ventilation around the appliance during operation.
- Only use accessories recommended by the manufacturer.

3. Package Contents

Verify that all items are present in the package:

- IH Rice Cooker Main Unit (SR-HVD1090-T)
- Inner Pot (with Diamond Hard Coat)

- Measuring Cup
- Rice Spatula
- Power Cord
- Instruction Manual (this document)

4. Product Overview



Figure 1: Front view of the Panasonic IH Rice Cooker SR-HVD1090-T. This image shows the main unit with its control panel and lid.

Familiarize yourself with the main components of your rice cooker:

- **Main Unit:** Houses the IH heating element and control panel.
- **Inner Pot:** The removable pot where rice is cooked. Features a Diamond Hard Coat for durability.
- **Lid:** Covers the inner pot during cooking. Contains a steam vent.
- **Control Panel:** Located on the front, with buttons for various cooking modes, start/cancel, and timer settings.

- **Steam Vent:** Releases steam during cooking. Do not block.

5. Setup

1. **Unpack:** Carefully remove all packaging materials from the rice cooker and its accessories.
2. **Clean:** Wash the inner pot, measuring cup, and rice spatula with warm soapy water. Rinse thoroughly and dry. Wipe the exterior of the main unit with a damp cloth.
3. **Placement:** Place the rice cooker on a stable, level surface away from direct sunlight, heat sources, and moisture. Ensure there is adequate space around the unit for ventilation.
4. **Connect Power:** Insert the power cord firmly into the rice cooker's power inlet, then plug the other end into a grounded electrical outlet.

6. Operating Instructions

6.1 Basic Rice Cooking

1. **Measure Rice:** Use the provided measuring cup to measure the desired amount of rice.
2. **Wash Rice:** Wash the rice thoroughly until the water runs clear.
3. **Add Water:** Place the washed rice into the inner pot. Add water up to the corresponding water level mark inside the pot for the type and quantity of rice. For example, for 3 cups of white rice, fill to the "White Rice 3" mark.
4. **Place Inner Pot:** Ensure the inner pot is dry on the outside, then place it into the main unit. Close the lid securely.
5. **Select Mode:** Press the "Menu" button to select the desired cooking mode (e.g., White Rice, Brown Rice, Quick Cook).
6. **Start Cooking:** Press the "Start" button. The cooking indicator will light up.
7. **Completion:** Once cooking is complete, the rice cooker will beep and automatically switch to "Keep Warm" mode.
8. **Serve:** Open the lid, stir the rice gently with the rice spatula, and serve.

6.2 Using the "New Brown Rice Course"

The "New Brown Rice Course" is designed to cook brown rice faster than traditional methods while maintaining optimal texture and flavor.

1. Follow steps 1-3 from "Basic Rice Cooking," ensuring you use the water level marks for "Brown Rice."
2. Place the inner pot and close the lid.
3. Press the "Menu" button until "New Brown Rice Course" is selected.
4. Press the "Start" button to begin cooking.

6.3 Keep Warm Function

The rice cooker automatically switches to "Keep Warm" mode after cooking. This function keeps the rice warm and ready to serve. For best results, do not keep rice warm for extended periods (e.g., more than 12 hours) to prevent drying or discoloration.

7. Maintenance

Regular cleaning ensures the longevity and hygienic operation of your rice cooker.

7.1 Cleaning the Inner Pot

- After each use, remove the inner pot and wash it with warm water and a soft sponge.
- Do not use abrasive cleaners, metal brushes, or harsh detergents, as these can damage the Diamond Hard Coat.
- Rinse thoroughly and dry completely before storing or next use.

7.2 Cleaning the Lid and Steam Vent

- The inner lid may be removable for cleaning. Refer to the diagrams in the full manual for specific instructions on detaching and reattaching.
- Wash the inner lid and steam vent components with warm soapy water.
- Ensure all rice residue is removed from the steam vent to prevent blockages.
- Dry all parts completely before reassembling.

7.3 Cleaning the Main Unit Exterior

- Wipe the exterior of the main unit with a soft, damp cloth.
- Do not use abrasive cleaners or immerse the main unit in water.
- Ensure the power cord is unplugged before cleaning.

8. Troubleshooting

If you encounter issues, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Rice is too hard or undercooked.	Insufficient water; old rice; incorrect cooking mode.	Add more water next time; soak old rice longer; select appropriate cooking mode.
Rice is too soft or mushy.	Too much water; new rice.	Reduce water next time; new rice requires less water.
Rice cooker does not start.	Power cord not plugged in; inner pot not correctly placed; lid not closed.	Check power connection; ensure inner pot is seated properly; close lid firmly.
Odor during cooking.	First use (normal); food residue on heating plate or lid.	The odor should dissipate after a few uses. Clean the heating plate and lid thoroughly.

If the problem persists after trying these solutions, please contact customer support.

9. Specifications

Brand	Panasonic
Model Number	SR-HVD1090-T
Capacity	5.5 cups (approx. 1.0 Liter)
Dimensions (W x D x H)	25.5 x 36.6 x 21 cm
Package Size	40.2 x 29.6 x 25 cm
Package Weight	4.66 kg

Power Source	Power cord
Inner Pot Coating	Diamond Hard Coat
Care Instructions	Hand wash (inner pot)
Special Features	Cooking options, New Brown Rice Course
ASIN	B085NL7BFZ
First Available on Amazon.co.jp	March 9, 2020

10. Warranty and Support

The inner pot of your Panasonic IH Rice Cooker SR-HVD1090-T is covered by a 3-year warranty from the date of purchase. For other components, standard manufacturer warranty terms apply. Please retain your proof of purchase for warranty claims.

For technical support, service, or warranty inquiries, please contact Panasonic customer service in your region. Contact information can typically be found on the official Panasonic website or on the product packaging.

You can also visit the official Panasonic store on Amazon for more product information:Panasonic Store on Amazon.co.jp

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B085NL7BFZ

More documents and user manuals: **https://manuals.plus/**