Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Cellet XG01

Cellet Wireless Bluetooth Earbuds Model XG01 User Manual

Model: XG01 | Brand: Cellet

1. Introduction

Thank you for choosing the Cellet Wireless Bluetooth Earbuds Model XG01. These earbuds are designed to provide a high-quality audio experience with the convenience of wireless connectivity. This manual will guide you through the setup, operation, and maintenance of your new earbuds. Please read it carefully before use and retain it for future reference.



Image 1.1: Cellet Wireless Bluetooth Earbuds with their charging case. The image shows the compact design of the earbuds and the portable charging case.

2. Package Contents

Please check the package contents to ensure all items are present:

- Cellet Wireless Bluetooth Earbuds (Left and Right)
- Portable Charging Case
- USB-C Charging Cable
- User Manual
- Ear Tips (Small, Medium, Large)



Image 2.1: Visual representation of all items included in the Cellet Wireless Bluetooth Earbuds package, including the earbuds, charging case, user manual, USB-C cable, and various ear tip sizes.

3. Product Overview

Familiarize yourself with the components and controls of your earbuds.



Image 3.1: Diagram illustrating the multi-function buttons and LED power indicators on the Cellet earbuds and charging case. The image highlights the left and right earbud buttons and the charging case's LED.

- **Multi-function Button:** Located on each earbud, used for playback control, call management, and voice assistant activation.
- **LED Indicator:** Provides status updates for pairing, connection, and charging.
- **Charging Contacts:** Located on the earbuds and inside the charging case.
- **Charging Case:** Stores and charges the earbuds.
- **USB-C Port:** For charging the case.

4. Setup

4.1 Initial Charge

Before first use, fully charge the earbuds and the charging case.

1. Place both earbuds into the charging case.
2. Connect the USB-C charging cable to the charging port on the case and to a power source.
3. The LED indicator on the case will show charging status. A full charge typically takes about 1.5 hours for the

case.

4.2 Pairing with a Device

Follow these steps to pair your earbuds with your Bluetooth-enabled device:

1. Remove both earbuds from the charging case. They will automatically power on, and a blue light will indicate this.
2. Wait for the voice prompt "Pairing, Left Channel, Right Channel." This confirms the earbuds are synced with each other.
3. On your device (smartphone, tablet, etc.), go to the Bluetooth settings.
4. Enable Bluetooth and search for available devices.
5. Select "Cellet_EB600" from the list of found devices.
6. Once connected, both earbuds will flash blue approximately every 8 seconds, indicating a successful connection.

Note: The earbuds will automatically attempt to reconnect to the last paired device when removed from the case.



Image 4.1: Illustration showing the broad compatibility of Cellet Wireless Bluetooth Earbuds with various devices, including MP3 players, smartphones (iOS, Android, Windows), and tablets.

5. Operating Instructions

The multi-function button on each earbud controls various features.

5.1 Power On/Off

- **Power On:** Remove earbuds from the charging case. They will power on automatically.
- **Power Off:** Place earbuds back into the charging case. They will power off automatically and begin charging.
- **Manual Power Off:** Press and hold the multi-function button for approximately 5 seconds until the LED indicator turns red.
- **Manual Power On:** Press and hold the multi-function button for approximately 3 seconds until the LED indicator flashes blue.

5.2 Music Playback

- **Play/Pause:** Single press the multi-function button on either earbud.
- **Next Track:** Double press the multi-function button on the *right* earbud.
- **Previous Track:** Double press the multi-function button on the *left* earbud.

5.3 Call Management

- **Answer Call:** Single press the multi-function button on either earbud.
- **End Call:** Single press the multi-function button on either earbud during a call.
- **Reject Call:** Press and hold the multi-function button on either earbud for 2 seconds.

5.4 Voice Assistant

- **Activate Voice Assistant:** Triple press the multi-function button on either earbud.



Image 5.1: Examples of using Cellet Wireless Bluetooth Earbuds in various daily activities, including listening to music, cycling, and answering calls while driving.

6. Charging

The earbuds and charging case have separate batteries.

6.1 Charging the Earbuds

- Place the earbuds into the charging case. Ensure the charging contacts align.
- The earbuds will automatically begin charging. The LED indicators on the earbuds will show charging status (e.g., red while charging, off when fully charged).

6.2 Charging the Charging Case

- Connect the provided USB-C cable to the charging port on the case and to a USB power adapter (not included) or a computer's USB port.
- The LED indicator on the charging case will show charging status.

- A full charge for the case typically takes about 1.5 hours.



Image 6.1: The charging case with key specifications highlighted, including Bluetooth version (V5.0), Bluetooth distance (10M), earbud battery capacity (45mAh*2), charging case battery capacity (300mAh), charging time (approx. 1.5 hours), music playing time (3-4 hours), calling talk time (3-4 hours), and waterproof level (IPX5).

7. Maintenance

To ensure the longevity and optimal performance of your earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Ear Tips:** Remove and clean the ear tips periodically with water and mild soap. Ensure they are completely dry before reattaching.
- **Charging Contacts:** Keep the charging contacts on both the earbuds and the case clean and free of debris to ensure proper charging.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage.
- **Avoid Extreme Conditions:** Do not expose the earbuds to extreme temperatures, humidity, or direct sunlight.

- **Water Resistance:** The earbuds have an IPX5 waterproof rating, meaning they are resistant to splashes and sweat. Do not submerge them in water.

8. Troubleshooting

If you encounter any issues with your earbuds, refer to the following common problems and solutions:

Problem	Solution
Earbuds not powering on.	Ensure the earbuds are charged. Place them in the charging case and connect the case to power.
Earbuds not pairing with device.	• Ensure Bluetooth is enabled on your device. • Make sure the earbuds are in pairing mode (flashing blue/red or "Pairing" voice prompt). • Forget "Cellet_EB600" from your device's Bluetooth list and try pairing again. • Ensure earbuds are within 10 meters of your device.
Only one earbud is working.	• Place both earbuds back into the charging case, then remove them simultaneously to re-sync. • Ensure both earbuds are charged.
Low volume or poor sound quality.	• Adjust the volume on your connected device. • Ensure ear tips are properly sealed in your ear. Try different sized ear tips. • Clean any debris from the earbud speakers.
Charging case not charging.	• Check the USB-C cable and power adapter for damage. • Ensure the cable is securely connected to both the case and the power source. • Clean the charging port on the case.

9. Specifications

Technical specifications for the Cellet Wireless Bluetooth Earbuds Model XG01:

Feature	Detail
Model Name	XG01
Bluetooth Version	V5.2
Wireless Communication Technology	Bluetooth
Connectivity Technology	Wireless
Earbud Battery Capacity	45mAh per earbud
Charging Case Battery Capacity	300mAh

Feature	Detail
Music Play Time	3-4 hours
Talk Time	3-4 hours
Charging Time (Case)	Approx. 1.5 hours
Wireless Range	Up to 10 meters (33 feet)
Waterproof Level	IPX5
Microphone	Built-in dual microphones
Control Method	Touch / Multi-function Button
Noise Isolation	Yes (Noise-isolating earbuds)
UPC	746697457412

10. Warranty and Support

For warranty information or technical support, please refer to the documentation provided at the time of purchase or contact your retailer.
For further assistance, you may visit the manufacturer's website or contact their customer service department. Please have your product model number (XG01) and purchase details ready.

© 2023 Cellet. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B085X9NTQX

More documents and user manuals: **https://manuals.plus/**