Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Campingaz Camping Kitchen 2 Grill & Go R

Portable Two Burner Gas Cooker, Outdoor Grill

Model: Camping Kitchen 2 Grill & Go R

Brand: Campingaz

Introduction

The Campingaz Camping Kitchen 2 Grill & Go R is a compact and versatile 2-in-1 camping stove and grill designed for outdoor cooking. It features two powerful burners and includes both pot supports and grill plates, allowing you to cook or grill simultaneously. With its piezo ignition, operation is simple and convenient, eliminating the need for external lighters or matches. Its lightweight design and included carrying bag make it an ideal companion for camping, festivals, or even for use on a balcony or patio.

This manual provides essential information for the safe and efficient use, setup, operation, and maintenance of your Campingaz Portable Two Burner Gas Cooker.

Safety Information

Please read all safety warnings and instructions carefully before assembling and using this appliance. Failure to follow these instructions may result in fire, explosion, or serious injury.

- **Outdoor Use Only:** This appliance is designed for outdoor use only and must not be operated in enclosed spaces.
- **Ventilation:** Ensure adequate ventilation during operation.
- **Gas Supply:** Use only the specified gas bottle types (Campingaz R904, R907, butane, or propane gas bottles). Ensure the gas bottle is connected securely and leak-free.
- **Leak Test:** Always perform a leak test after connecting a new gas bottle or if the appliance has not been used for a long period.
- **Clearance:** Maintain a safe distance from combustible materials.
- **Children and Pets:** Keep children and pets away from the appliance during use and while it is cooling down.
- **Hot Surfaces:** Appliance surfaces will become hot during use. Use heat-resistant gloves when handling hot components.

- **Storage:** Store the appliance in a cool, dry place away from direct sunlight and heat sources when not in use. Disconnect the gas bottle before storage.

Components

The Campingaz Camping Kitchen 2 Grill & Go R includes the following main components:

- Main Stove Unit with two burners
- Two removable pot supports
- Two removable grill plates (one flat, one ribbed)
- Integrated piezo ignition for each burner
- Control knobs for flame adjustment
- Lid/Windshield
- Carrying bag (provided)

Note: The gas hose and regulator are not supplied with the unit and must be purchased separately.



Figure 1: Overview of the Campingaz Camping Kitchen 2 Grill & Go R with both grill plates in place.



Figure 2: The stove configured with a kettle on one burner and a griddle plate on the other.

Setup

Assembly is required for initial setup. Follow these steps to prepare your stove for use:

1. **Unpack:** Remove all components from the packaging and the carrying bag.
2. **Positioning:** Place the stove on a stable, level, non-combustible surface outdoors, away from any flammable materials.
3. **Open Lid:** Lift the lid of the stove until it locks into an upright position, serving as a windshield.
4. **Install Supports/Plates:** Decide whether you will be using the pot supports for cookware or the grill plates. Place the desired components securely over the burners.
5. **Connect Gas Bottle:** Ensure both control knobs on the stove are in the 'OFF' position. Connect the appropriate gas hose and regulator (sold separately) to the stove's gas inlet and then securely attach it to your Campingaz R904/R907 or compatible butane/propane gas bottle.
6. **Leak Test:** Before first use and after every gas bottle change, perform a leak test. Apply a soapy water solution to all gas connections. If bubbles appear, there is a leak. Tighten connections or replace faulty parts. Do not use the appliance if a leak is detected.



Figure 3: The stove set up for outdoor cooking with a gas bottle.

Operating Instructions

Once the stove is set up and the gas bottle is connected, you can begin cooking:

1. **Open Gas Supply:** Slowly open the valve on the gas bottle.
2. **Ignite Burner:** Push in and turn the desired control knob counter-clockwise to the 'HIGH' position. Simultaneously press the piezo ignition button located next to the control knob. You should hear a click and see the burner ignite.
3. **Adjust Flame:** Once ignited, release the piezo ignition button. You can then adjust the flame intensity by turning the control knob between 'HIGH' and 'LOW' settings.
4. **Cooking/Grilling:** Place your cookware on the pot supports or food directly on the grill plates.
5. **Turn Off:** To turn off a burner, turn its control knob clockwise to the 'OFF' position. After cooking, close the valve on the gas bottle and allow the appliance to cool completely before handling or storing.



Figure 4: The stove in operation, demonstrating cooking and grilling capabilities.

Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your stove.

- **Cool Down:** Always ensure the appliance has completely cooled down before cleaning.
- **Grill Plates and Pot Supports:** The grill plates and pot supports are removable for easy cleaning. They can be washed by hand with warm soapy water or placed in a dishwasher.
- **Stove Body:** Wipe down the stove body with a damp cloth and mild detergent. Avoid abrasive cleaners or scouring pads that could damage the finish.
- **Burners:** Keep the burner ports clean and free from food debris. Use a soft brush if necessary. Do not use water directly on the burners.
- **Storage:** Once clean and dry, store the stove in its carrying bag in a dry, well-ventilated area. Disconnect the gas bottle before storage.



Figure 5: Cleaning the stove surface after use.

Troubleshooting

If you encounter issues with your stove, refer to the following common troubleshooting tips:

- **Burner Not Igniting:**
  - Check if the gas bottle valve is fully open.
  - Ensure the gas hose and regulator are securely connected and not kinked.
  - Verify there is gas in the bottle.
  - Check if the piezo igniter is clicking and sparking. If not, it may need cleaning or servicing.
- **Low Flame:**
  - The gas bottle may be running low.
  - Check for blockages in the burner ports.
  - Ensure the regulator is functioning correctly.
- **Gas Leak Smell:**
  - Immediately turn off the gas supply at the bottle.
  - Move the appliance to a well-ventilated area.
  - Perform a leak test with soapy water on all connections.

- Do not attempt to light the appliance if a leak is suspected. Contact customer support if the leak persists.

Specifications

Brand	Campingaz
Model Name	Camping Kitchen 2 Grill & Go R
Product Dimensions (Open)	49 x 35 x 35 cm (LxWxH)
Product Dimensions (Closed)	49 x 35 x 10 cm (LxWxH)
Item Weight	5.3 kg
Fuel Type	Gas (R904, R907, butane or propane gas bottle)
Wattage	2 x 2000 W (Total 4000 W)
Gas Consumption	2 x 145 g/h
Ignition	Piezo
Cooking Time (1L water)	5 min 45 s
Running Time (R907)	9 h 30 min
Running Time (R904)	6 h 10 min
Material	Aluminum
Assembly Required	Yes

Warranty and Support

For warranty information, please refer to the documentation included with your purchase or visit the official Campingaz website. Keep your proof of purchase for any warranty claims.

If you require technical assistance, spare parts, or have any questions not covered in this manual, please contact Campingaz customer support through their official channels. Contact information can typically be found on the product packaging or the Campingaz website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0864KFQNX

More documents and user manuals: **https://manuals.plus/**