Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Paladone PP6593MCF

Paladone Minecraft Creeper Light (Model PP6593MCF) Instruction Manual

Model: PP6593MCF | Brand: Paladone

Introduction

This manual provides essential information for the safe and effective use of your Paladone Minecraft Creeper Light. Please read these instructions carefully before use and retain them for future reference.



Image: Front view of the Paladone Minecraft Creeper Light, showcasing its pixelated design and green color.

Package Contents

- 1 x Paladone Minecraft Creeper Light
- Instruction Manual (this document)



Image: The Paladone Minecraft Creeper Light shown in its retail box, indicating the product as packaged.

Setup

Battery Installation

1. Locate the battery compartment cover on the base of the Creeper Light.
2. Using a small screwdriver (not included), carefully remove the screw securing the battery compartment cover.
3. Remove the cover.
4. Insert 1 x AAA battery (not included), ensuring correct polarity (+/-) as indicated inside the compartment.
5. Replace the battery compartment cover and secure it with the screw.

Note: Ensure batteries are inserted correctly. Incorrect insertion can damage the device.

Operating Instructions

Power On/Off

The Creeper Light features a push-button switch for operation. This switch is typically located on the base or rear of the unit.

- To turn the light **ON**: Press the power button once.
- To turn the light **OFF**: Press the power button again.

Light Modes (3-Way Feature)

This light may offer multiple brightness settings or light modes. If your model includes a 3-way feature, repeatedly pressing the power button will cycle through the available modes:

1. First press: Standard brightness.
2. Second press: Dimmer setting (if applicable).
3. Third press: Off.



Image: The Creeper Light glowing green in a dimly lit environment, demonstrating its function as a light source.

Maintenance

Cleaning

To clean the Creeper Light, gently wipe the surface with a soft, dry cloth. Do not use abrasive cleaners, solvents, or immerse the unit in water, as this can damage the electronics and finish.

Battery Replacement

When the light begins to dim or stops functioning, it is time to replace the battery. Follow the "Battery Installation" steps in the Setup section to replace the AAA battery.

- Always use fresh, high-quality AAA batteries.
- Dispose of old batteries responsibly according to local regulations.
- If the device will not be used for an extended period, remove the battery to prevent leakage.

Troubleshooting

Problem	Possible Cause	Solution
Light does not turn on.	• Batteries are dead or incorrectly installed. • Battery compartment cover not secured.	• Replace with fresh AAA batteries, ensuring correct polarity. • Ensure the battery compartment cover is properly closed and screwed.
Light is dim or flickers.	• Batteries are low.	• Replace with fresh AAA batteries.
Light turns off unexpectedly.	• Batteries are low. • Loose battery connection.	• Replace with fresh AAA batteries. • Check battery installation for secure contact.

Specifications

Feature	Detail
Model Number	PP6593MCF
Brand	Paladone
Dimensions (D x W x H)	2.95" x 2.95" x 4.72" (7.5 cm x 7.5 cm x 12 cm)
Item Weight	4.2 ounces (120 Grams)
Power Source	Battery Powered
Batteries Required	1 x AAA (not included)
Light Source Type	LED
Brightness	200 Lumen
Material	Plastic (BDP - Biodegradable Plastic)
Switch Type	Push Button
Special Feature	3-Way (if applicable to model)
Indoor/Outdoor Usage	Indoor
Water Resistance Level	Not Water Resistant



Image: Diagram illustrating the height and width measurements of the Creeper Light.

Safety Information

- This product is not a toy. Keep out of reach of small children.
- Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Remove batteries if storing for long periods to prevent leakage.
- Do not expose the light to water or extreme temperatures.
- Do not attempt to disassemble or modify the product.

Warranty and Support

For product support or warranty inquiries, please contact Paladone customer service through their official website or the retailer where the product was purchased. Please have your model number (PP6593MCF) and purchase date available.

You can visit the official Paladone store for more information:Paladone Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B086688WJ6

More documents and user manuals: **https://manuals.plus/**