Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Inalsa Kratos 1000W

INALSA Kratos 1000W Stand Mixer User Manual

Model: Kratos 1000W

1. Introduction

Thank you for choosing the INALSA Kratos Stand Mixer. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your appliance. Please read these instructions carefully before first use and keep them for future reference.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

1. Read all instructions before using the appliance.
2. To protect against risk of electrical shock, do not immerse the motor unit in water or other liquid.
3. Close supervision is necessary when any appliance is used by or near children.
4. Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
5. Avoid contact with moving parts. Keep hands, hair, and clothing, as well as spatulas and other utensils, away from beaters during operation to reduce the risk of injury to persons and/or damage to the mixer.
6. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner. Contact customer service for examination, repair, or electrical or mechanical adjustment.
7. The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter.
10. Do not let cord contact hot surfaces, including the stove.
11. Always operate the mixer on a dry, stable, and level surface.
12. Ensure the appliance is switched off before connecting to the power supply.

2. Product Overview

The INALSA Kratos Stand Mixer is designed for efficient mixing, kneading, and whisking. It features a powerful motor and a robust design for various culinary tasks.

Components

- Main Unit with Motor Head
- 5.0 Litre Stainless Steel Mixing Bowl

- Splash Guard
- Dough Hook
- Beater (Mixing Paddle)
- Whisk (Balloon Whisk)



Figure 1: Overview of the INALSA Kratos Stand Mixer components, including the main unit, 5.0L stainless steel bowl, splash guard, dough hook, whisk, and beater.

Key Features

- **Powerful 1200W Pure Copper Motor:** Delivers consistent power for heavy doughs, batters, and whipping.
- **5.0 Litre Stainless Steel Bowl:** Large capacity for preparing family-sized meals and baking.
- **8-Speed Control with Pulse Function:** Offers precise control for various mixing needs.
- **Overheat Protection:** Ensures motor longevity and safe operation.
- **Safety Lock:** Secures the motor head during operation.
- **Dust-Proof Splash Guard:** Prevents splatters and keeps your kitchen clean.



Figure 2: Illustration of the 1200W pure copper motor, highlighting its efficiency and power for various tasks.



Figure 3: The 5.0L food-grade stainless steel mixing bowl with a handle for easy handling and pouring.

3. Setup

Unpacking

1. Carefully remove the stand mixer and all accessories from the packaging.
2. Remove any protective films or packaging materials from the appliance.
3. Clean all parts that will come into contact with food before first use (refer to the Cleaning and Maintenance section).

Assembly

1. Place the stand mixer on a clean, dry, stable, and level surface.
2. **Attach the Mixing Bowl:** Place the stainless steel bowl into its base on the main unit and turn it clockwise until it locks securely into place.
3. **Attach the Splash Guard:** Position the splash guard over the bowl, ensuring the opening aligns with the attachment shaft.
4. **Install an Attachment:**
   - Ensure the mixer is unplugged and the speed control is set to '0'.
   - Press the head-release button and lift the motor head until it locks in the tilted position.
   - Insert the desired attachment (Dough Hook, Beater, or Whisk) into the attachment shaft. Push upwards and turn counter-clockwise until it clicks into place.
   - Lower the motor head by pressing the head-release button again and gently pushing the head down until it locks.

4. Operating Instructions

Always ensure the mixer is unplugged before attaching or removing accessories.

General Operation

1. Ensure the mixer is correctly assembled with the desired attachment and bowl.
2. Add your ingredients to the mixing bowl.
3. Plug the mixer into a suitable power outlet.
4. Turn the speed control knob to the desired speed setting (1-8). The LED power indicator will illuminate.
5. When finished, turn the speed control knob back to '0' and unplug the appliance.
6. Lift the motor head to remove the bowl and attachment.

Attachment Usage Guide



Figure 4: Detailed view of the three included attachments: Dough Hook for heavy mixtures, Beater for medium-heavy mixtures, and Whisk for light mixtures.

- **Dough Hook:** Ideal for kneading heavy mixtures such as bread dough, pizza dough, and pasta. Use speeds 1-5.
- **Beater (Mixing Paddle):** Suitable for medium-heavy mixtures like cake batters, cookies, frostings, and mashed potatoes. Use speeds 1-6.
- **Whisk (Balloon Whisk):** Perfect for light mixtures such as whipping cream, egg whites, meringues, and light batters. Use speeds 7-8.

Speed Settings and Pulse Function



Figure 5: The speed control knob with 8 settings and a pulse function, featuring an LED power indicator for easy operation.

- **Speeds 1-5:** For Dough Hook (heavy mixtures).
- **Speeds 1-6:** For Mixing Beater (medium-heavy mixtures).
- **Speeds 7-8:** For Whisk (light mixtures).
- **Pulse Function (P):** Provides a quick burst of power for short mixing intervals or to incorporate ingredients quickly. Hold the knob at 'P' for as long as needed, then release.

Usage Guidelines (5L Bowl)



Figure 6: A table detailing recommended speed levels, times, and maximum capacities for each attachment with the 5L bowl.

Recommended Usage Parameters

Attachment	Speed Level	Time	Max Capacity
Dough Hook	Level 1-5	3-5 min	Max 600g flour + 500g water
Mixing Beater	Level 2-6	3-10 min	Max 400g flour + 500g water
Whisking Cone	Level 6-8	3-10 min	Max 12 egg whites

Caution:

- During dough kneading, use a maximum speed of level 5.
- Slight heating on top of the mixing arm is normal during operation.
- Total mixture should not exceed 900g.
- Do not exceed level 5 when using the dough hook.
- Follow speed, time, and quantity limits to avoid overheating and ensure proper performance.

5. Cleaning and Maintenance

Proper cleaning and maintenance will ensure the longevity and optimal performance of your stand mixer.

1. Always unplug the appliance from the power outlet before cleaning.
2. **Main Unit:** Wipe the exterior of the motor unit with a soft, damp cloth. Do not use abrasive cleaners or immerse the motor unit in water or any other liquid.
3. **Mixing Bowl and Attachments:** The stainless steel mixing bowl, dough hook, beater, and whisk are dishwasher safe. Alternatively, they can be washed by hand with warm, soapy water and then rinsed thoroughly and dried.
4. **Splash Guard:** Wash the splash guard by hand with warm, soapy water.
5. Ensure all parts are completely dry before reassembling or storing the appliance.
6. Store the mixer in a dry place, away from direct sunlight and out of reach of children.

6. Troubleshooting

If you encounter any issues with your INALSA Kratos Stand Mixer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Mixer does not turn on.	Not plugged in; power outlet not working; speed control not at '0' before starting.	Check power cord connection; test outlet with another appliance; ensure speed control is at '0' before turning on.
Motor stops during operation.	Overload protection activated; motor overheating.	Turn off and unplug the mixer. Reduce the load (amount of ingredients). Let the mixer cool down for at least 20-30 minutes before restarting.
Attachments are difficult to install/remove.	Attachment not aligned correctly; motor head not fully tilted.	Ensure the motor head is fully tilted and locked. Align the attachment shaft correctly and push/twist firmly.
Mixer vibrates excessively.	Uneven surface; too much mixture; mixture too stiff.	Place mixer on a stable, level surface. Do not exceed maximum capacities. If mixture is too stiff, add liquid or reduce quantity.

If the problem persists after trying these solutions, please contact INALSA customer support.

7. Specifications

Model	Kratos 1000W
Power (Motor)	1200W

Voltage	240V
Frequency	50Hz
Bowl Capacity	5.0 Litres
Speed Settings	8 Speeds + Pulse
Material	Stainless Steel (Bowl), Plastic (Body)
Product Dimensions (D x W x H)	22.5D x 22.5W x 29.8H Centimeters
Item Weight	3.6 Kilograms
Special Features	Overheat Protection, Removable Bowl, Safety Lock

8. Warranty and Customer Support

Warranty

The INALSA Kratos Stand Mixer comes with a**2-year manufacturer warranty** from the date of purchase. This warranty covers manufacturing defects under normal household use. Please retain your purchase receipt as proof of purchase for warranty claims.
The warranty does not cover damage resulting from misuse, abuse, accident, alteration, improper installation, or normal wear and tear.

Customer Support

For any service, repair, or warranty-related inquiries, please contact INALSA customer support. You can find contact details on the official INALSA website or through your retailer.
Importer Contact Information:
Tuareg Marketing Pvt.Ltd, KHASRA NO.154,1092,1189, BHALSWA VILLAGE,BHALSWA, North West Delhi, Delhi, 110033.
Contact No: 9773982065, 9773982066, 9773982067, 9773982068, 9773982069

© 2026 Inalsa. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0873G3Z44

More documents and user manuals: **https://manuals.plus/**