Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun 70-N7200cc

Braun Series 7 70-N7200cc Electric Shaver User Manual

Efficient, Close & Gentle Shave

1. Introduction

This manual provides essential information for the safe and effective use of your Braun Series 7 Electric Shaver, model 70-N7200cc. Please read these instructions thoroughly before first use and retain them for future reference.



Image: Braun Series 7 Electric Shaver with its SmartCare Center and Precision Trimmer attachment, highlighting its efficient, close, and gentle shave capabilities.

2. Setup

2.1 Charging the Shaver

The shaver is equipped with a Li-Ion battery. Before first use, or when the battery indicator shows low charge, fully charge the shaver.

1. Ensure the shaver is dry.
2. Connect the charger to the shaver's charging port located at the bottom.
3. Plug the charger into an electrical outlet. The battery status indicator will illuminate to show charging progress.
4. A full charge takes approximately 1 hour and provides up to 50 minutes of shaving time. A 5-minute quick charge is sufficient for one full shave.

2.2 Attaching/Detaching Accessories

The Braun Series 7 features EasyClick attachments for versatile grooming.

1. To attach the Precision Trimmer: Ensure the shaver is off. Gently pull off the existing shaver head. Align the Precision Trimmer attachment with the shaver body and push until it clicks into place.
2. To detach: Gently pull the attachment away from the shaver body.



Image: The Braun Series 7 shaver demonstrating the EasyClick system with the Precision Trimmer attachment.

3. Operating the Shaver

3.1 Power On/Off

Press the power button () to turn the shaver on or off.

3.2 Shaving Modes

The shaver features AutoSense technology which reads and adapts power to your beard density. You can also manually select shaving modes:

- **Standard Mode:** Default setting for everyday shaving.
- **Gentle Mode:** Indicated by a feather icon, ideal for sensitive skin or lighter beard growth.
- **Turbo Mode:** Indicated by a fan icon, provides maximum power for dense beards.

Press the mode button (∧) to cycle through the available modes.



Image: Close-up of the Braun Series 7 shaver head, illustrating the AutoSense Technology that adapts to beard density.

3.3 Wet & Dry Use

The Braun Series 7 is 100% waterproof and can be used for both wet and dry shaving. For a refreshing shave, use with foam or gel.

3.4 Travel Lock

To activate the travel lock, press and hold the power button for 3 seconds. The travel lock indicator will illuminate.

Repeat the process to deactivate.

4. Maintenance

4.1 Cleaning

Regular cleaning ensures optimal performance and hygiene.

- **Manual Cleaning:** After each shave, remove the shaver head and tap out any loose hair. You can rinse the shaver head and the shaver under warm running water. Allow to air dry.
- **SmartCare Center:** For thorough cleaning, lubrication, and charging, place the shaver in the SmartCare Center. Follow the instructions provided with your SmartCare Center.





Image: The Braun SmartCare Center, designed to clean, lubricate, and charge the shaver, ensuring it remains in optimal condition.

4.2 Foil & Cutter Cassette Replacement

To maintain 100% shaving performance, replace the shaver head (Foil & Cutter Cassette, model 74S) approximately every 18 months. A replacement indicator light will appear on the shaver's display when replacement is due.

▶ **Watch video online**
S7 73S 360 Replacement Head Foil & Cutters for Braun

Video: This video demonstrates the replacement process for the S7 73S 360 Replacement Head Foil & Cutters for Braun Series 7 shavers. It shows how to remove the old head and install a new one, ensuring continued optimal shaving performance.

5. Troubleshooting

If you encounter issues with your shaver, please consider the following:

- **Shaver not turning on:** Check the battery indicator. If low, charge the shaver. Ensure the travel lock is not activated.
- **Reduced shaving performance:** Clean the shaver head thoroughly. Consider replacing the Foil & Cutter Cassette if it has been more than 18 months since the last replacement.
- **Irritation:** Ensure you are using the appropriate shaving mode for your skin and beard type. For sensitive skin, use Gentle Mode.

6. Specifications

- **Brand:** Braun
- **Model Name:** Series 7
- **Item Model Number:** 4210201332169
- **Product Dimensions:** 15.7 x 15.7 x 25.2 cm; 940 g

- **Power Source:** Battery Powered (Li-Ion)
- **Battery Life:** Up to 50 minutes
- **Special Features:** Cordless, Dry Shave, Rechargeable, Wet Shave, 360° Adaptation, AutoSense Technology
- **Blade Material:** Stainless Steel
- **Included Components:** Shaver, SmartCare Center, Precision Trimmer attachment

7. Warranty & Support

The Braun Series 7 Electric Shaver comes with a warranty of up to 5 years. For detailed warranty information, product support, or to purchase replacement parts, please visit the official Braun website or contact their customer service. You can also visit the Braun Store on Amazon for more information and products.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Is the Braun Series 7 shaver supposed to remain in the charging unit when not being used, or only for recharging?

Yes, you can leave the shaver in the SmartCare Center (charging unit) when it is not in use. Modern Braun Series 7 shavers use Li-Ion batteries, which are designed to be stored in the...

Read full answer

Open the live page

https://manuals.plus/asin/B0883MKSGM

More documents and user manuals: **https://manuals.plus/**