Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Joyroom JR-TL1

JoyRoom JR-TL1 True Wireless Earphones

Model: JR-TL1 | **Brand:** Joyroom

Product Overview

The JoyRoom JR-TL1 True Wireless Earphones are designed for a seamless audio experience. These in-ear headphones offer wireless connectivity and come with a portable charging case, providing convenience for daily use.



Image: JoyRoom JR-TL1 True Wireless Earphones, white, resting inside their open charging case. The earbuds are visible in their respective slots, and the case has indicator lights.

Setup Guide

1. Initial Charging

Before first use, ensure both the charging case and the earphones are fully charged.

- Place the earphones into the charging case. Ensure the charging contacts on the earphones align with the pins in the case.
- Connect the charging case to a power source using a compatible charging cable. The indicator lights on the case

will show charging status.

- Allow sufficient time for a full charge.



Image: A close-up view of the two white JoyRoom JR-TL1 earbuds. The underside of each earbud is visible, showing the small gold-colored charging contacts.

2. Bluetooth Pairing

To connect your earphones to a device:

1. Ensure the earphones are charged and inside the charging case.
2. Open the charging case. The earphones will automatically enter pairing mode.
3. On your device (smartphone, tablet, etc.), navigate to the Bluetooth settings.
4. Search for available devices and select "JR-TL1" from the list.
5. Once connected, a voice prompt or indicator light on the earphones will confirm successful pairing.

Note: If pairing fails, ensure the earphones are not connected to another device and try again.

Operating Instructions

Power On/Off

- **Power On:** Open the charging case, and the earphones will automatically power on and connect to the last paired device. Alternatively, press and hold the touch area on each earbud for a few seconds.
- **Power Off:** Place the earphones back into the charging case and close the lid. They will automatically disconnect and power off. Alternatively, press and hold the touch area on each earbud for a few seconds until they power off.

Music Playback

- **Play/Pause:** Tap the touch area on either earbud once.
- **Next Track:** Double-tap the touch area on the right earbud.
- **Previous Track:** Double-tap the touch area on the left earbud.

Call Handling

- **Answer/End Call:** Tap the touch area on either earbud once.
- **Reject Call:** Press and hold the touch area on either earbud for 2 seconds.

Maintenance

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Pay special attention to the charging contacts and ear tips to prevent debris buildup. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the earphones in their charging case to protect them from dust and damage. Keep the case closed.
- **Battery Care:** To prolong battery life, avoid fully discharging the earphones and charging case frequently. Charge them regularly, even if not in constant use. Avoid exposing the device to extreme temperatures.



Image: The white JoyRoom JR-TL1 charging case, closed, with the "JOYROOM" logo visible on the top surface. A white wrist strap is attached to the case.

Troubleshooting

Problem	Possible Cause	Solution
Earphones not pairing with device.	Not in pairing mode, already connected to another device, low battery.	Ensure earphones are in the case with the lid open. Turn off Bluetooth on other nearby devices. Recharge earphones and case. Try re-pairing.
No sound from one or both earbuds.	Low battery, earbud not properly seated in case, connection issue.	Check battery levels. Ensure earbuds are clean and properly seated in the charging case. Reconnect Bluetooth.
Charging case not charging.	Faulty cable/adapter, dirty charging port.	Try a different charging cable and power adapter. Clean the charging port on the case.
Poor call quality.	Weak signal, microphone obstruction.	Move closer to your connected device. Ensure the microphone area on the earbuds is not covered.

Specifications

- **Model:** JR-TL1
- **Brand:** Joyroom
- **Color:** White
- **Material:** ABS
- **Connectivity Technology:** Wireless (Bluetooth)
- **Headphones Form Factor:** In Ear
- **Headphones Ear Placement:** In Ear
- **Noise Control:** None
- **Headphones Jack:** No Jack
- **Charging Box Battery:** 300 mAh
- **Play Time:** Approximately 6 hours
- **Talking Time:** Approximately 3 hours
- **Batteries:** 1 Lithium Ion battery required (included)
- **Product Dimensions:** 19.2 x 16.4 x 3 cm
- **Weight:** 140 g
- **Included Components:** Wireless Charging Case
- **Frequency Response:** 3045 (Hz) *(Note: This value is as provided in product data. Typical frequency response ranges are broader.)*

Warranty and Support

Specific warranty details for the JoyRoom JR-TL1 True Wireless Earphones are not provided in the available product information. Please refer to the product packaging or the official Joyroom website for comprehensive warranty terms and conditions.

For technical support, troubleshooting assistance, or any product-related inquiries, please contact Joyroom customer service directly. Contact information can typically be found on the manufacturer's official website or product documentation.

© 2023 Joyroom. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B088FTBYX9

More documents and user manuals: **https://manuals.plus/**