Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

iHome IH-CT538W-PA

iHome 2-Port USB Wall Charger User Manual

Model: IH-CT538W-PA

Introduction

Thank you for purchasing the iHome 2-Port USB Wall Charger. This compact and efficient charger is designed to provide convenient power for your mobile devices, featuring a flat profile for easy access to outlets and dual USB ports for simultaneous charging. This manual provides important information regarding the setup, operation, maintenance, and troubleshooting of your new charger.

Important Safety Information

Please read all safety instructions carefully before using this product. Failure to follow these instructions may result in electric shock, fire, or damage to the product or connected devices.

- Do not expose the charger to liquids, moisture, or extreme temperatures.
- Do not disassemble or attempt to repair the charger. Refer all servicing to qualified personnel.
- Ensure the wall outlet voltage matches the charger's input voltage (120 Volts).
- Avoid using damaged cables or adapters with the charger.
- Unplug the charger from the wall outlet when not in use or during electrical storms.
- Keep out of reach of children.

Package Contents

Verify that all items are present in your package:

- iHome 2-Port USB Wall Charger (Model: IH-CT538W-PA)

Note: USB charging cables are not included and must be purchased separately.

Product Overview

The iHome 2-Port USB Wall Charger is designed for convenience and efficiency. Key features include:

- **Dual USB Ports:** Allows charging of two devices simultaneously.
- **Flat Wall Plug Design:** Enables use in tight spaces, such as behind furniture.
- **Rapid Charging Port:** One dedicated 2.4A port for faster charging of compatible devices.

- **Foldable Prongs:** For easy portability and storage.





Image: The iHome 2-Port USB Wall Charger, white in color, shown plugged into a standard wall outlet, highlighting its flat design that sits flush against the wall.



Image: A desk setup showing the iHome 2-Port USB Wall Charger plugged into an outlet, with cables extending to charge a laptop and a smartphone, demonstrating its dual USB port capability.



Image: The iHome 2-Port USB Wall Charger plugged into a wall outlet located behind a nightstand, illustrating its ultra-slim profile that allows it to fit in narrow spaces without obstructing furniture.



Image: A detailed view of the iHome 2-Port USB Wall Charger, highlighting its two USB ports. One port is specifically labeled to indicate its 2.4A rapid charging capability.



Image: The iHome 2-Port USB Wall Charger with its foldable prongs extended and then being tucked into a bag, demonstrating its compact and travel-friendly design.



Image: An assortment of electronic devices such as smartphones, tablets, and cameras, visually representing the universal compatibility of the iHome 2-Port USB Wall Charger with a wide range of USB-powered gadgets.

Setup

1. **Unfold Prongs:** Gently extend the foldable prongs from the charger body until they lock into place.
2. **Plug into Outlet:** Insert the charger into a standard 120V AC wall outlet. The flat design allows it to fit snugly against the wall, even behind furniture.
3. **Connect Devices:** Using your device's USB charging cable (not included), connect one end to a USB port on the iHome charger and the other end to your device.
4. **Begin Charging:** Your device should automatically begin charging. For faster charging, use the port labeled 2.4A with compatible devices.

Operating Instructions

The iHome 2-Port USB Wall Charger is designed for simple plug-and-play operation.

- **Simultaneous Charging:** You can charge up to two USB-powered devices at the same time.
- **Optimal Charging:** For devices that support faster charging, utilize the dedicated 2.4A USB port. Standard USB ports will charge at their normal rate.
- **Device Compatibility:** This charger is compatible with a wide range of devices including iPhones, Android phones, iPads, tablets, AirPods, and other USB-powered gadgets.

Maintenance

To ensure the longevity and optimal performance of your iHome 2-Port USB Wall Charger, follow these maintenance guidelines:

- **Cleaning:** Disconnect the charger from the power outlet before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or aerosols.
- **Storage:** When not in use, fold the prongs and store the charger in a cool, dry place away from direct sunlight and moisture.
- **Handling:** Avoid dropping the charger or subjecting it to strong impacts.

Troubleshooting

Problem	Possible Cause	Solution
Device not charging.	Charger not properly plugged in. Faulty USB cable. Device charging port issue. Charger malfunction.	Ensure the charger is fully inserted into the wall outlet. Try a different USB cable. Test charging the device with another charger. If issues persist, contact customer support.
Slow charging.	Using a non-2.4A port for a fast-charge compatible device. High power consumption by device during charging. Cable quality.	Ensure the device is connected to the 2.4A port if it supports rapid charging. Close unnecessary applications on your device. Use a high-quality USB cable.
Charger feels warm.	Normal operation during charging. Overload or poor ventilation.	Slight warmth is normal. Ensure adequate ventilation around the charger. Avoid covering it. If it becomes excessively hot, unplug immediately.

Specifications

- **Model:** IH-CT538W-PA
- **Input Voltage:** 120 Volts
- **Connector Type:** USB-A
- **Number of Ports:** 2
- **Special Feature:** Fast Charging (2.4A dedicated port)
- **Color:** White
- **Dimensions:** 3.86 x 3.11 x 0.94 inches (Package Dimensions)
- **Item Weight:** 2.89 ounces
- **Manufacturer:** iHome by Lifeworks Technology
- **Country of Origin:** China

Warranty and Support

For warranty information or technical support, please visit the official iHome website or contact their customer service. Details are typically provided with your product packaging or on the manufacturer's website.
You can visit the iHome Store on Amazon for more information: iHome Amazon Store

© 2025 iHome. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B088X5FVHN

More documents and user manuals: **https://manuals.plus/**