Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Giochi Preziosi MEC07000

Giochi Preziosi Me Contro Te MEC07000 Headphones User Manual

Model: MEC07000

1. Introduction

Welcome to the user manual for your new Giochi Preziosi Me Contro Te MEC07000 Headphones. These headphones are designed for children aged 3 and above, offering a comfortable and safe listening experience. Please read this manual thoroughly to ensure proper use and maintenance of your product.



Image 1.1: The Me Contro Te MEC07000 Headphones shown in their retail packaging, highlighting the product's design and branding.

2. Product Features

The Me Contro Te MEC07000 Headphones are equipped with features designed for comfort and safety:

- **Me Contro Te Design:** Features popular Me Contro Te branding, allowing users to enjoy their favorite music with a personalized touch.
- **Padded Ear Cushions:** Designed with soft, padded ear cushions to provide enhanced comfort during extended listening sessions.
- **Adjustable Headband:** The headband is adjustable, ensuring a secure and comfortable fit for various head sizes.
- **3.5mm Wired Audio:** Connects via a standard 3.5mm audio jack, compatible with most smartphones, tablets, and other audio devices. The 1.2-meter cable allows for flexible movement.
- **85 dB Volume Limit:** Engineered with a maximum volume output of 85 dB to protect children's hearing.


©ME CONTRO TE Licensed by Me Contro Te srl
Me Contro Te
WOW!
Design originale
me contro te!


Cuscinetti para orecchie
imbottiti per aumentare
il confort durante l uso



Image 2.1: A detailed view of the Me Contro Te branding on the headphone earcup. Image 2.2: A close-up showing the soft, padded ear cushions for enhanced comfort. Image 2.3: The adjustable mechanism of the headband, allowing for a customized fit.

3. Setup Guide

Setting up your Me Contro Te MEC07000 Headphones is straightforward:

1. **Unpack:** Carefully remove the headphones from their packaging.
2. **Identify Audio Jack:** Locate the 3.5mm audio jack on the headphone cable.
3. **Connect to Device:** Insert the 3.5mm audio jack into the corresponding audio port on your desired playback device (e.g., smartphone, tablet, MP3 player). Ensure the jack is fully inserted for a stable connection.
4. **Adjust Headband:** Place the headphones on your head and adjust the headband by sliding the earcups up or down until they fit comfortably over your ears.



Image 3.1: The 3.5mm audio jack, used for connecting the headphones to compatible devices.

4. Operating Instructions

Once connected, operating your headphones is simple:

- **Play Audio:** Start playing audio from your connected device. Sound will be transmitted through the headphones.
- **Volume Control:** Adjust the volume directly on your connected audio device. The headphones are designed with a maximum volume limit of 85 dB to protect hearing.
- **Comfort Check:** Ensure the headphones remain comfortable during use. If discomfort occurs, readjust the headband.



Image 4.1: A child demonstrating the proper wear and fit of the Me Contro Te headphones.

5. Care and Maintenance

To ensure the longevity and optimal performance of your headphones, follow these care instructions:

- **Cleaning:** Use a soft, dry cloth to wipe the exterior surfaces of the headphones. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, store the headphones in a clean, dry place away from direct sunlight and extreme temperatures. Avoid tangling the cable.
- **Handling:** Handle the headphones gently. Avoid dropping them or applying excessive force to the headband or earcups.
- **Cable Care:** Do not pull on the cable to disconnect the headphones from a device. Always grasp the plug firmly.

6. Troubleshooting

If you encounter issues with your headphones, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No sound	◦ Audio jack not fully inserted. ◦ Device volume is too low or muted. ◦ Incorrect audio output selected on device. ◦ Faulty audio cable or jack.	◦ Ensure the 3.5mm jack is securely plugged into the device. ◦ Increase the volume on your audio device and check if it's muted. ◦ Verify the correct audio output is selected in your device's settings. ◦ Test with another audio device or another pair of headphones to isolate the issue.
Distorted sound	◦ Loose connection. ◦ Audio source quality is poor. ◦ Damaged headphone components.	◦ Check the audio jack connection. ◦ Try playing a different audio file or source. ◦ If the issue persists, the headphones may be damaged.

7. Specifications

Feature	Detail
Brand	Giochi Preziosi
Model Number	MEC07000
Model Name	Me Contro Te
Connectivity Technology	Wired
Headphone Jack	3.5 mm Jack
Form Factor	Over-ear
Color	Multi-colored
Product Dimensions	20.8 x 21.1 x 38.6 cm
Item Weight	130 g
Manufacturer Recommended Age	3 years and up
Material Type(s)	Leather (ear cushions)
Batteries Required?	No
Assembly Required?	No
Cable Feature	Retractable

8. Safety Information

Please observe the following safety guidelines:

- **Volume Limit:** The headphones are designed with a maximum volume of 85 dB to protect children's hearing. Do not attempt to bypass or modify this safety feature.
- **Choking Hazard:** Keep the headphones and their components away from very young children who may put small parts in their mouths.
- **Supervision:** Adult supervision is recommended for young children using these headphones.
- **No Warnings Applicable:** According to manufacturer information, there are no specific safety warnings beyond general usage precautions.

9. Warranty and Support

For information regarding warranty coverage, product support, or spare parts, please refer to the documentation included with your purchase or contact Giochi Preziosi customer service directly. Contact details can typically be found on the product packaging or the official Giochi Preziosi website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B088XGJ7WJ

More documents and user manuals: **https://manuals.plus/**